



Bredgar Road, Gillingham, Kent, ME8 6PN

Tel: 01634 386683 e.mail: sales @ mixertech.co.uk

Fax: 01634 386684 Internet: www.mixertech.co.uk

Operating and Maintenance Manual

General

General Instructions For Installation And Maintenance

Rev 03 – 04.08.05

Manual Main Index

| | |
|--|---------------|
| A | |
| Agitator Declaration of Incorporation | 2 to 3 |
| Agitator Long Term Storage | 5 |
| Agitator Parts Lists for 1000 and 2000 Series Mixers with Worm Gearbox | 134 to 136 |
| Agitator Parts Lists for 1000 Series Mixer (Base Plate Mounted) | 128 to 131 |
| Agitator Parts Lists for 2000 Series Mixers (Motor Stool Mounted) | 132 to 133 |
| Agitator Supply of Machinery (Safety) Regulations 1992 | 1 |
| Agitator Trouble Shooting Tips | 10 to 18 |
| ATEX - EC Declaration of Conformity for Gearbox | 117 |
| ATEX - Gearbox Maintenance and Repair | 88 to 89 |
| ATEX - Gearbox Supplement | 114 to 117 |
| ATEX Maintenance and Repair - Gearbox | 88 to 89 |
| B | |
| Bolt Tightening Torques | 22, 23 & 150 |
| Boss Stiffeners | 22 and 23 |
| Bottom Steady Bearing | 24 |
| Breather Plug - Gearbox | 37 to 43 & 82 |
| Bush and Packing (Where Applicable) | 19 |
| D | |
| Declaration of Conformity | 112 |
| Declaration of Incorporation | 2 to 3 |
| Direction of Rotation | 9 and 22 |
| E | |
| EC Declaration of Conformity | 113 |
| Emptying and filling the Vessel with Agitator | 9 |
| F | |
| Flender Gearbox Operating Manual | 25 to 113 |
| G | |
| Gearbox - ATEX Supplement to IoM | 114 to 117 |
| Gearbox - Declaration of Conformity | 112 |
| Gearbox - EC Declaration of Conformity | 113 |
| Gearbox Breather Plug | 82 |
| Gearbox Maintenance and Repair | 88 to 89 |
| Gearbox Manual | 25 to 113 |
| Gearbox Manual Index | 26 to 28 |
| Gearbox Mounting Positions - Helical Bevel Gearbox | 40 to 41 |
| Gearbox Mounting Positions - Helical Worm Gearboxes | 43 |
| Gearbox Mounting Positions - Single Stage Helical Gearbox | 36 |
| Gearbox Mounting Positions - Two and Three Stage Helical Gearbox | 37 to 39 |
| Gearbox Oil Change | 94 |
| Gearbox Oil Change Intervals | 7 |
| Gearbox Trouble Shooting Tips | 85 to 87 |
| Grades of Oil | 99 |
| I | |
| Impeller Blade Fitting Details | 22 and 23 |
| Index for Gearbox Manual | 26 to 28 |
| Installation Of Bottom Steady or Slap Rings (Where Applicable) | 24 |
| L | |
| Labeling (Mixer) - 1000 Series | 153 |
| Labeling (Mixer) - 2000 Series | 152 |
| Labeling (Mixer) - On Gearbox and Shaft | 151 |
| Long Term Storage - Mixer | 5 |
| Lubrication Change - Gearbox | 94 |
| Lubrication Intervals - Gearbox | 7 |
| Lubrication Schedule | 99 |
| M | |
| Maintenance and Repair - Gearbox | 88 to 89 |

| | |
|---|------------------|
| Maintenance and Repair - Gearbox | 88 to 89 |
| Mixer Declaration of Incorporation | 2 to 3 |
| Mixer General Installation and Maintenance Instructions | 6 to 9 |
| Mixer Labeling - On Gearbox and Shaft | 151 |
| Mixer Labeling - 1000 Series | 153 |
| Mixer Labeling - 2000 Series | 152 |
| Mixer Long Term Storage | 5 |
| Mixer Parts Lists for 1000 and 2000 Series Mixers with Worm Gearbox | 134 to 136 |
| Mixer Parts Lists for 1000 Series Mixer (Base Plate Mounted) | 128 to 131 |
| Mixer Parts Lists for 2000 Series Mixers (Motor Stool Mounted) | 132 to 133 |
| Mixer Supply of Machinery (Safety) Regulations 1992 | 1 |
| Mixer Trouble Shooting Tips | 10 to 18 |
| Motor Removal From Gearhead | 72 or 73 |
| Mounting Positions - Helical Bevel Gearbox | 40 to 41 |
| Mounting Positions - Helical Worm Gearboxes | 43 |
| Mounting Positions - Single Stage Helical Gearbox | 36 |
| Mounting Positions - Two and Three Stage Helical Gearbox | 37 to 39 |
| O | |
| Oil Alternatives | 99 |
| Oil Change | 94 |
| Oil Level | 4 & 90 |
| Oil Level - Gearbox | 4 & 37 to 43 |
| Oil Level - Sight Glass (Where Applicable) | 92 |
| Oil Level - Warning | 4 |
| Oil Quantity - ATEX | 34 |
| Oil Quantity - Std | 33 |
| Oil Type - ATEX | 34 |
| Oil Type - Std | 33 |
| Oil Viscosity - ATEX | 34 |
| Oil Viscosity - Std | 33 |
| P | |
| Packed Gland (Where Applicable) | 19 |
| Parts Lists for 1000 and 2000 Series Mixers with Worm Gearbox | 134 to 136 |
| Parts Lists for 1000 Series Mixer (Base Plate Mounted) | 128 to 131 |
| Parts Lists for 2000 Series Mixers (Motor Stool Mounted) | 132 to 133 |
| Parts Lists for Gearboxes | 103 to 107 |
| Proximity Switch Instructions (Where Applicable) | 118 to 127 |
| R | |
| Removable Shaft Coupling Fitting and Removal Procedure (Where Applicable) | 20 to 21 |
| Removal Of Electric Motor | 73 |
| Rotation | 9 and 22 |
| Rotation Sensor Instructions (Where Applicable) | 118 to 127 |
| Running Through Liquid Level | 9 |
| S | |
| Sealing - Packed Gland (Where Applicable) | 19 |
| Stabilising Fins | 22 |
| Start Up - Gearbox | 4 & 82 |
| Stuffing Box (Where Applicable) | 19 |
| Supply of Machinery (Safety) Regulations 1992 | 1 |
| T | |
| Trouble Shooting Tips | 10 to 18 |
| Trouble Shooting Tips - Gearbox | 85 to 87 |
| Turbine Blade Fitting Details | 22,23,137 to 149 |
| V | |
| Ventilation Plug | 82 |
| W | |
| Warning - Oil Level | 4 |



Bredgar Road, Gillingham, Kent, ME8 6PN

Tel: 01634 386683 e.mail: sales @ mixertech.co.uk

Fax: 01634 386684 Internet: www.mixertech.co.uk

SUPPLY OF MACHINERY (SAFETY)

REGULATIONS 1992

The mixer or agitator is considered part of a system, however is CE marked.

A Declaration of Incorporation is supplied in accordance with this.

IMPORTANT


By design, the shaft and impeller of a mixer cannot be guarded.

The unit therefore must not be operated unless it has been installed in the relevant vessel (system) which must comply with the machinery directives.

In addition, we recommend that the electrical supply be equipped with isolators to ensure that the mixer cannot be run whilst entry made to the vessel i.e. manways covers and inspection hatches etc.

Note:

This machinery must not be put into service until the machinery into which it is to be incorporated has been declared in conformity with the provisions of the machinery directive.



Bredgar Road, Gillingham, Kent, ME8 6PN
Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
Fax: 01634 386684 Internet: www.mixertech.co.uk

DECLARATION OF CONFORMITY

Name & Place of Business: Mixertech Limited
Bredgar Road
Gillingham
Kent, ME8 6PN

Responsible Person: Mr A. LaMoury - General Manager

Machinery Description: Series 1000, 2000 and 3000 Top Entry
Mixers and Agitators.
Series 5000 Side Entry Mixers and
Agitators.

EC Type Examination Certificate: Not Applicable

Body To Which Technical File Has Been Forwarded: Not Applicable

Approved Body Issuing Certificate Of Adequacy: Not Applicable


Transposed Harmonised Standards, National Standards & Technical Specifications Used.

| Description | B.S. No | EN/ISO/CEN |
|---|----------------|------------|
| Code of Practice for earthing | 7430 (1991) | |
| Guide to common aspects of installation and equipment for protection against electric shock | PD 6535 (1993) | IEC 1140 |
| Requirements for electrical installations, IEE wiring Regulations, 16th Edition | 7671 (1992) | IEC 364 |
| Memorandum: Construction of electrical equipment for protection against electric shock | 2754 (1976) | IEC 536 |

| | | |
|--|------------------------------|----------------------------|
| Electrical equipment of industrial machines | 2771 Part 1 (1986) | EN 60204 IEC 204. 1 & 2 |
| Code of practice for control of undesirable static electricity | 5958 Part 1 & 2 (1991) | |
| Safety of machinery. Emergency Stop equipment, functional aspects. Principals for design | BS EN 418 (1992) | EN 418 |
| Safety of machinery, Basic concepts, general principles for design | BS EN 292 Parts 1 & 2 (1991) | EN 292 |
| Safety of Machinery. Terminology | DD ENV 1070 (1993) | ENV 1070 |
| Code of Practice for safety of machinery | 5304 (1988) | |

THE MIXER(S) ARE CONSIDERED AS COMPONENTS OF A SYSTEM AND THEREFORE MUST NOT BE PUT INTO SERVICE UNTIL THE MACHINERY INTO WHICH IT IS TO BE INCORPORATED HAS BEEN DECLARED IN CONFORMITY WITH THE PROVISIONS OF THE MACHINERY DIRECTIVES 89/392/EEC, 91/368/EEC, 93/68/EEC AND 93/44/EEC.

A COPY OF THE TECHNICAL FILE IS RETAINED AT THE ABOVE ADDRESS

Signed 

A. LA MOURY
Name (Block Capitals)

GENERAL MANAGER
Position

For and on behalf of Mixertech Limited



WARNING

It is important that the oil level in the gearbox is checked prior to starting the equipment. Should the gearbox oil level be found to low, you must top up with the correct grade of oil.

If the gearbox is not filled with oil at all you must fill to the correct level with suitable lubrication. Please see IoM for details.

Starting the equipment with low or no oil will cause early and expensive failures

If in any doubt please contact Mixertech Limited on

Tel - 01634 386684


Fax – 01634 386684

Email – sales@mixertech.co.uk

Engineering Dept

MIXERTECH
LIMITED

Station Road, Greenhithe
Kent, DA9 9NG, England
Tel 01322-383281
Fax 01322-386684



Storage Procedure Specification

In the event of the equipment being stored for periods of one month and above we recommend the following.

- That the electric motor fan cowl is removed and the fan rotated in either direction by 1/4 of one revolution. This will help prevent the geared motor bearing bruneling and the gland bush and packing binding to the shaft
- Should the equipment be stored in the horizontal position the shafts must be carefully supported along their lengths to prevent them from sagging and ultimately bending.
- It is always beneficial to pack the equipment in a wooden create if they are to be stored for long periods of time.
- It is always best to install the mixers into the vessels so that the shafts hang vertically under their own mass. This will also help prevent damage to the wetted ends whilst in storage
- Before commissioning the equipment always check the oil level in the gearbox and fit the breather plug supplied.
- Refer to the specific gearbox long term storage instructions. If you can not locate the information please contact Mixertech Limited for further details

Should you have any queries please do not hesitate to contact us.

Steve Phillips

(Contracts Engineering)

SJP - 08.01.99.

Doc Ref - C:\Word-QA-Storage Procedure



Bredgar Road, Gillingham, Kent, ME8 6PN
Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
Fax: 01634 386684 Internet: www.mixertech.co.uk

MIXERTECH 1000/2000 SERIES FLUID MIXERS WITH FLENDER MOTOX & SEW GEARED MOTORS

CONTRACT NO:

SERIAL NO:

INSTRUCTIONS FOR INSTALLATION AND MAINTENANCE

**PLEASE READ CAREFULLY BEFORE INSTALLING OR OPERATING
YOUR MIXERTECH MIXER**

INSTALLATION

General

Units should be bolted into place as rigidly as possible to minimise vibration and movement.

Where fitted 'G' clamp mounts should be tightened using a 10mm Allen Key.

Sleeve couplings are secured to geared motor shaft and mixer output shaft by 6 or 8mm offset grub screws. When assembling, care should be taken to ensure correct seating of grub screws into 'dimples' on respective shafts.

Split muff type couplings should be assembled with even tightening of bolts after checking that drive keys are clean and neatly engaged.

Propellers are secured in a similar manner with two 6mm grub screws.



Bredgar Road, Gillingham, Kent, ME8 6PN
Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
Fax: 01634 386684 Internet: www.mixertech.co.uk

MAINTENANCE

General

Maintenance of **Mixertech** mixers is mainly limited to the geared driving motor, however, the periodic checking of mounting bolts and fixing grub screws is advised.

Geared Motor

To ensure adequate cooling, deposits of dirt and dust on the surfaces of the units must be removed at frequent intervals. Particular attention should be paid to the motor by removing all deposits from between the motor cooling fins and also from the air intake on the fan guard.

To ensure correct performance, highest efficiency and long life, it is essential that the lubricating oil be maintained at the correct level. The recommended grade of oil must be used at all times, since the use of unsuitable oil may result in excessive temperature rise, loss of efficiency and consequent damage to gears and bearings.

The lubricating oil level should be checked at regular intervals. We recommend that the first oil change should be carried out after approximately 500 hours initial operation and thereafter. Under normal operating conditions the oil should be changed every 10,000 operating hours. If however, a synthetic lubricant is used, then this period of time can be extended to 20,000 hours or alternatively four years maximum. In applications where arduous operating conditions exist, the lubricant should be changed at more frequent intervals. Grease packed bearings should be cleaned and re-greased every 10,000 hours, care being taken that only approximately 40% of the free volume of the bearing is filled with grease in order to avoid overheating of the bearing.

Whenever the lubricating oil is changed it is preferable to dismantle and thoroughly clean the gear case, gear wheels and bearings. After dismantling, the component parts of the gear unit should be thoroughly cleaned with flushing oil or cleaning benzene and all gear case joints should be cleaned to ensure that all traces of the original sealing compound are removed. Any foreign matter and the cleaning fluid should be removed from the gear unit bearings and gear wheels. The bearings should be re-greased immediately after cleaning and drying. When re-assembling, all mating

MIXERTECH LIMITED



Bredgar Road, Gillingham, Kent, ME8 6PN
Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
Fax: 01634 386684 Internet: www.mixertech.co.uk

Surfaces of the gear case must be free from oil and grease and coated with an oil resistant sealing compound.

IMPORTANT

When the recommended lubricate is not available, it is permissible to use a lubricant having similar characteristics, but we do not recommend that the lubricants of difference manufacture be mixed. Under no circumstances should a synthetic lubricant be mixed with one having a mineral base.



Bredgar Road, Gillingham, Kent, ME8 6PN
Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
Fax: 01634 386684 Internet: www.mixertech.co.uk

Gearboxes are filled prior to despatch with correct quantity and grade of lubricating oil (or grease where specified).

Important

Before putting the unit into service, change the closing plug in the highest position for the breather plug supplied.

Electrical Connections

Care should be taken to connect the motor correctly in accordance with the information contained on the motor data plate and the circuit diagram contained in the motor terminal box. The motor starter should incorporate an overload device to protect the windings against damage which, could otherwise result from overload or failure of one or more phases of the electrical supply.

This is particularly important in cases where the motor starter windings are not provided with built in temperature detectors connected to suitable overriding control gear. In the case of motors controlled by Star/Delta starters, the line voltage must correspond to the Delta voltage as indicated on the motor data plate. Motors rated up to 4 kW are suitable for direct on line starting if local regulations permit. Care should be taken at all times to ensure adequate ventilation of the motor.

IMPORTANT

- 1. PROPELLER SHOULD ROTATE IN A CLOCKWISE (DOWN THRUST) DIRECTION (VIEWED FROM TOP DRIVE END).**
- 2. UNIT SHOULD NOT BE RUN WHILE FILLING OR EMPTYING VESSEL UNLESS STABILIZER IS FITTED.**



Bredgar Road, Gillingham, Kent, ME8 6PN
Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
Fax: 01634 386684 Internet: www.mixertech.co.uk

Trouble Shooting Tips

Your Mixertech mixer drive will perform satisfactorily if the following suggestions are carefully carried out.

It is estimated that approximately 98 percent of gear reduction failures can be attributed to improper lubrication, misapplication and misalignment.

Improper lubrication causes a high percentage of gear reduction unit failures. Too frequently speed reducers are started up without any lubricant at all. Conversely, units are sometimes filled to a higher oil level than specified in the belief that better lubrication is obtained. This higher oil level usually results in more of the input power going in to churning of the oil, creating excessive temperatures with detrimental results to the bearings and gearing. Insufficient lubrication causes the same results.

Gear failure due to overload is a broad and varied area of misapplication. The nature of load (input torque, output torque, duration of operating cycle, shocks, speed, acceleration, etc.) determines the gear unit sizing and other design criteria. Generally, a mixer drive must be larger than the torque output capability of the prime mover would indicate.

A gearbox service factor compensates for varying severity of application conditions by providing a higher nominal power rating which in effect increases the size of the gear unit. If there is any question in the user's mind that the actual service conditions may be more severe than originally anticipated, it is recommended that this information be communicated to the mixer supplier before start-up. Often there are remedies that can be suggested before a mixer unit is damaged by overload, but none are effective after severe damage occurred.

MIXERTECH LIMITED



Bredgar Road, Gillingham, Kent, ME8 6PN
Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
Fax: 01634 386684 Internet: www.mixertech.co.uk

Motors and other prime movers should be analysed while driving the mixer unit under fully loaded conditions to determine that the prime mover is not overloaded and thus putting out more than rated torque. If it is determined that overload does exist, the unit should be stopped and steps taken to either remove the overload or contact MixerTech to determine suitability of the gear drive under observed conditions.

Once the mixer has been delivered to site and installed, check the following items:-

This is known as '**RAMBO**'

1. **Rotation** - Is the mixer going around in the correct direction.
2. **Assembly** - Is the mixer assembled correctly, especially the impeller - check the GA drawing
3. **Mounting Arrangement** - Check the gearbox is level and the shaft is vertical.
4. **Bolting** - Are all bolts torqued to the correct readings.
5. **Oil** - Check oil level and grade in gearbox.

Once these simple five steps have been completed hot commissioning can commence.

If during hot commissioning problems occur, check the following trouble shooting charts for possible causes.




Bredgar Road, Gillingham, Kent, ME8 6PN
Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
Fax: 01634 386684 Internet: www.mixertech.co.uk

Problem: The electrical motor constantly trips out or is running at a high temperature.
Note: Most motors are to Class F, temperature will rise which gives an operating temperature to 100 degrees C. Direct sunlight and high ambient temperatures could cause this to rise by as much as 15 degrees.

| Inspection | Action |
|----------------------|---|
| Check Tank | Check number and sizes of baffles, also proximity of impeller to tank bottom. |
| Sample Tank Contents | Check specific gravity of tank contents. |
| Gearbox | Is unit free to rotate? Remove motor Fan cover and rotate by hand. If answer is No - then see ' Gearbox won't rotate' |
| Check Rotation | See direction arrow on nameplate. |
| Check Oil | Remove and refill with correct grade of oil and grease. |
| Check Oil Level | Use dipstick or oil level plug. Top up if required. |
| Check Breather | Clean with solvent or paraffin. |
| Check Impeller | Remove any debris. Measure diameter tip to tip and check with GA drawing. |

MIXERTECH LIMITED



Bredgar Road, Gillingham, Kent, ME8 6PN

Tel: 01634 386683 e.mail: sales @ mixertech.co.uk

Fax: 01634 386684 Internet: www.mixertech.co.uk

Check Speed of Rotation

Count number of revolutions per Minute of output shaft and check nameplate for same.

Check Gearbox Mounting

Release holding down bolts and re-shim to level gearbox.

Check Input Coupling

Disconnect motor. Realign as required.

Check oil Seals

Oil seals must be grease packed . High temperatures will cause seals to crack.

Switch Gear

Check overload settings.

Motor in Direct Sunlight.

Shade motor - do not cover - allow for good ventilation.



Bredgar Road, Gillingham, Kent, ME8 6PN
Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
Fax: 01634 386684 Internet: www.mixertech.co.uk

Problem: Gearbox won't rotate or is difficult to turn. Gearbox should be free to rotate by hand , they do not require a running-in period.

| Inspection | Action |
|-------------------------|--|
| Check Gearbox Mounting | If gearbox is incorrectly bolted down then the casing can be twisted thus misaligning bearings and gears. |
| Bearings | Remove cover plates, check bearings for wear or obstructions. Replace as necessary . Check end float in workshop. |
| Gears | Remove inspection cover, if worn return to workshop for repair. Check backlash If excessive return to workshop for repair. |
| Check Gearbox Internals | Corrosion of bearings and gears is possible after long storage. Return to workshop for overhaul. Remove any mud or sand. Return to workshop for overhaul. Modify installation to prevent ingress of solids. |
| Check Stuffing Box. | Slacken glandplate. Back of packing. |

MIXERTECH LIMITED



Bredgar Road, Gillingham, Kent, ME8 6PN
Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
Fax: 01634 386684 Internet: www.mixertech.co.uk

Problem: Gearbox leaks oil - oil at high temperature is almost impossible to seal. It can weep through gearbox casings, out of breathers and at shaft oil seals. The mess this can make is usually out of all proportion to the amount actually lost. Good house-keeping is required to remove any surface deposits.

| Inspection | Action |
|----------------------------|---|
| Drive Output shaft | Has recommended oil level been exceeded. Check oil level in gearbox, when stationary. |
| Is breather clean and open | A dirty blocked breather will not allow the hot air in the gearbox to escape. This will pressurize box and force oil out. Clean breather in paraffin or solvent. |
| Check Housings and Caps | Tighten bolts. If it still persists apply joint sealer - do not fit gaskets. End caps and body joints are machined surfaces and additional packing will alter gearbox tolerances, end float etc. |
| Check Oil Seals | Replace if worn. Check shaft for damage. Polish if necessary. |
| Check Housing Joint | Check oil level, reduce if necessary. |

MIXERTECH L I M I T E D



Bredgar Road, Gillingham, Kent, ME8 6PN
Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
Fax: 01634 386684 Internet: www.mixertech.co.uk

Problem: Gearbox is running hot. Although heat can be a sign of wear, it need not always be true. Gearbox temperatures normally rise by up to 80 degrees C and the final operating temperature can be over 100 degrees C. The gearbox will operate without problems at this temperature and higher provided the correct lubrication is supplied and changed at the prescribed intervals. However, if sudden or unexpected temperature increase occurs check the following:-

| Inspection | Action |
|--------------------------------|--|
| Is oil level low | Check oil level in gearbox. |
| Check Breather | Breather must be open and clean. |
| Check oil seal | Output shaft bearing and oil seal are grease lubricated . Re-lubricate and check oil seal for damage. |
| Oil Grade | Check grade. Flush box and refill with correct lubricant. |
| Oil quality and condition | Constant running at high temperatures causes rapid breakdown of lubricant. Check to see if oil has oxidized, dirty or contains sludge. Flush box and refill. |
| Check input coupling alignment | Disconnect coupling and realign. |
| Check bearing adjustment. | Bearings must not be pinched or Binding. Adjust to correct end float. All shafts must spin freely when disconnected from load. |




Bredgar Road, Gillingham, Kent, ME8 6PN
Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
Fax: 01634 386684 Internet: www.mixertech.co.uk

Problem: Mixer vibrates or is rocking - because a mixer is rotating equipment it will vibrate and rock. However, excessive movement is detrimental to the equipment and could cause premature failure.

| Inspection | Action |
|----------------------------|--|
| Check Impellers | Tighten bolts if required. Check for correct installation. |
| Check holding down bolts. | Tighten bolts on mixer bridge and baseplate. |
| Check foundation steelwork | Stiffen or brace steelwork. |
| Check shaft. | Is it straight? Is it vertical? Drop plumbline from coupling. |
| Check output coupling | Is it fitted correctly? Remove burrs And sharp edges - tighten coupling bolts. |
| Critical speed | Refer to supply for design calculations. Reduce speed to 30% below critical speed. |
| Steady bearing (if fitted) | Check for wear and for slack bolts. |
| Liquid level | Is mixer designed to operate at varying liquid levels. Check stabilizers on blades. Limit variation. |

MIXERTECH LIMITED



Bredgar Road, Gillingham, Kent, ME8 6PN
Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
Fax: 01634 386684 Internet: www.mixertech.co.uk

Problem: Mixer makes a noise - a mixer is a rotating piece of equipment and as such will generate noise. The noise level will normally be 85 decibels at 1 metre which will be consistent. Beware random noise or knocks and high pitch sounds.

| Inspection | Action |
|-------------------------|---|
| Check motor fan cowling | Re-adjust as necessary. |
| Check Bearings | Replace or lubricate |
| Check gears | Adjust or replace |
| Check gear casing | Remove any debris found and refill With correct grade of lubricant. Remove rust and make necessary provision to prevent entrance of water. |
| Check tank contents | Remove any timber, hard hats etc. |



Bredgar Road, Gillingham, Kent, ME8 6PN
Tel: 01634 386683 e.mail: sales@mixertech.co.uk
Fax: 01634 386684 Internet: www.mixertech.co.uk


Operating and Maintenance Manual Gland Plate Assembly

The gland plate helps to create a seal between the inside of the vessel and atmosphere via, between 6 and 9 rows of gland packing. Or 3 rows of packing and a running bush, the combination/s then sit tightly around the mixer shaft thus creating a seal providing some support.

The gland packing stack is housed within the throat of the gland plate, which is ultimately bolted to the vessel nozzle, and held down in position by a gland follower.

When installing the equipment it is important that the gland plate and packing are correctly located around the shaft and that it does not pre load the shaft when bolted down onto the vessel nozzle.

This is best achieved by simply allowing the gland plate assembly to slide down the shaft and rest on top of the nozzle one down place each of the bolts through the plate and nozzle and tighten to the recommended bolt torque.



Incorrect assembly of the Gland Plate will cause early failure of the Mixer/Agitator. If in any doubt please do not hesitate to contact us.

19



Bredgar Road, Gillingham, Kent, ME8 6PN
Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
Fax: 01634 386684 Internet: www.mixertech.co.uk

Confidential

TITLE: *REMOVABLE FLANGE COUPLING
FITTING PROCEEDURE*

Modification

Please refer to Drawing No. 1000/01

- 1. Ensure shaft end, and inside of coupling are clean and free from burrs.*
- 2. Ensure shoulder on shaft is also clean and free from burrs.*
- 3. Fit key (5) into shaft.*
- 4. Smear shaft with copper slip or other anti-galling substance.*
- 5. Slide coupling (4) onto shaft (1).*
- 6. Ensure shaft sits down on shaft shoulder and the slide fit is a neat fit i.e. coupling does not rock on shaft.*
- 7. Fit locating/spigot plate (3) to coupling ensure shaft end does not protrude past spigot plate face.*
- 8. Fit 8.8 H.T bolts c/w spring washer and torque to recommend bolting torques given in service manual for the correct bolt size. Ensure bolt heads do not protrude outside spigot plate.*
- 9. Remove coupling in reverse order.*

MIXERTECH LIMITED


Bredgar Road, Gillingham, Kent, ME8 6PN

Tel: 01634 386683

e.mail: sales @ mixertech.co.uk

Fax: 01634 386684


Internet: www.mixertech.co.uk



MIXERTECH LIMITED



Bredgar Road, Gillingham, Kent, ME8 6PN
 Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
 Fax: 01634 386684 Internet: www.mixertech.co.uk






Bredgar Road, Gillingham, Kent, ME8 6PN
 Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
 Fax: 01634 386684 Internet: www.mixertech.co.uk

ENSURE THAT ALL COUPLING FACES ARE FREE OF OIL AND GREASE. ALSO THAT ANY CORROSION PROTECTION MEDIUMS ARE COMPLETELY REMOVED. CHECK COUPLING FACES AND REMOVE ANY DAMAGE OR BURRS.

| REQUIRED BOLT TORQUE (Nm) | |
|---------------------------|-------------------|
| BOLT DIA. | GR. 8,8 HTS BOLTS |
| 16 | 178 |
| 20 | 348 |
| 24 | 600 |
| 30 | 1190 |



MIXERTECH

TEL. 01634 386683
 FAX. 01634 386684
 GILLINGHAM - KENT

CONFIDENTIAL

UNLESS INDICATED OTHERWISE ALL RIGHTS RESERVED THE PROPERTY OF MIXERTECH AND ARE STRICTLY CONFIDENTIAL. THE INFORMATION CONTAINED HEREIN SHALL NOT BE DISCLOSED TO THIRD PARTIES WITHOUT PRIOR WRITTEN COMMENT BY MIXERTECH.

SCALE:

N.T.S.

DRAWN:

A.E. ISAACS

DATE:

04/05/98


MANUFACTURING NOTES:

1. .
 2. .
 3. .

TITLE: IMPELLERS AND SHAFT ASSEMBLY

DRG. No.: C14703/ASSY

REV.




INSTALLATION OF BOTTOM STEADY BEARING OR SLAP RINGS

A bottom steady bearing (or slap ring) must be installed only after the drive assembly and lower agitator shaft, complete with impellers, has been assembled and firmly bolted in place: Do not predetermine the exact bearing location from certified tank and mixer outline dimension drawings. The vertical centre line of the steady bearing must coincide with the shaft's axis of rotation to minimise bearing preload.

This axis may not necessarily be at the centre of the tank. The agitator shaft must be hand rotated (using input shaft coupling or motor fan with a fixture attached to the shaft to scribe a line on the tank bottom. The centre of this inscribed area will be the location for the centre of the steady bearing.

The steady bearing should be securely installed, with its vertical centreline coincident with the axis of rotation, as established.


The amount of lateral movement required to bring the shaft into proper alignment with the final steady bearing location will vary, depending upon the shaft length and diameter.



True location of bottom steady or slap ring

Operating Instructions

BA 2010 EN 05.04



MOTOX[®]-N

Gear Units

FLENDER
TÜBINGEN

FLENDER TÜBINGEN GMBH · Bahnhofstr. 40-44 · D-72072 Tübingen
Telefon +49 (0) 70 71 - 707 0 · Fax +49 (0) 70 71 - 707 400 · <http://www.flender.com>

E-mail: sales-motox@flender-motox.com

A company of the Flender group

Contents

| | | |
|-----------|---|-----------|
| 1. | Important instructions | 6 |
| 1.1 | Instruction symbols in the operating instructions | 6 |
| 1.2 | General instructions | 6 |
| 1.3 | Amendments | 7 |
| 2. | Safety instructions | 8 |
| 2.1 | Intended use | 8 |
| 2.2 | General safety instructions | 8 |
| 3. | Technical data | 9 |
| 3.1 | Type designations | 9 |
| 3.2 | General technical data | 10 |
| 3.3 | Weights | 11 |
| 3.4 | Sound-pressure level | 11 |
| 3.5 | Mounting positions | 12 |
| 3.5.1 | One-stage helical gear units | 13 |
| 3.5.2 | Two and three-stage helical gear units | 14 |
| 3.5.3 | Bevel-helical gear units | 17 |
| 3.5.4 | Parallel shaft helical gear units | 19 |
| 3.5.5 | Helical worm gear units | 20 |
| 3.5.6 | Tandem gear unit - compound helical gear unit | 21 |
| 3.6 | Oil quantities | 22 |
| 3.6.1 | Helical gear units | 22 |
| 3.6.2 | Bevel-helical gear units | 23 |
| 3.6.3 | Parallel shaft helical gear units | 24 |
| 3.6.4 | Helical worm gear units | 24 |
| 3.6.5 | Tandem gear unit - compound helical gear unit | 25 |
| 3.6.5.1 | Two and three-stage helical gear units | 25 |
| 3.6.5.2 | Bevel-helical gear units | 26 |
| 3.6.5.3 | Parallel shaft helical gear units | 28 |
| 3.6.5.4 | Helical worm gear units | 29 |
| 4. | Technical description | 30 |
| 4.1 | General description | 30 |
| 4.2 | Housing | 30 |
| 4.3 | Toothed components | 30 |
| 4.4 | Lubrication | 30 |
| 4.5 | Shaft bearing | 30 |
| 4.6 | Shaft seals | 30 |
| 4.7 | Cooling | 30 |
| 4.8 | Couplings | 30 |
| 4.9 | Backstop | 31 |
| 4.10 | Rating plates | 31 |
| 4.11 | Paint coats | 32 |
| 4.11.1 | General | 32 |
| 4.11.2 | Painted version | 32 |
| 4.11.3 | Primed version | 33 |
| 5. | Incoming goods, Handling and Storage | 34 |
| 5.1 | Incoming goods | 34 |
| 5.2 | Handling | 34 |
| 5.3 | Storage | 35 |

| | | |
|-----------|---|-----------|
| 6. | Installation | 36 |
| 6.1 | General information on installation | 36 |
| 6.2 | Fastening in the case of reversing operation or high shock loads | 36 |
| 6.3 | Drives with foot mounting | 37 |
| 6.3.1 | Foundation | 37 |
| 6.3.2 | Installing gear units with foot mounting | 37 |
| 6.4 | Drive units in foot or flange version | 37 |
| 6.5 | Drive units with C-type housing flange | 38 |
| 6.6 | Installation of input drive and output drive elements on gear unit shafts | 40 |
| 6.7 | Steel safety cover for hollow shaft and shrink disc | 41 |
| 6.8 | Cast iron end cover for hollow shaft | 42 |
| 6.9 | Shaft-mounting gear unit with hollow shaft and parallel key, hollow shaft and splines, hollow shaft and shrink disc | 43 |
| 6.9.1 | Mounting the hollow shaft | 43 |
| 6.9.2 | Remove hollow shaft and parallel key | 45 |
| 6.9.3 | Suggested design for threaded piece and disc | 46 |
| 6.10 | Shrink disc | 47 |
| 6.10.1 | Mounting the shrink disc | 47 |
| 6.10.2 | Pulling off the shrink disc | 48 |
| 6.10.3 | Cleaning and greasing the shrink disc | 48 |
| 6.11 | Attachment of standard motors | 49 |
| 6.11.1 | Fit standard motor on coupling housing with torsionally flexible coupling | 49 |
| 6.11.2 | Using a clamp ring, attach standard motor to coupling housing | 50 |
| 6.12 | Motor base plate | 52 |
| 6.12.1 | Mounting IEC motors up to size 112 | 53 |
| 6.12.2 | Mounting IEC motors sizes 132 to 200 | 54 |
| 6.12.3 | Mounting IEC motors from size 225 | 55 |
| 6.13 | Torque arm with shaft-mounted gear units | 56 |
| 6.13.1 | Fit torque arm to bevel helical gear unit | 56 |
| 6.13.2 | Mounting torque arm on parallel shaft helical gear unit | 57 |
| 6.13.3 | Mounting torque arm on helical worm gear unit | 58 |
| 7. | Start-up | 59 |
| 7.1 | Oil level check before start-up | 59 |
| 7.2 | Fill in oil | 59 |
| 7.3 | Ventilation of the gear unit | 59 |
| 7.3.1 | Filter for ventilation or pressure relief valve without securing clip | 59 |
| 7.3.2 | Pressure relief valve with securing clip (special version) | 59 |
| 7.4 | Start-up after long-term preservation | 60 |
| 7.4.1 | Long-term preservation up to 18 months | 60 |
| 7.4.2 | Long-term preservation up to 36 months | 60 |
| 7.5 | Drive with backstop (special version) | 60 |
| 8. | Operation | 61 |
| 9. | Faults, causes and remedy | 62 |

| | | |
|------------|---|-----------|
| 10. | Maintenance and repair | 65 |
| 10.1 | General information for maintenance | 65 |
| 10.2 | Description of maintenance and repair work | 66 |
| 10.2.1 | Oil level | 66 |
| 10.2.1.1 | Check the oil level in the gear housing | 67 |
| 10.2.1.2 | Checking the oil level by the oil sight glass (special version) | 69 |
| 10.2.1.3 | Checking the oil level by the oil dipstick (special version) | 69 |
| 10.2.1.4 | Checking the oil level sensor (special version) | 69 |
| 10.2.2 | Oil quality | 69 |
| 10.2.3 | Oil change | 70 |
| 10.2.4 | Replacing bearings | 71 |
| 10.2.5 | Relubrication of the rolling bearings in drive units | 71 |
| 10.2.6 | Change rolling bearing grease | 72 |
| 10.2.7 | Seal check | 72 |
| 10.2.8 | Clean ventilation filter | 72 |
| 10.2.9 | Clean drive | 72 |
| 10.2.10 | Checking tightness of fastening bolts | 73 |
| 10.2.11 | Inspection of the drive | 73 |
| 10.2.12 | Carry out maintenance on slip coupling | 73 |
| 10.3 | Lubricants | 74 |
| 11. | Disposal | 78 |
| 12. | Stocking spare parts and customer service addresses | 79 |
| 12.1 | Stocking spare parts | 79 |
| 12.2 | Spare parts lists | 80 |
| 12.2.1 | One-stage helical gear units | 80 |
| 12.2.2 | Two and three-stage helical gear units | 81 |
| 12.2.3 | Bevel-helical gear units | 82 |
| 12.2.4 | Parallel shaft helical gear units | 83 |
| 12.2.5 | Helical worm gear units | 84 |
| 12.3 | Customer-service addresses | 85 |
| | FLENDER TÜBINGEN GMBH Germany | 85 |
| | FLENDER TÜBINGEN GMBH Europe | 86 |
| | FLENDER TÜBINGEN GMBH International | 87 |
| 13. | Declaration by the manufacturer, Declaration of Conformity | 89 |
| 13.1 | Declaration by the manufacturer | 89 |
| 13.2 | EC Declaration of Conformity | 90 |

1. Important instructions

1.1 Instruction symbols in the operating instructions

Instructions relating to operating safety are emphasized as follows:



Danger.
Possible consequences: Death or very severe injuries.



Caution.
Possible consequences: Damage to the drive and the environment.



Note.
Pointers for application and useful information.



Drives in ATEX version.
Instructions and measures applying in particular to drives in ATEX version.

1.2 General instructions

These operating instructions are an integral part of the gear unit delivery.

These operating instructions apply to the standard version of the **MOTOX[®]-N** gear unit:

Helical gear units E, Z and D Size 38 - 188.

Bevel-helical gear units K Size 38 - 188.

Parallel shaft helical gear units F Size 38B - 188B.

Helical worm gear units C Size 38 - 88.



Note.
Special types of drive and their additional equipment are governed by the special contractual agreements and technical documents.
Note also the other operating instructions for couplings, motors, brake motors, additional equipment for motors, etc., delivered with the equipment.



Note.
We accept no responsibility for damage or disruption resulting from disregard of these operating instructions.

Keep these operating instructions in the vicinity of the gear unit.

Read these operating instructions before working with the drive.

Only a precise knowledge of these operating instructions will guarantee reliable, faultfree operation of the drive by avoiding operating errors and improper use.

The drives described in these Instructions reflect the state of technical development at the time these instructions went to print.

In the interest of technical progress we reserve the right to make changes to the individual assemblies and accessories which we regard as necessary to preserve their essential characteristics and improve the efficiency and safety of the drive.

The copyright to these operating instructions is held by **FLENDER TÜBINGEN GMBH**.

These operating instructions must not be wholly or partly reproduced, used in any unauthorised way for competitive purposes or made available to third parties without our agreement.

Amendments or additions to these operating instructions may be made only by us; otherwise any guarantee claim against us will lapse.

Technical enquiries should be addressed to the following works

FLENDER TÜBINGEN GMBH

Postfach 1709 · D-72007 Tübingen

Bahnhofstr. 40-44 · D-72072 Tübingen

Telefon +49 (0) 70 71 - 707 0

Fax +49 (0) 70 71 - 707 400

E-mail: sales-motox@flender-motox.com

<http://www.flender.com>

24 h Service Hotline +49 (0) 172 - 7 32 29 55

or to one of our customer-services. The addresses of the customer-services are given in section 12. "Stocking spare parts and customer service addresses".

1.3 Amendments

These amended overall operating instructions replace the individual operating instructions BA G298, BA K298, BA F298, BA F298B and BA S298 including their annexes.

2. Safety instructions

2.1 Intended use

The **MOTOX[®]-N drives** described in these operating instructions have been developed for stationary use in general engineering applications. Unless otherwise agreed, the drives have been designed for use in plant and equipment in industrial environments.

The drives have been manufactured in accordance with the state of the art and are delivered in a condition for safe and reliable use. Any changes on the part of the user which may affect safety and reliability are prohibited.

The drives are designed only for the application described in section 3. "Technical data". They must not be operated outside the specified power limits. Other operating conditions must be contractually agreed.



Drives in ATEX version.

The ATEX drive satisfies the requirements of explosion safety guideline 94/9/EG. The performance data apply at an ambient temperature of $-20\text{ }^{\circ}\text{C}$ to $+40\text{ }^{\circ}\text{C}$.

In the case of drives in ATEX version please observe the instructions marked with this symbol.

2.2 General safety instructions

The drives must be installed, started up, operated, maintained and, if necessary, repaired only by authorised, properly trained and qualified personnel. For definition of expert staff, refer to i.a. IEC 364.

The operator must ensure that all persons involved in installation, operation, maintenance and repair have read and understood these operating instructions and comply with them at all times in order to:

- avoid injury or damage
- ensure the safety and reliability of the drive
- avoid disruptions and environmental damage through incorrect use.

Carry out work on the drives only when they are at a standstill.

Secure the drive units against unintentional starting (e.g. lock key switches or remove fuses in the power supply).

A notice should be attached to the start switch stating clearly that work on the drives is in progress.

Carry out all work with great care and with due regard to safety.

Always observe the instructions on the plates on the drives. The plates must be kept free from paint and dirt at all times. Replace any missing plates.

Ensure compliance with the relevant safety and environmental regulations during transport, assembly and dismantling, operation, and care and maintenance of the unit.

Secure rotating drive parts, e.g. couplings, gears or belt drives, against contact by means of suitable safety devices.


Ensure adequate ventilation when working with solvents. Do not inhale vapours. Do not smoke.

Collect and dispose of used oil in accordance with regulations. Remove any oil spillage immediately with an oil-binding agent in compliance with environmental requirements.

When installing the drives in plant or equipment, the manufacturer of such plant or equipment must ensure that the contents of the present operating instructions are incorporated in his own instructions, information and descriptions.

3. Technical data

3.1 Type designations



Gear unit type

- (-)** Helical gear unit
- K** Bevel helical gear unit
- F** Parallel shaft helical gear unit
- C** Helical worm gear unit

Compound helical gear unit

- Transmission steps**
- Z** two-stage
 - D** three-stage

Transmission steps

- (-)**
- E** single-stage
- Z** two-stage
- D** three-stage

Drive group

- K4** Bell housing with stub-shaft connection for IEC flanged motors
- K2** Bell housing with flexible coupling for IEC flanged motors
- A** Drive flange with free drive flange
- P** Motor bedplate version

Type

- Shaft**
- (-)** Solid shaft
 - A** Hollow shaft

Fixing

- (-)** Foot-mounted design
- F** Flanged version (A-type)
- Z** Housing flange (C-type)
- D** Torque arm
- G** Flange (A-type) opposite output shaft
- R** Agitator flange
- M** Agitator / mixer flange
- E** Extruder flange

Connection

- (-)** Parallel key
- S** Shrink disc
- T** Hollow shaft with splines

Backstop

- X** Backstop in intermediate stage

3.2 General technical data

The most important technical data are shown on the rating plate of the gear units of gear motors. These data together with the contractual agreements on the drive units determine the limits of its proper use.

In the case of gear motors a rating plate attached to the motor serves for the entire drive.

In certain cases separate rating plates are attached to the gear unit and the motor.

Examples: Rating plate - gear motor

Rating plate - gear unit





Figure 3.2-1: Rating plate

- | | |
|--|--|
| <ul style="list-style-type: none"> 1 Company logo 2 Manufacturing date encoded 3 Weight m [kg] 4 Order no. / seq. no. 5 Model - Type - Size 6 Performance rating T_2 [Nm] 7 Mounting position 8 Total transmission ratio i 9 Speed n_2 [min^{-1}] 10 Type of oil 11 Oil viscosity ISO VG class to DIN 51519 / ISO 3448 12 Oil quantity [l] Main gear unit / ancillary transmission+extruder flange 13 Free space for additional data 14 max. ambient temperature $T_{U_{\text{max}}}$ [$^{\circ}\text{C}$] | <ul style="list-style-type: none"> 15 Phase number and type of current of the motor 16 Switch symbols to DIN EN 60617 T6 / IEC 617-6 18 Rating voltage U [V] 18 Rating current I [A] 19 Rating frequency f [Hz] 20 Rating speed n [min^{-1}] 21 Rating performance P [kW] 22 Operating mode (if \neq S1) 23 Performance factor $\cos \varphi$ 24 Type of protection to IEC 60034-5 or IEC 529 25 Heat class Th. Cl. 26 applied standard 27 CE-marking or other marking, if any 28 Brake data |
|--|--|

Symbols (IEC 617-2): = Brake
 = Coupling



Drives in ATEX version.
Example: Rating plate




Figure 3.2–2: Rating plate ATEX version



- | | |
|---|--|
| <p>1 Type designation</p> <p>2 Mounting position, order number</p> <p>3 Output speed n_2 [min^{-1}] Output torque T_2 [Nm] Transmission ratio i Duty factor Input speed n_1 [min^{-1}] Input torque T_1 [Nm]</p> | <p>4 Explosion-hazard symbol and explosion-hazard marking, CE-marking</p> <p>5 Oil quantity [l] Type of oil Weight m [kg]</p> <p>6 Space for additional information</p> |
|---|--|

3.3 Weights

The weight of the overall drive including motor is indicated on the rating plate of the gear unit or gear motor, if it exceeds 30 kg; in each case it is shown in the delivery documents.

Where there are several rating plates on one drive, the specification on the main gear unit is decisive.

The weight specification refers only to the condition on delivery of the products.

3.4 Sound-pressure level

The A-assessed sound-pressure levels L_{WA} of a selection of gear units in figure 3.4 “Sound-pressure level” have been measured to DIN EN 21680, using measuring instruments to DIN IEC 651.

The noise depends mainly on speed, output and transmission ratio.




Figure 3.4: Sound-pressure level

The sound-pressure levels of **MOTOX®-N gear motors** fall mainly in the dark-coloured part of the range. Gear units with very small transmission ratios, high output and high input speed may fall in the cross-hatched part.

If repeat measurements on site do not produce conclusive results with regard to measuring technology, the measurement obtained on the **FLENDER TÜBINGEN GMBH** test bench will apply.

External noises

Noises not generated by the gear unit but emitted from it are not taken into consideration here.

Likewise noises emitted from the prime mover and output machines and from the foundation are not taken into consideration here, even if transmitted to these by the gear unit.

3.5 Mounting positions

The assembly option designations are in accordance with IEC 60034-7 (Code I).

The drives must be operated only in the assembly option specified on the rating plate. This ensures that the correct quantity of lubricant is provided

Identification marking:



Oil level



Housing ventilation



Oil drain plug



Oil dipstick

A,B Position of stub-shaft and / or solid shaft

V Gear units of size 38 are standard-fitted with a screw plug at point "V". Ventilation is not required.

* on opposite side

② two-stage gear unit

③ three-stage gear unit

④ Tandem gear unit

--- alternative

3.5.1 One-stage helical gear units



Note.
For key to diagram symbols, see section 3.5 "Mounting positions".




Figure 3.5.1-1: Mounting positions for E38 - E148




Figure 3.5.1-2: Mounting positions for E.38 - E.148

3.5.2 Two and three-stage helical gear units

i

Note.
For key to diagram symbols, see section 3.5 "Mounting positions".




Figure 3.5.2-1: Mounting positions for D/Z38 - D/Z88





Figure 3.5.2-2: Mounting positions for D/Z108 - D/Z168

37


i

Note.
For key to diagram symbols, see section 3.5 "Mounting positions".


D/Z B3 (IM B3)




D/Z B8 (IM B8)




D/Z B7 (IM B7)



D/Z B6 (IM B6)



D/Z V5 (IM V5)



D/Z V6 (IM V6)






Figure 3.5.2-3: Mounting positions for D/Z188

ZK, DF/ZF B5 (IM B5)
DZ/ZZ B14 (IM B14)



ZK, DF/ZF V1 (IM V1)
DZ/ZZ V18 (IM V18)



ZK, DF/ZF V3 (IM V3)
DZ/ZZ V19 (IM V19)






Figure 3.5.2-4: Mounting positions for D./Z.38 - D./Z.88

ZK, DF/ZF B5 (IM B5)
DZ/ZZ B14 (IM B14)



ZK, DF/ZF V1 (IM V1)
DZ/ZZ V18 (IM V18)



ZK, DF/ZF V3 (IM V3)
DZ/ZZ V19 (IM V19)





Figure 3.5.2-5: Mounting positions for D./Z.108 - D./Z.168


i

Note.
For key to diagram symbols, see section 3.5 "Mounting positions".

ZK, DF/ZF **B5 (IM B5)**
DZ/ZZ **B14 (IM B14)**



ZK, DF/ZF **V1 (IM V1)**
DZ/ZZ **V18 (IM V18)**



ZK, DF/ZF **V3 (IM V3)**
DZ/ZZ **V19 (IM V19)**






Figure 3.5.2-6: Mounting positions for D./Z.188

DR/ZR **B5 (IM B5)**



DR/ZR **V1 (IM V1)**



DR/ZR **V3 (IM V3)**






Figure 3.5.2-7: Mounting positions for DR/ZR68 - DR/ZR88

DR/ZR **B5 (IM B5)**



DR/ZR **V1 (IM V1)**



DR/ZR **V3 (IM V3)**




Figure 3.5.2-8: Mounting positions for DR/ZR108 - DR/ZR168

3.5.3 Bevel-helical gear units



Note.
 For key to diagram symbols, see section 3.5 "Mounting positions".

The assembly options shown apply also to the foot/flange-mounted housing, size 188.







Figure 3.5.3-1: Presentation - foot/flange housing K.188

K B3-00 (IM B3-00)
KA. H-01

K B8-00 (IM B8-00)
KA. H-02

K B7-00 (IM B7-00)
KA. H-03



K B6-00 (IM B6-00)
KA. H-04

K V5-00 (IM V5-00)
KA. H-05

K V6-00 (IM V6-00)
KA. H-06







Figure 3.5.3-2: Mounting positions for K, KA, KAS, KAT Size 38 - 188


i

Note.
 For key to diagram symbols, see section 3.5 "Mounting positions".


KZ, KF B5-01 (IM B5-01)
 KA. H-01




KZ, KF B5-03 (IM B5-03)
 KA. H-02




KZ, KF B5-02 (IM B5-02)
 KA. H-03



KZ, KF B5-00 (IM B5-00)
 KA. H-04



KZ, KF V1-00 (IM V1-00)
 KA. H-05



KZ, KF V3-00 (IM V3-00)
 KA. H-06





Figure 3.5.3-3: Mounting positions for KZ, KF, KAD, KAF, KAZ, KADS, KAFS, KAZS, KADT, KAFT, KAZT Size 38 - 188

3.5.4 Parallel shaft helical gear units




Note.
For key to diagram symbols, see section 3.5 "Mounting positions".


F.Z, F.F **B5-01 (IM B5-01)**
F.A. **H-01**




F.Z, F.F **B5-03 (IM B5-03)**
F.A. **H-02**




F.Z, F.F **B5-02 (IM B5-02)**
F.A. **H-03**



F.Z, F.F **B5-00 (IM B5-00)**
F.A. **H-04**



F.Z, F.F **V1-00 (IM V1-00)**
F.A. **H-05**



F.Z, F.F **V3-00 (IM V3-00)**
F.A. **H-06**





Figure 3.5.4: Mounting positions for F.38B - F.188B

3.5.5 Helical worm gear units




Note.
For key to diagram symbols, see section 3.5 "Mounting positions".


C B3-00 (IM B3-00)
CA. H-01




C B8-00 (IM B8-00)
CA. H-02




C B7-00 (IM B7-00)
CA. H-03



C B6-00 (IM B6-00)
CA. H-04



C V5-00 (IM V5-00)
CA. H-05



C V6-00 (IM V6-00)
CA. H-06






Figure 3.5-1: Mounting positions for C, CA, CAS, CAT Size 38 - 88


CZ, CF B5-01 (IM B5-01)
CA. H-01




CZ, CF B5-03 (IM B5-03)
CA. H-02




CZ, CF B5-02 (IM B5-02)
CA. H-03



CZ, CF B5-00 (IM B5-00)
CA. H-04



CZ, CF V1-00 (IM V1-00)
CA. H-05



CZ, CF V3-00 (IM V3-00)
CA. H-06




Figure 3.5.5-2: Mounting positions for CZ, CF, CAD, CAF, CAZ, CADS, CAFS, CAZS, CADT, CAFT, CAZT Size 38 - 88

3.5.6 Tandem gear unit - compound helical gear unit

i

Note.

In a horizontal operating position the bulging part of the housing of the 2nd gear unit generally faces downwards.

Types Z.28 are standard-fitted with three screw plugs.




Figure 3.5.6: Operating position for dual gear unit

a Main gear unit

3.6 Oil quantities



Caution.

Incorrect oil quantities cause damage to the drive.
The exact oil quantities are specified on the rating plates of the drives.
The oil quantities listed in the tables are approximate values. They serve for the storage and procurement of lubricant.

3.6.1 Helical gear units

| Type | Mounting position | | | | | | | | |
|-------|-------------------|-----------|------|------|------|-----------|-----------|------|------|
| | B3 | B5 B14 | B6 | B7 | B8 | V1 V18 | V3 V19 | V5 | V6 |
| E.38 | 0.2 | 0.2 | 0.3 | 0.3 | 0.4 | 0.5 | 0.6 | 0.5 | 0.6 |
| E.48 | 0.3 | 0.3 | 0.6 | 0.5 | 0.7 | 0.7 | 1.1 | 0.7 | 1.1 |
| E.68 | 0.5 | 0.5 | 1.0 | 1.1 | 1.5 | 1.7 | 1.9 | 1.8 | 1.9 |
| E.88 | 0.8 | 0.7 | 1.6 | 1.6 | 2.5 | 2.2 | 3.8 | 2.3 | 3.8 |
| E.108 | 1.3 | 1.0 | 2.7 | 2.8 | 4.6 | 3.7 | 6.6 | 3.8 | 6.6 |
| E.128 | 2.3 | 2.3 | 5.3 | 5.2 | 7.2 | 6.4 | 10.9 | 6.4 | 10.9 |
| E.148 | 4.0 | 2.8 | 7.0 | 7.0 | 10.3 | 9.3 | 14.5 | 9.5 | 14.8 |
| Z.38 | 0.5 | 0.5 | 0.6 | 0.6 | 0.6 | 0.8 | 1.2 | 0.7 | 1.1 |
| Z.48 | 1.1 | 1.0 | 1.6 | 1.3 | 1.5 | 1.8 | 2.4 | 1.9 | 2.4 |
| Z.68 | 1.8 | 1.7 | 2.7 | 2.3 | 2.5 | 3.0 | 4.1 | 3.2 | 4.1 |
| Z.88 | 4.1 | 3.7 | 6.1 | 5.3 | 5.7 | 6.8 | 8.3 | 7.5 | 8.8 |
| Z.108 | 7.3 | 6.0 | 10.5 | 9.3 | 8.6 | 13.8 | 14.0 | 13.2 | 13.6 |
| Z.128 | 9.5 | 7.0 | 16.0 | 14.1 | 13.2 | 18.5 | 20.7 | 19.9 | 20.9 |
| Z.148 | 13.0 | 9.9 | 20.8 | 18.3 | 26.9 | 23.9 | 27.7 | 25.7 | 27.4 |
| Z.168 | 21.0 | 15.3 | 34.8 | 30.1 | 32.1 | 48.0 | 31.1 | 48.0 | 41.7 |
| Z.188 | 18.5 | 18.5 | 50.0 | 46.0 | 75.0 | 72.0 | 70.0 | 72.0 | 70.0 |
| D.38 | 0.5 | 0.5 | 0.6 | 0.6 | 0.6 | 0.9 | 1.1 | 0.9 | 1.1 |
| D.48 | 1.1 | 1.0 | 1.5 | 1.4 | 1.5 | 2.3 | 2.4 | 2.4 | 2.4 |
| D.68 | 1.7 | 1.6 | 2.6 | 2.4 | 2.6 | 3.9 | 4.0 | 4.0 | 4.0 |
| D.88 | 4.0 | 3.6 | 5.9 | 5.4 | 5.9 | 8.7 | 8.9 | 9.3 | 8.9 |
| D.108 | 7.1 | 5.7 | 10.3 | 9.5 | 10.0 | 16.3 | 14.2 | 15.6 | 13.7 |
| D.128 | 9.4 | 6.8 | 15.8 | 14.8 | 14.1 | 24.6 | 21.8 | 24.4 | 21.5 |
| D.148 | 12.5 | 9.4 | 20.4 | 19.1 | 23.4 | 30.6 | 28.2 | 32.2 | 27.9 |
| D.168 | 19.0 | 16.0 | 34.1 | 31.2 | 33.8 | 53.0 | 43.7 | 54.4 | 42.2 |
| D.188 | 18.4 | 18.4 | 48.0 | 46.0 | 73.0 | 69.0 | 68.0 | 69.0 | 68.0 |

Table 3.6.1: Oil quantities for E.38 - E.148, D./Z.38 - D./Z.188

45

3.6.2 Bevel-helical gear units

| Type | Mounting position | | | | | |
|-------|-------------------|---------------|---------------|---------------|---------------|---------------|
| | B3-00 H-01 | B8-00 H-02 | B7-00 H-03 | B6-00 H-04 | V5-00 H-05 | V6-00 H-06 |
| K.38 | 0.5 | 1.1 | 1.4 | 0.8 | 1.0 | 0.9 |
| K.48 | 0.7 | 1.6 | 2.0 | 1.4 | 1.5 | 1.8 |
| K.68 | 1.6 | 3.2 | 3.9 | 2.7 | 3.0 | 3.0 |
| K.88 | 2.6 | 5.7 | 7.4 | 5.0 | 4.9 | 5.2 |
| K.108 | 5.5 | 9.5 | 12.6 | 8.8 | 8.7 | 8.3 |
| K.128 | 8.3 | 19.6 | 24.4 | 15.8 | 16.9 | 16.1 |
| K.148 | 14.8 | 30.2 | 37.0 | 22.0 | 25.8 | 27.0 |
| K.168 | 21.6 | 45.6 | 60.5 | 34.2 | 40.2 | 38.5 |
| K.188 | 33.8 | 82.5 | 104.2 | 63.4 | 70.7 | 69.4 |

Table 3.6.2-1: Oil quantities for K, KA, KAS, KAT Size 38 - 188

| Type | Mounting position | | | | | |
|-------|-------------------|---------------|---------------|---------------|---------------|---------------|
| | B5-01 H-01 | B5-03 H-02 | B5-02 H-03 | B5-00 H-04 | V1-00 H-05 | V3-00 H-06 |
| K.38 | 0.5 | 1.1 | 1.5 | 0.8 | 1.0 | 0.9 |
| K.48 | 0.7 | 1.7 | 2.0 | 1.4 | 1.6 | 1.8 |
| K.68 | 1.6 | 3.2 | 3.9 | 2.6 | 2.8 | 3.0 |
| K.88 | 2.6 | 5.8 | 7.7 | 5.0 | 5.1 | 5.0 |
| K.108 | 6.2 | 9.9 | 13.7 | 8.9 | 10.0 | 8.9 |
| K.128 | 8.7 | 19.6 | 25.0 | 14.8 | 17.5 | 16.6 |
| K.148 | 14.8 | 30.1 | 41.0 | 25.0 | 26.0 | 28.1 |
| K.168 | 21.7 | 46.3 | 62.6 | 34.8 | 41.1 | 39.4 |
| K.188 | 33.8 | 82.5 | 104.5 | 63.4 | 70.7 | 69.4 |

Table 3.6.2-2: Oil quantities for KZ, KF, KAD, KAF, KAZ, KADS, KAFS, KAZS, KADT, KAFT, KAZT Size 38 - 188

3.6.3 Parallel shaft helical gear units

| Type | Mounting position | | | | | |
|---------|-------------------|---------------|---------------|---------------|---------------|---------------|
| | B5-01 H-01 | B5-03 H-02 | B5-02 H-03 | B5-00 H-04 | V1-00 H-05 | V3-00 H-06 |
| FZ.38B | 0.7 | 0.6 | 0.7 | 0.7 | 1.0 | 1.1 |
| FZ.48B | 1.6 | 1.0 | 1.3 | 1.3 | 1.8 | 2.1 |
| FZ.68B | 2.5 | 2.3 | 2.4 | 2.3 | 3.3 | 3.8 |
| FZ.88B | 4.5 | 5.0 | 4.8 | 4.6 | 7.0 | 6.6 |
| FZ.108B | 7.4 | 9.2 | 8.4 | 8.1 | 11.1 | 13.1 |
| FZ.128B | 13.8 | 13.7 | 15.5 | 14.8 | 22.1 | 22.7 |
| FZ.148B | 19.5 | 20.8 | 22.7 | 22.3 | 34.5 | 33.5 |
| FZ.168B | 32.8 | 30.0 | 37.0 | 35.8 | 53.8 | 53.0 |
| FZ.188B | 41.4 | 40.7 | 44.2 | 46.5 | 68.0 | 66.4 |
| FD.38B | 0.9 | 0.6 | 0.7 | 0.7 | 0.9 | 1.1 |
| FD.48B | 2.0 | 0.9 | 1.3 | 1.3 | 1.8 | 2.0 |
| FD.68B | 3.3 | 2.3 | 2.4 | 2.3 | 3.2 | 3.8 |
| FD.88B | 6.3 | 5.0 | 4.7 | 4.7 | 6.8 | 6.7 |
| FD.108B | 10.6 | 9.1 | 8.2 | 8.2 | 11.1 | 13.0 |
| FD.128B | 16.8 | 13.5 | 15.2 | 14.8 | 21.6 | 22.5 |
| FD.148B | 24.7 | 20.3 | 21.8 | 22.3 | 33.6 | 32.6 |
| FD.168B | 44.0 | 28.8 | 36.0 | 35.8 | 52.4 | 51.9 |
| FD.188B | 52.0 | 38.4 | 44.5 | 45.1 | 66.0 | 65.2 |

Table 3.6.3: Oil quantities for F.38B - F.188B

3.6.4 Helical worm gear units

| Type | Mounting position | | | | | |
|------|-------------------|---------------|---------------|---------------|---------------|---------------|
| | B3-00 H-01 | B8-00 H-02 | B7-00 H-03 | B6-00 H-04 | V5-00 H-05 | V6-00 H-06 |
| C.38 | 0.5 | 1.2 | 1.3 | 1.2 | 1.2 | 1.2 |
| C.48 | 0.7 | 1.6 | 1.7 | 1.6 | 1.3 | 1.3 |
| C.68 | 1.5 | 3.3 | 4.1 | 3.3 | 2.8 | 2.9 |
| C.88 | 1.7 | 6.1 | 6.5 | 5.1 | 4.5 | 4.5 |

Table 3.6.4-1: Oil quantities for C, CA, CAS, CAT Size 38 - 88

| Type | Mounting position | | | | | |
|------|-------------------|---------------|---------------|---------------|---------------|---------------|
| | B5-01 H-01 | B5-03 H-02 | B5-02 H-03 | B5-00 H-04 | V1-00 H-05 | V3-00 H-06 |
| C.38 | 0.4 | 1.2 | 1.3 | 1.1 | 1.0 | 1.0 |
| C.48 | 0.5 | 1.7 | 1.8 | 1.6 | 1.3 | 1.3 |
| C.68 | 1.5 | 3.6 | 4.2 | 3.3 | 3.1 | 3.2 |
| C.88 | 1.7 | 6.6 | 7.3 | 5.2 | 4.8 | 4.8 |

Table 3.6.4-2: Oil quantities for CZ, CF, CAD, CAF, CAZ, CADS, CAFS, CAZS, CADT, CAFT, CAZT Size 38 - 88

3.6.5 Tandem gear unit - compound helical gear unit

3.6.5.1 Two and three-stage helical gear units

| Type | Mounting position | | | | | | | | |
|-------------|-------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|
| | B3 | B5 B14 | B6 | B7 | B8 | V1 V18 | V3 V19 | V5 | V6 |
| Z.38 - Z28 | 0.5+0.3 0.8 | 0.5+0.3 0.8 | 0.6+0.3 0.9 | 0.6+0.3 0.9 | 0.6+0.3 0.9 | 0.7+0.8 1.5 | 1.2+0.8 2.0 | 0.7+0.8 1.5 | 1.1+0.8 1.9 |
| Z.48 - Z28 | 1.1+0.3 1.4 | 1.0+0.3 1.3 | 1.6+0.3 1.9 | 1.3+0.3 1.6 | 1.5+0.3 1.8 | 1.8+0.8 2.6 | 2.4+0.8 3.2 | 1.9+0.8 2.7 | 2.4+0.8 3.2 |
| Z.68 - Z28 | 1.8+0.3 2.1 | 1.8+0.3 2.1 | 2.7+0.3 3.0 | 2.3+0.3 2.6 | 2.5+0.3 2.8 | 3.0+0.8 3.8 | 4.1+0.8 4.9 | 3.2+0.8 4.0 | 4.1+0.8 4.9 |
| Z.68 - Z38 | 1.8+0.5 2.3 | 1.8+0.5 2.3 | 2.7+0.5 3.2 | 2.3+0.5 2.8 | 2.5+0.5 3.0 | 3.0+0.8 3.8 | 4.1+1.2 5.3 | 3.2+0.7 3.9 | 4.1+1.2 5.3 |
| D.38 - Z28 | 0.5+0.3 0.8 | 0.5+0.3 0.8 | 0.6+0.3 0.9 | 0.6+0.3 0.9 | 0.6+0.3 0.9 | 0.9+0.8 1.7 | 1.1+0.8 1.9 | 0.9+0.8 1.7 | 1.1+0.8 1.9 |
| D.48 - Z28 | 1.1+0.3 1.4 | 1.0+0.3 1.3 | 1.5+0.3 1.8 | 1.4+0.3 1.7 | 1.5+0.3 1.8 | 2.3+0.8 3.1 | 2.4+0.8 3.2 | 2.4+0.8 3.2 | 2.4+0.8 3.2 |
| D.68 - Z28 | 1.7+0.3 2.0 | 1.6+0.3 1.9 | 2.6+0.3 2.9 | 2.4+0.3 2.7 | 2.6+0.3 2.9 | 3.9+0.8 4.7 | 4.0+0.8 4.8 | 4.0+0.8 4.8 | 4.0+0.8 4.8 |
| D.68 - Z38 | 1.7+0.5 2.2 | 1.6+0.5 2.1 | 2.6+0.5 3.1 | 2.4+0.5 2.9 | 2.6+0.5 3.1 | 3.9+0.8 4.7 | 4.0+1.2 5.2 | 4.0+0.7 4.7 | 4.0+1.2 5.2 |
| D.68 - D38 | 1.7+0.5 2.2 | 1.6+0.5 2.1 | 2.6+0.5 3.1 | 2.4+0.5 2.9 | 2.6+0.5 3.1 | 3.9+0.9 4.8 | 4.0+1.1 5.1 | 4.0+0.9 4.9 | 4.0+1.1 5.1 |
| D.88 - Z28 | 4.0+0.3 4.3 | 3.6+0.3 3.9 | 5.9+0.3 6.2 | 5.4+0.3 5.7 | 5.9+0.3 6.2 | 8.7+0.8 9.5 | 8.9+0.8 9.7 | 9.3+0.8 10.1 | 8.9+0.8 9.7 |
| D.88 - Z38 | 4.0+0.5 4.5 | 3.6+0.5 4.1 | 5.9+0.5 6.4 | 5.4+0.5 5.9 | 5.9+0.5 6.4 | 8.7+0.8 9.5 | 8.9+1.2 10.1 | 9.3+0.7 10.0 | 8.9+1.2 10.1 |
| D.88 - D38 | 4.0+0.5 4.5 | 3.6+0.5 4.1 | 5.9+0.5 6.4 | 5.4+0.5 5.9 | 5.9+0.5 6.4 | 8.7+0.9 9.6 | 8.9+1.1 10.0 | 9.3+0.9 10.2 | 8.9+1.1 10.0 |
| D.108 - Z28 | 7.1+0.3 7.4 | 5.7+0.3 6.0 | 10.3+0.3 10.6 | 9.5+0.3 9.8 | 10.0+0.3 10.3 | 16.3+0.8 17.1 | 14.2+0.8 15.0 | 15.6+0.8 16.4 | 13.7+0.8 14.5 |
| D.108 - Z38 | 7.1+0.5 7.6 | 5.7+0.5 6.2 | 10.3+0.5 10.8 | 9.5+0.5 10.0 | 10.0+0.5 10.5 | 16.3+0.8 17.1 | 14.2+1.2 15.4 | 15.6+0.7 16.3 | 13.7+1.2 14.9 |
| D.108 - D38 | 7.1+0.5 7.6 | 5.7+0.5 6.2 | 10.3+0.5 10.8 | 9.5+0.5 10.0 | 10.0+0.5 10.5 | 16.3+0.9 17.2 | 14.2+1.1 15.2 | 15.6+0.9 16.5 | 13.7+1.1 14.8 |
| D.128 - Z28 | 9.4+0.3 9.7 | 6.8+0.3 7.1 | 15.8+0.3 16.1 | 14.8+0.3 15.1 | 14.1+0.3 14.4 | 24.6+0.8 25.4 | 21.8+0.8 22.6 | 24.4+0.8 25.2 | 21.5+0.8 22.3 |
| D.128 - Z38 | 9.4+0.5 9.9 | 6.8+0.5 7.3 | 15.8+0.5 16.3 | 14.8+0.5 15.3 | 14.1+0.5 14.6 | 24.6+0.8 25.4 | 21.8+1.2 23.0 | 24.4+0.7 25.1 | 21.5+1.2 22.7 |
| D.128 - Z48 | 9.4+1.0 10.4 | 6.8+1.0 7.8 | 15.8+1.0 16.8 | 14.8+1.0 15.8 | 14.1+1.0 15.1 | 24.6+1.8 26.4 | 21.8+2.4 24.2 | 24.4+1.8 26.2 | 21.5+2.4 23.9 |
| D.128 - D38 | 9.4+0.5 9.9 | 6.8+0.5 7.3 | 15.8+0.5 16.3 | 14.8+0.5 15.3 | 14.1+0.5 14.6 | 24.6+0.9 25.5 | 21.8+1.1 22.9 | 24.4+0.9 25.3 | 21.5+1.1 22.6 |
| D.148 - Z38 | 12.5+0.5 13.0 | 9.4+0.5 9.9 | 20.4+0.5 20.9 | 19.1+0.5 19.6 | 23.4+0.5 23.9 | 30.6+0.8 31.4 | 28.2+1.2 29.4 | 32.2+0.7 32.9 | 27.9+1.2 29.1 |
| D.148 - Z48 | 12.5+1.0 13.5 | 9.4+1.0 10.4 | 20.4+1.0 21.4 | 19.1+1.0 20.1 | 23.4+1.0 24.4 | 30.6+1.8 32.4 | 28.2+2.4 30.6 | 32.2+1.8 34.0 | 27.9+2.4 30.3 |
| D.148 - D38 | 12.5+0.5 13.0 | 9.4+0.5 9.9 | 20.4+0.5 20.9 | 19.1+0.5 19.6 | 23.4+0.5 23.9 | 30.6+0.9 31.5 | 28.2+1.1 29.3 | 32.2+0.9 33.1 | 27.9+1.1 29.0 |
| D.168 - Z48 | 19.0+1.0 20.0 | 16.0+1.0 17.0 | 34.1+1.0 35.1 | 31.2+1.0 32.2 | 33.8+1.0 34.8 | 53.0+1.8 54.8 | 43.7+2.4 46.1 | 54.4+1.8 56.2 | 42.2+2.4 44.6 |
| D.168 - Z68 | 19.0+1.7 20.7 | 16.0+1.7 17.7 | 34.1+1.7 35.8 | 31.2+1.7 32.9 | 33.8+1.7 35.5 | 53.0+3.0 56.0 | 43.7+4.1 47.8 | 54.4+3.0 57.4 | 42.2+4.1 46.3 |
| D.168 - D48 | 19.0+1.0 20.0 | 16.0+1.0 17.0 | 34.1+1.0 35.1 | 31.2+1.0 32.2 | 33.8+1.0 34.8 | 53.0+2.3 55.3 | 43.7+2.4 46.1 | 54.4+2.3 56.7 | 42.2+2.4 44.6 |
| D.188 - Z48 | 18.4+1.0 19.4 | 18.4+1.0 19.4 | 48.0+1.0 49.0 | 46.0+1.0 47.0 | 73.0+1.0 74.0 | 83.0+1.8 84.8 | 68.0+2.4 70.4 | 83.0+1.8 84.8 | 68.0+2.4 70.4 |
| D.188 - Z68 | 18.4+1.7 20.1 | 18.4+1.7 20.1 | 48.0+1.7 49.7 | 46.0+1.7 47.7 | 73.0+1.7 74.7 | 83.0+3.0 86.0 | 68.0+4.1 72.1 | 83.0+3.0 86.0 | 68.0+4.1 72.1 |
| D.188 - D48 | 18.4+1.0 19.4 | 18.4+1.0 19.4 | 48.0+1.0 49.0 | 46.0+1.0 47.0 | 73.0+1.0 74.0 | 83.0+2.3 85.3 | 68.0+2.4 70.4 | 83.0+2.3 85.3 | 68.0+2.4 70.4 |

Table 3.6.5.1: Oil quantities for Z.38 - Z.68, D.38 - D.188

3.6.5.2 Bevel-helical gear units

| Type | Mounting position | | | | | |
|-------------|-------------------|------------------|--------------------|------------------|------------------|------------------|
| | B3-00 H-01 | B8-00 H-02 | B7-00 H-03 | B6-00 H-04 | V5-00 H-05 | V6-00 H-06 |
| K.38 - Z28 | 0.5+0.3 0.8 | 1.1+0.3 1.4 | 1.4+0.8 2.2 | 0.8+0.8 1.6 | 1.0+0.3 1.3 | 0.9+0.3 1.2 |
| K.48 - Z28 | 0.7+0.3 1.0 | 1.6+0.3 1.9 | 2.0+0.8 2.8 | 1.2+0.8 2.0 | 1.5+0.3 1.8 | 1.8+0.3 2.1 |
| K.68 - Z28 | 1.6+0.3 1.9 | 3.2+0.3 3.5 | 3.9+0.8 4.7 | 2.7+0.8 3.5 | 3.0+0.3 3.3 | 3.0+0.3 3.3 |
| K.68 - Z38 | 1.6+0.5 2.1 | 3.2+0.5 3.7 | 3.9+0.8 4.7 | 2.7+1.2 3.9 | 3.0+0.5 3.5 | 3.0+0.5 3.5 |
| K.68 - D38 | 1.6+0.5 2.1 | 3.2+0.5 3.7 | 3.9+0.9 4.8 | 2.7+1.1 3.8 | 3.0+0.5 3.5 | 3.0+0.5 3.5 |
| K.88 - Z28 | 2.6+0.3 2.9 | 5.7+0.3 6.0 | 7.4+0.8 8.2 | 5.0+0.8 5.8 | 4.9+0.3 5.2 | 5.2+0.3 5.5 |
| K.88 - Z38 | 2.6+0.5 3.1 | 5.7+0.5 6.2 | 7.4+0.8 8.2 | 5.0+1.2 6.2 | 4.9+0.5 5.4 | 5.2+0.5 5.7 |
| K.88 - D38 | 2.6+0.5 3.1 | 5.7+0.5 6.2 | 7.4+0.9 8.3 | 5.0+1.1 6.1 | 4.9+0.5 5.4 | 5.2+0.5 5.7 |
| K.108 - Z38 | 5.5+0.5 6.0 | 9.5+0.5 10.0 | 12.6+0.8 13.4 | 8.8+1.2 10.0 | 8.7+0.5 9.2 | 8.3+0.5 8.8 |
| K.108 - Z48 | 5.5+1.0 6.5 | 9.5+1.0 10.5 | 12.6+1.8 14.4 | 8.8+2.4 11.2 | 8.7+1.0 9.7 | 8.3+1.0 9.3 |
| K.108 - D38 | 5.5+0.5 6.0 | 9.5+0.5 10.0 | 12.6+0.9 13.5 | 8.8+1.1 9.9 | 8.7+0.5 9.2 | 8.3+0.5 8.8 |
| K.128 - Z38 | 8.3+0.5 8.8 | 19.6+0.5 20.1 | 24.4+0.8 25.2 | 15.8+1.2 17.0 | 16.9+0.5 17.4 | 16.1+0.5 16.6 |
| K.128 - Z48 | 8.3+1.0 9.3 | 19.6+1.0 20.6 | 24.4+1.8 26.2 | 15.8+2.4 18.2 | 16.9+1.0 17.9 | 16.1+1.0 17.1 |
| K.128 - D38 | 8.3+0.5 8.8 | 19.6+0.5 20.1 | 24.4+0.9 25.3 | 15.8+1.1 16.9 | 16.9+0.5 17.4 | 16.1+0.5 16.6 |
| K.148 - Z38 | 14.8+0.5 15.3 | 30.2+0.5 30.7 | 37.0+0.8 37.8 | 22.0+1.2 23.2 | 25.8+0.5 26.3 | 27.0+0.5 27.5 |
| K.148 - Z68 | 14.8+1.7 16.5 | 30.2+1.7 31.9 | 37.0+3.0 40.0 | 22.0+4.1 26.1 | 25.8+1.7 27.5 | 27.0+1.7 28.7 |
| K.148 - D38 | 14.8+0.5 15.3 | 30.2+0.5 30.7 | 37.0+0.9 37.9 | 22.0+1.1 23.1 | 25.8+0.5 26.3 | 27.0+0.5 27.5 |
| K.168 - Z48 | 21.6+1.0 22.6 | 45.6+1.0 46.6 | 60.5+1.8 62.3 | 34.2+2.4 36.6 | 40.2+1.0 41.2 | 38.5+1.0 39.5 |
| K.168 - Z68 | 21.6+1.7 23.3 | 45.6+1.7 47.3 | 60.5+3.0 63.5 | 34.2+4.1 38.3 | 40.2+1.7 41.9 | 38.5+1.7 40.2 |
| K.168 - D48 | 21.6+1.1 22.7 | 45.6+1.1 46.7 | 60.5+2.3 62.8 | 34.2+2.4 36.6 | 40.2+1.1 41.3 | 38.5+1.1 39.6 |
| K.188 - Z68 | 33.8+1.7 35.5 | 82.5+1.7 84.2 | 104.2+3 107.2 | 63.4+4.1 67.5 | 70.7+1.7 72.4 | 69.4+1.7 71.1 |
| K.188 - Z88 | 33.8+3.7 37.5 | 82.5+3.7 86.2 | 104.2+6.8 111 | 63.4+8.8 72.2 | 70.7+3.7 74.4 | 69.4+3.7 73.1 |
| K.188 - D68 | 33.8+1.6 35.4 | 82.5+1.6 84.1 | 104.2+3.9 108.1 | 63.4+4 67.4 | 70.7+1.6 72.3 | 69.4+1.6 71.0 |

Table 3.6.5.2-1: Oil quantities for K, KA, KAS, KAT Size 38 - 188

| Type | Mounting position | | | | | |
|--------------------|-------------------|------------------|--------------------|------------------|------------------|------------------|
| | B5-01 H-01 | B5-03 H-02 | B5-02 H-03 | B5-00 H-04 | V1-00 H-05 | V3-00 H-06 |
| K.38 - Z28 | 0.5+0.3 0.8 | 1.1+0.3 1.4 | 1.5+0.8 2.3 | 0.8+0.8 1.6 | 1.0+0.3 1.3 | 0.9+0.3 1.2 |
| K.48 - Z28 | 0.7+0.3 1.0 | 1.7+0.3 2.0 | 2.3+0.8 3.1 | 1.2+0.8 2.0 | 1.6+0.3 1.9 | 1.8+0.3 2.1 |
| K.68 - Z28 | 1.6+0.3 1.9 | 3.2+0.3 3.5 | 3.9+0.8 4.7 | 2.6+0.8 3.4 | 2.8+0.3 3.1 | 3.0+0.3 3.3 |
| K.68 - Z38 | 1.6+0.5 2.1 | 3.2+0.5 3.7 | 3.9+0.7 4.6 | 2.6+1.2 3.8 | 2.8+0.5 3.3 | 3.0+0.5 3.5 |
| K.68 - D38 | 1.6+0.5 2.1 | 3.2+0.5 3.7 | 3.9+0.9 4.8 | 2.6+1.1 3.7 | 2.8+0.5 3.3 | 3.0+0.5 3.5 |
| K.88 - Z28 | 2.6+0.3 2.9 | 5.8+0.3 6.1 | 7.7+0.8 8.5 | 5.0+0.8 5.8 | 5.1+0.3 5.4 | 5.0+0.3 5.3 |
| K.88 - Z38 | 2.6+0.5 3.1 | 5.8+0.5 6.3 | 7.7+0.7 8.4 | 5.0+1.2 6.2 | 5.1+0.5 5.6 | 5.0+0.5 5.5 |
| K.88 - D38 | 2.6+0.5 3.1 | 5.8+0.5 6.3 | 7.7+0.9 8.6 | 5.0+1.1 6.1 | 5.1+0.5 5.6 | 5.0+0.5 5.5 |
| K.108 - Z38 | 6.2+0.5 6.7 | 9.9+0.5 10.4 | 13.7+0.7 14.4 | 8.9+1.2 10.1 | 10.0+0.5 10.5 | 8.9+0.5 9.4 |
| K.108 - Z48 | 6.2+1.0 7.2 | 9.9+1.0 10.9 | 13.7+1.8 15.5 | 8.9+2.4 11.3 | 10.0+1.0 11.0 | 8.9+1.0 9.9 |
| K.108 - D38 | 6.2+0.5 6.7 | 9.9+0.5 10.4 | 13.7+0.9 14.6 | 8.9+1.1 10.0 | 10.0+0.5 10.5 | 8.9+0.5 9.4 |
| K.128 - Z38 | 8.7+0.5 9.2 | 19.6+0.5 20.1 | 25.0+0.7 25.7 | 14.8+1.2 16.0 | 17.5+0.5 18.0 | 16.6+0.5 17.1 |
| K.128 - Z48 | 8.7+1.0 9.7 | 19.6+1.0 20.6 | 25.0+1.8 26.8 | 14.8+2.4 17.2 | 17.5+1.0 18.5 | 16.6+1.0 17.6 |
| K.128 - D38 | 8.7+0.5 9.2 | 19.6+0.5 20.1 | 25.0+0.9 25.9 | 14.8+1.1 15.9 | 17.5+0.5 18.0 | 16.6+0.5 17.1 |
| K.148 - Z38 | 14.8+0.5 15.3 | 30.1+0.5 30.6 | 41.0+0.7 41.7 | 25.0+1.2 26.2 | 26.0+0.5 26.5 | 28.1+0.5 28.6 |
| K.148 - Z68 | 14.8+1.7 16.5 | 30.1+1.7 31.8 | 41.0+3.0 44.0 | 25.0+4.1 29.1 | 26.0+1.7 27.7 | 28.1+1.7 29.8 |
| K.148 - D38 | 14.8+0.5 15.3 | 30.1+0.5 30.6 | 41.0+0.9 41.9 | 25.0+1.1 26.1 | 26.0+0.5 26.5 | 28.1+0.5 28.6 |
| K.168 - Z48 | 21.7+1.0 22.7 | 46.3+1.0 47.3 | 62.6+1.8 64.4 | 34.8+2.4 37.2 | 41.1+1.0 42.1 | 39.4+1.0 40.4 |
| K.168 - Z68 | 21.7+1.7 23.4 | 46.3+1.7 48.0 | 62.6+3.0 65.6 | 34.8+4.1 38.9 | 41.1+1.7 42.8 | 39.4+1.7 41.1 |
| K.168 - D48 | 21.7+1.1 22.8 | 46.3+1.1 47.4 | 62.6+2.3 64.9 | 34.8+2.4 37.2 | 41.1+1.1 42.2 | 39.4+1.1 40.5 |
| K.188 - Z68 | 33.8+1.7 35.5 | 82.5+1.7 84.2 | 104.2+3 107.2 | 63.4+4.1 67.5 | 70.7+1.7 72.4 | 69.4+1.7 71.1 |
| K.188 - Z88 | 33.8+3.7 37.5 | 82.5+3.7 86.2 | 104.2+6.8 111 | 63.4+8.8 72.2 | 70.7+3.7 74.4 | 69.4+3.7 73.1 |
| K.188 - D68 | 33.8+1.6 35.4 | 82.5+1.6 84.1 | 104.2+3.9 108.1 | 63.4+4 67.4 | 70.7+1.6 72.3 | 69.4+1.6 71.0 |

Table 3.6.5.2-2: Oil quantities for KZ, KF, KAD, KAF, KAZ, KADS, KAFS, KAZS, KADT, KAFT, KAZT
Size 38 - 188

3.6.5.3 Parallel shaft helical gear units

| Type | Mounting position | | | | | |
|---------------|-------------------|------------------|------------------|------------------|------------------|------------------|
| | B5-01 H-01 | B5-03 H-02 | B5-02 H-03 | B5-00 H-04 | V1-00 H-05 | V3-00 H-06 |
| FD.38B - Z28 | 0.9+0.3 1.2 | 0.6+0.3 0.9 | 0.7+0.3 1.0 | 0.7+0.3 1.0 | 0.9+0.9 1.8 | 1.1+1.0 2.1 |
| FD.48B - Z28 | 2.0+0.3 2.3 | 0.9+0.3 1.2 | 1.3+0.3 1.6 | 1.3+0.3 1.6 | 1.8+0.9 2.7 | 2.0+1.0 3.0 |
| FD.48B - Z38 | 2.0+0.5 2.5 | 0.9+0.5 1.4 | 1.3+0.5 1.8 | 1.3+0.5 1.8 | 1.8+0.8 2.6 | 2.0+1.2 3.2 |
| FD.48B - D38 | 2.0+0.5 2.5 | 0.9+0.5 1.4 | 1.3+0.5 1.8 | 1.3+0.5 1.8 | 1.8+0.9 2.7 | 2.0+1.1 3.1 |
| FD.68B - Z28 | 3.3+0.3 3.6 | 2.3+0.3 2.6 | 2.4+0.3 2.7 | 2.3+0.3 2.6 | 3.2+0.9 4.1 | 3.8+1.0 4.8 |
| FD.68B - Z38 | 3.3+0.5 3.8 | 2.3+0.5 2.8 | 2.4+0.5 2.9 | 2.3+0.5 2.8 | 3.2+0.8 4.0 | 3.8+1.2 5.0 |
| FD.68B - D38 | 3.3+0.5 3.8 | 2.3+0.5 2.8 | 2.4+0.5 2.9 | 2.3+0.5 2.8 | 3.2+0.9 4.1 | 3.8+1.1 4.9 |
| FD.88B - Z28 | 6.3+0.3 6.6 | 5.0+0.3 5.3 | 4.7+0.3 5.0 | 4.7+0.3 5.0 | 6.8+0.9 7.7 | 6.7+1.0 7.7 |
| FD.88B - Z38 | 6.3+0.5 6.8 | 5.0+0.5 5.5 | 4.7+0.5 5.2 | 4.7+0.5 5.2 | 6.8+0.8 7.6 | 6.7+1.2 7.9 |
| FD.88B - D38 | 6.3+0.5 6.8 | 5.0+0.5 5.5 | 4.7+0.5 5.2 | 4.7+0.5 5.2 | 6.8+0.9 7.7 | 6.7+1.1 7.8 |
| FD.108B - Z38 | 10.6+0.5 11.1 | 9.1+0.5 9.6 | 8.2+0.5 8.7 | 8.2+0.5 8.7 | 11.1+0.8 11.9 | 13.0+1.2 14.2 |
| FD.108B - D38 | 10.6+0.5 11.1 | 9.1+0.5 9.6 | 8.2+0.5 8.7 | 8.2+0.5 8.7 | 11.1+0.9 12.0 | 13.0+1.1 14.1 |
| FD.128B - Z38 | 16.8+0.5 17.3 | 13.5+0.5 14.0 | 15.2+0.5 15.7 | 14.8+0.5 15.3 | 21.6+0.8 22.4 | 22.5+1.2 23.7 |
| FD.128B - Z48 | 16.8+1.0 17.8 | 13.5+1.0 14.5 | 15.2+1.0 16.2 | 14.8+1.0 15.8 | 21.6+1.8 23.4 | 22.5+2.4 24.9 |
| FD.128B - D38 | 16.8+0.5 17.3 | 13.5+0.5 14.0 | 15.2+0.5 15.7 | 14.8+0.5 15.3 | 21.6+0.9 22.5 | 22.5+1.1 23.6 |
| FD.148B - Z38 | 24.7+0.5 25.2 | 20.3+0.5 20.8 | 21.8+0.5 22.3 | 22.3+0.5 22.8 | 33.6+0.8 34.4 | 32.6+1.2 33.8 |
| FD.148B - Z48 | 24.7+1.0 25.7 | 20.3+1.0 21.3 | 21.8+1.0 22.8 | 22.3+1.0 23.3 | 33.6+1.8 35.4 | 32.6+2.4 35.0 |
| FD.148B - D38 | 24.7+0.5 25.2 | 20.3+0.5 20.8 | 21.8+0.5 22.3 | 22.3+0.5 22.8 | 33.6+0.9 34.5 | 32.6+1.1 33.7 |
| FD.168B - Z48 | 44.0+1.0 45.0 | 28.8+1.0 29.8 | 36.0+1.0 37.0 | 35.8+1.0 36.8 | 52.4+1.8 54.2 | 51.9+2.4 54.3 |
| FD.168B - Z68 | 44.0+1.7 45.7 | 28.8+1.7 30.5 | 36.0+1.7 37.7 | 35.8+1.7 37.5 | 52.4+3.0 55.4 | 51.9+4.1 56.0 |
| FD.168B - D48 | 44.0+1.0 45.0 | 28.8+1.0 29.8 | 36.0+1.0 37.0 | 35.8+1.0 36.8 | 52.4+2.3 54.7 | 51.9+2.4 54.3 |
| FD.188B - Z48 | 52.0+1.0 53.0 | 38.4+1.0 39.4 | 44.5+1.0 45.5 | 45.1+1.0 46.1 | 66.0+1.8 67.8 | 65.2+2.4 67.6 |
| FD.188B - Z68 | 52.0+1.7 53.7 | 38.4+1.7 40.1 | 44.5+1.7 46.2 | 45.1+1.7 46.8 | 66.0+3.0 69.0 | 65.2+4.1 69.3 |
| FD.188B - D48 | 52.0+1.0 53.0 | 38.4+1.0 39.4 | 44.5+1.0 45.5 | 45.1+1.0 46.1 | 66.0+2.3 68.3 | 65.2+2.4 67.6 |

Table 3.6.5.3: Oil quantities for F.38B - F.188B

51

3.6.5.4 Helical worm gear units

| Type | Mounting position | | | | | |
|-------------------|-------------------|----------------|----------------|----------------|----------------|----------------|
| | B3-00 H-01 | B8-00 H-02 | B7-00 H-03 | B6-00 H-04 | V5-00 H-05 | V6-00 H-06 |
| C.38 - Z28 | 0.5+0.3 0.8 | 1.2+0.3 1.5 | 1.3+0.8 2.1 | 1.2+0.8 2.0 | 1.2+0.3 1.5 | 1.2+0.3 1.5 |
| C.48 - Z28 | 0.7+0.3 1.0 | 1.6+0.3 1.9 | 1.7+0.8 2.5 | 1.6+0.8 2.4 | 1.3+0.3 1.6 | 1.3+0.3 1.6 |
| C.68 - Z28 | 1.5+0.3 1.8 | 3.3+0.3 3.6 | 4.1+0.8 4.9 | 3.3+0.8 4.1 | 2.8+0.3 3.1 | 2.9+0.3 3.2 |
| C.68 - Z38 | 1.5+0.5 2.0 | 3.3+0.5 3.8 | 4.1+0.8 4.9 | 3.3+1.2 4.5 | 2.8+0.5 3.3 | 2.9+0.5 3.4 |
| C.68 - D38 | 1.5+0.5 2.0 | 3.3+0.5 3.8 | 4.1+0.9 5.0 | 3.3+1.1 4.4 | 2.8+0.5 3.3 | 2.9+0.5 3.4 |
| C.88 - Z28 | 1.7+0.3 2.0 | 6.1+0.3 6.4 | 6.5+0.8 7.3 | 5.1+0.8 5.9 | 4.5+0.3 4.8 | 4.5+0.3 4.8 |
| C.88 - Z38 | 1.7+0.5 2.2 | 6.1+0.5 6.6 | 6.5+0.8 7.3 | 5.1+1.2 6.3 | 4.5+0.5 5.0 | 4.5+0.5 5.0 |
| C.88 - D38 | 1.7+0.5 2.2 | 6.1+0.5 6.6 | 6.5+0.9 7.4 | 5.1+1.1 6.2 | 4.5+0.5 5.0 | 4.5+0.5 5.0 |

Table 3.6.5.4-1: Oil quantities for C, CA, CAS, CAT Size 38 - 88

| Type | Mounting position | | | | | |
|-------------------|-------------------|----------------|----------------|----------------|----------------|----------------|
| | B5-01 H-01 | B5-03 H-02 | B5-02 H-03 | B5-00 H-04 | V1-00 H-05 | V3-00 H-06 |
| C.38 - Z28 | 0.4+0.3 0.7 | 1.2+0.3 1.5 | 1.3+0.8 2.1 | 1.1+0.8 1.9 | 1.0+0.3 1.3 | 1.0+0.3 1.3 |
| C.48 - Z28 | 0.5+0.3 0.8 | 1.7+0.3 2.0 | 1.8+0.8 2.6 | 1.6+0.8 2.4 | 1.3+0.3 1.6 | 1.3+0.3 1.6 |
| C.68 - Z28 | 1.5+0.3 1.8 | 3.6+0.3 3.9 | 4.2+0.8 5.0 | 3.3+0.8 4.1 | 3.1+0.3 3.4 | 3.2+0.3 3.5 |
| C.68 - Z38 | 1.5+0.5 2.0 | 3.6+0.5 4.1 | 4.2+0.8 5.0 | 3.3+1.2 4.5 | 3.1+0.5 3.6 | 3.2+0.5 3.7 |
| C.68 - D38 | 1.5+0.5 2.0 | 3.6+0.5 4.1 | 4.2+0.9 5.1 | 3.3+1.1 4.4 | 3.1+0.5 3.6 | 3.2+0.5 3.7 |
| C.88 - Z28 | 1.7+0.3 2.0 | 6.6+0.3 6.9 | 7.3+0.8 8.1 | 5.2+0.8 6.0 | 4.8+0.3 5.1 | 4.8+0.3 5.1 |
| C.88 - Z38 | 1.7+0.5 2.2 | 6.6+0.5 7.1 | 7.3+0.8 8.1 | 5.2+1.2 6.4 | 4.8+0.5 5.3 | 4.8+0.5 5.3 |
| C.88 - D38 | 1.7+0.5 2.2 | 6.6+0.5 7.1 | 7.3+0.9 8.2 | 5.2+1.1 6.3 | 4.8+0.5 5.3 | 4.8+0.5 5.3 |

Table 3.6.5.4-2: Oil quantities for CZ, CF, CAD, CAF, CAZ, CADS, CAFS, CAZS, CADT, CAFT, CAZT Size 38 - 88

52

4. Technical description

4.1 General description

The gear units are supplied with one, two or three transmission stages. The gear units are suitable for the different mounting positions, taking into consideration the oil level.

4.2 Housing

The gear unit housings of grey cast iron are designed for continuous operation.

4.3 Toothed components

The toothed components of the gear unit are hardened. In the case of helical-gear units the worm is hardened and ground and the gear manufactured from bronze.

4.4 Lubrication

The toothed components are adequately supplied with lubricant by dip lubrication.

4.5 Shaft bearing

All shafts are mounted in rolling bearings. The rolling bearings are lubricated by dip lubrication or oil spray lubrication. Bearings that are not supplied with lubricant are closed and grease-lubricated.

4.6 Shaft seals

Radial shaft sealing rings at the shaft outlets prevent lubricant from escaping from the housing and dirt from entering. Where (by contractual agreement) housings are subjected to high temperatures, shaft sealing rings of temperature-resistant material are used.

4.7 Cooling



Caution.
Dirt deposits impair cooling.

The gear units normally require no additional cooling. The generously dimensioned housing surface is sufficient for conducting away dissipated heat where there is free convection. If the difference between the temperature of the housing and the ambient temperature (max. +40 °C) exceeds 70 K, please contact the **FLENDER TÜBINGEN GMBH** customer service.

4.8 Couplings

As a rule, flexible couplings are provided for the input and output drive sides of the gear unit.

If rigid couplings or other input or output elements which generate additional radial and / or axial forces (e.g. gear wheels, belt pulleys) are to be used, this must be agreed by contract.



Caution.
Couplings with peripheral velocities on the outer diameter of up to 30 m/s must be statically balanced. Couplings with peripheral velocities over 30 m/s must be dynamically balanced.

The special operating instructions should be observed for operation of the couplings.

4.9 Backstop

For certain requirements, the gear units can be fitted with a mechanical backstop. It can be fitted either in the coupling housing or in the bevel-helical gear unit. It permits only the correct direction of rotation during the operation of the unit. This is marked by a corresponding direction arrow.



Caution.

Damage or destruction of the backstop through wrong direction of rotation.
Do not run motor against the backstop.
Observe information on the gear unit.

The backstop is fitted with centrifugally operated sprags. When the gear unit is running in the specified direction, the inner ring and the cage with the sprags also rotate while the outer ring remains stationary.

Where the backstop is used in the coupling housing, lifting of the sprags is ensured at speeds above 1 000 rpm. The backstop is wear-free.



Caution.

In the case of applications at speeds under 1 000 rpm or frequent starting and stopping operations (≥ 20 starts / stops an hour) the service life is limited.
Ensure that the backstop is replaced in good time.

If used in the bevel-helical gear unit, the backstop operates below the lift-off speed of the sprags in the oil. The oil must be changed at the same intervals as those of the gear unit.

4.10 Rating plates

The rating plates of the gear units or gear motors are normally of coated aluminium foil. They are covered with a special masking film which guarantees permanent resistance to UV radiation and media of all kinds (oils, greases, salt water, cleaning agents, etc.).

The adhesives and materials are selected to ensure extremely firm adhesion and permanent high legibility, even at the limits of the range of operating temperatures ($-40\text{ °C} \dots +155\text{ °C}$).

The edges of the rating plates are coated with a matching special paint, see section 4.11 "Paint coats".

In special cases, i.e. special specifications, riveted or bolted metal plates are used.

54

4.11 Paint coats

4.11.1 General

All paint finishes are sprayed on.



Drives in ATEX version.

Plastic surfaces exposed to friction in normal operation can become electrostatically charged.

With use in zone 21 and 22 (dusts) the thickness of the paint finish must not exceed 200 µm.



Note.

Information on repaintability is not a guarantee of the quality of the paint material supplied by your supplier.

Only the paint manufacturer is liable for the quality and compatibility.

4.11.2 Painted version

| Paint system | Plastic | 2K-PUR | 2K-epoxide |
|------------------------------------|---|--|--|
| Colours | RAL 1007, 1012, 1023, 2000, 2004, 3000, 5007, 5009, 5010, 5012, 5015, 6011, 7001, 7011, 7030, 7032, 7035, 9005, 9006, black-mat | RAL 1003, 1018, 2004, 5002, 5015, 6011, 7000, 7031, 9010, 9011, 9016 | RAL 5015, 6018, 7031, 7035 |
| Typical area of application | Standard-1-layer paint finish for interior areas | Standard 2-layer paint finish, especially for outside installation or higher corrosion protection requirements | high-quality paint finish in the outside area or where exposed to dilute acid and alkaline solution ($\leq 5\%$) |
| Repaintability | after prior rubbing down with: Plastic or synthetic resin paint | after prior rubbing down with: 2K-PUR paint, 2K-epoxide paint | after prior rubbing down with: 2K-PUR paint, 2K-epoxide paint, 2K-AC paint |
| Chem. phys. resistance | good resistance to: cleaning agent, oil and petrol; resistant to: exposure to dilute acid and alkaline solution for a short time ($\leq 3\%$); not solvent-resistant; not steam-resistant | very good resistance to: oil, grease, petrol, water, seawater and cleaning agent; good resistance to: weather action and dilute acid and alkaline solution ($\leq 3\%$); good mechanical resistance to: abrasion | excellent resistance to: weak acid and alkaline solution ($\leq 5\%$), oil, grease, petrol, cooling emulsion, salt, solvent; tough and scratchproof paint film |
| Temperature resistance | -40 °C ... +100 °C temporarily up to 140 °C | -40 °C ... +150 °C | -40 °C ... +150 °C |
| Remark | Standard paint finish with very good adhesive property, not suitable for: storage or installation outside | Standard paint finish for cooling tower and agitator drives or, if requested, resistance to sea water below deck, etc. | 2K-epoxide paint becomes chalky when installed outside (without effect on quality), high gloss with good mechanical resistance |

Table 4.11.2: Painted version

55

4.11.3 Primed version

| Paint system | primed | unpainted |
|-----------------------------|---|--|
| Standard colour | RAL 7032 | - |
| Typical area of application | for repainting*): adhesion promoter for all common paint systems, temporary corrosion prevention | for repainting*): temporary corrosion prevention |
| Repaintability | very good with: plastic paint, synthetic resin paint, 2K-PUR paint, 2K-epoxide paint, SH paint, 2K-AC paint | very good with: Plastic paint, synthetic resin paint, oil paint, bitumen paint, 2K-PUR paint, 2K-epoxide paint |
| Chem. phys. resistance | good resistance to: cleaning agent, good salt-spray resistance; resistant to: oil and petrol | - |
| Temperature resistance | -40 °C ... +150 °C | (-40 °C ... +150 °C) |
| Remark | Adhesion promoter with very good adhesive property and good corrosion prevention | GCI parts, dip-primed, steel parts primed or galvanised, aluminium and plastic parts untreated |

Table 4.11.3: Primed version

*) On drive versions which are primed or unpainted the rating plate and the masking film are covered with a paint-protective film, see section 4.10 "Rating plates". It enables repainting without further preparation, e.g. masking with adhesive tape.

Peel off paint-protective film

The paint coat must have fully hardened before the paint-protective film is peeled off (be at least "touch-proof").




Figure 4.11.3: Peel off paint-protective film

1) Company Logo

- 1) Pull peeling tab up.
- 2) Carefully peel the paint-protective film off diagonally from one corner (not parallel to the plate).
- 3) If necessary, blow paint fragments away or wipe them off with a clean cloth.

5. Incoming goods, Handling and Storage

5.1 Incoming goods



Note.

Inspect the delivery immediately after arrival for completeness and any transport damage.

Notify the freight company of any damage caused during transport immediately, as otherwise it is not possible to have damage rectified free of charge.



Caution.

Ensure that damaged drives are not put into operation.

The drive unit is delivered in the fully assembled condition. Additional items are delivered separately packaged.

The products supplied are listed in the despatch papers.

5.2 Handling

Different forms of packaging may be used, depending on the size of the drive and method of transport. Unless otherwise agreed, the packaging complies with the **HPE Packaging Guidelines** (Bundesverband Holzpackmittel Paletten Exportverpackungen e.V.).

Note the symbols applied to the packing. These have the following meanings:



This way up



Fragile



Keep dry



Keep cool



Centre of gravity



Use no hand hook



Attach here


Figure 5.2-1: Symbols on packaging

Fasten drive for suspended transport



Danger.


Adhere to the maximum load in direction F of the transport eyes and eye bolt axis, see figure and table 5.2-2 bzw. 5.2-3 "Max. load in kg from drive to be attached". Use eye bolt on motor only for transporting the unmounted or demounted motor or as auxiliary support for the drive, e.g. to achieve a horizontal mounting position. If necessary, use additional, suitable carrying means for transport or on installation. When attaching by a number of chains and ropes just two strands must be sufficient to bear the entire load. Secure carrying means against slipping.



| | K.38 | K.48 | K.68 | K.88 | K.108 | K.128 | K.148 | K.168 | K.188 |
|---------------------|------|------|------|------|-------|-------|-------|-------|-------|
| d ₂ [mm] | 22 | 22 | 26 | 30 | 35 | 40 | 44 | 55 | 55 |
| m [kg] | 200 | 250 | 350 | 600 | 750 | 800 | 1300 | 1800 | 2300 |

Figure and Table 5.2-2: Max. load in kg from drive to be attached, with pull ↑ in direction F.

57



| d_3 [mm] | 36 | 45 | 54 | 63 | 72 | 90 | 108 |
|---------------|------------|-------------|-------------|-------------|-------------|-------------|-------------|
| M | M 8 | M 10 | M 12 | M 16 | M 20 | M 24 | M 30 |
| m [kg] | 140 | 230 | 340 | 700 | 1200 | 1800 | 3600 |

Figure and Table 5.2-3: Max. load in kg from drive to be attached, with pull \uparrow in direction F of the bolt axis.



Caution.
Do not use the front threads at the shaft ends to attach eye bolts for transport.



Caution.
The use of force causes damage to the drive unit.
Transport drive carefully. Avoid knocks.
Remove any transport fixtures fitted before putting into operation and keep them safe or render them ineffective. Use them again for further transport or render them ineffective again.

- 1) Mount the drive on the transport device by the heaviest permissible weight to be attached. This will normally be on the main gear unit.
- 2) Check that the eye bolt is firmly seated.
- 3) Drive is slung for transport.

5.3 Storage

The gear unit must be stored in its position of use on a horizontal wooden support in a dry place not subject to high temperature fluctuations and covered over. The storage place must be free from vibration and shaking.



Danger.
Do not stack drive units one on top of another.



Caution.
Mechanical damage (scratches), chemical damage (acids, alkalis) and thermal damage (sparks, welding beads, heat) cause corrosion which may cause failure of the external protective coating.
Ensure that the paint is not damaged.

The drive units are provided with an interior preservative agent; the free shaft ends and flanges are painted for protection.



Note.
The guarantee period for the standard preservative lasts 6 months and, unless otherwise agreed, begins at the date of delivery of the gear unit.
In the case of longer periods of storage (> 6 months) special arrangements must be made for preservation. Contact the **FLENDER TÜBINGEN GMBH** customer service.

6. Installation

6.1 General information on installation



Danger.

When working with solvents, ensure adequate ventilation. Do not inhale vapours. Do not smoke!



Caution.

Overheating of the drives through exposure to direct sunlight. Provide suitable safety equipment, such as covers and roofs.



Caution.

Irreparable damage to toothed components and bearings from fusing. Do not carry out any welding work on the drive. The drives must not be used as an earthing point for welding operations.



Note.

Use headless bolts of strength class 8.8 or higher to fasten the drives.



Drives in ATEX version.

Affect on bearings of stray electric currents from electrical equipment. When mounting or connecting the gear unit to the machine care must be taken that potential is equalised.

Exercise particular care when assembling and installing. The manufacturer cannot be held liable for damage caused by incorrect assembly and installation.

Ensure that there is sufficient space around the drive for assembly, maintenance and repair.

On drives with a fan leave sufficient free space for the entry of air.

Provide sufficient lifting gear at the start of assembly and fitting work.

Use all the fastening means which have been assigned to the relevant assembly option.

6.2 Fastening in the case of reversing operation or high shock loads

In the case of reversing operation or high shock loads provide additional suitable positive fastenings such as cylindrical taper pins or spring pins.



Caution.

Do not use spring washers, serrated lock washers, spring or toothed lock washers, cup washers or conical spring washers as a substitute for the above mentioned positive fastenings.

Do not subject the gear unit housing to excessive stress when tightening the fastening bolts.

Cap screws cannot be used in some cases, as there is insufficient space available for inserting them. In case of doubt please contact the **FLENDER TÜBINGEN GMBH** customer service, quoting the type of gear unit.

54

6.3 Drives with foot mounting

6.3.1 Foundation

The foundation must be level and free from dirt.



Note.

The levelness of the gear unit support must not exceed the following values:
for gear units up to size 88 ≤ 0.1 mm
for gear units from size 108 ≤ 0.2 mm.

The foundation should be designed in such a way that no resonance vibrations are created and that no vibrations are transmitted from adjacent foundations.

Steel structures on which the unit is to be mounted must be rigid. They must be designed according to the weight and torque, taking into account the forces acting on the gear unit.

When fastening the gear unit to concrete foundations by means of foundation blocks, suitable recesses should be made in the foundation.

Align and grout the slide rails into the foundation.

6.3.2 Installing gear units with foot mounting

Use stud bolts or headless bolts of strength class 8.8 or higher for the foot mounting.

6.4 Drive units in foot or flange version

The drive must be fastened for force and torque transmission only to either the flange or the foot mounting in accordance with section 6.3 "Drives with foot mounting" to prevent overstress on the gear unit housings.

The second mounting option (foot or flange) is usually intended for add-on elements, e.g. safety covers with an intrinsic weight of up to 30 % of the weight of the drive.



Caution.

Do not subject gear housings to overstress from add-on elements.
Add-on elements must not transmit forces, torques and vibration to the drives.

6.5 Drive units with C-type housing flange

In the case of sizes 108 - 188 the customer's interface can be pinned on the C-type housing flange. The drive flanges are designed to enable the permissible torques and radial forces to be reliably transmitted by the bolt connections.

For additional fastening, e.g. in the case of reversing operation or high shock loads, the drilled pin holes can be used.

The gear unit can also be drilled and pinned together with the machine. For this the specified dimensions must be adhered to.



Caution.
Observe maximum drilling depth (A-A).






Figure 6.5–1: C-type housing flange helical gear units


K.Z.108, F.Z.108B



K.Z.128, F.Z.128B



K.Z.148, F.Z.148B



K.Z.168, K.Z.188, F.Z.168B, F.Z.188B





Figure 6.5-2: C-type housing flange bevel helical gear units and parallel shaft helical gear units

- Spring pins, heavy-duty design, to DIN 1481: Use pin holes provided in the housing flange.
- ⊕ Cylindrical grooved pins with chamfer to DIN EN 28740/ISO 8740: Drill connecting component together with housing.

6.6 Installation of input drive and output drive elements on gear unit shafts

Use a fitting device to fit the drive or output elements.

Located in the shaft end faces are centring holes to DIN 332 which can be used for this.



Example of a fitting device for fitting couplings or hubs on the ends of gear unit or motor shafts. If necessary, the axial thrust bearing on the fitting device can be dispensed with.

Figure 6.6-1: Fitting device



Note.

Deburr the parts of elements to be fitted in the area of the hole or keyways.
Recommendation: 0.2 x 45°

Mount in- or output elements



Caution.

Damage to shaft sealing ring through solvent or benzine.
Protect against contact at all time.


- 1) Using petrol ether or solvent, remove the corrosion-preventive paint coat on the shaft ends and flanges or remove any protective skin provided.



Caution.

Damage to bearings, housing, shaft and locking rings.
Do not use a hammer to force the drive and output elements to be mounted onto the shaft.

- 2) Fit the drive and output elements onto the shafts and, if necessary, secure them.



Correct mounting arrangement of running wheel, gear or chain wheel, belt pulley, etc., to keep the shaft and bearing load exerted by transverse forces as low as possible.

Figure 6.6-2: Mounting arrangement

a Hub

✗ wrong

✓ right

Where couplings are to be fitted in a heated condition, please observe the specific operating instructions for the coupling.

6.7 Steel safety cover for hollow shaft and shrink disc



Drives in ATEX version.
Sparks may be caused by a damaged safety cover.
Replace damaged safety cover immediately.

The steel safety cover is delivered ready-fitted to the gear unit flange. The safety cover must be demounted to fit the output shaft.

Mounting the protective cover

- 1) Undo screws part 1 and remove protective cover part 2.
- 2) Using a suitable cleaning agent, clean the support surface of the safety cover, part 2, on the gear unit.
- 3) Ensure that the O-ring, part 3, is correctly seated.
- 4) Coat the supporting surface of the safety cover, part 2, with a suitable sealing agent.
- 5) Fasten protective cover part 2 by screws.




Figure 6.7: Steel safety cover

- | | | |
|--------------------|----------------|---------------------|
| 1 Bolt | 3 O-ring | 5 Gear unit housing |
| 2 Protective cover | 4 Adaptor ring | |

The adaptor ring, part 4, is provided only on foot-mounted versions of bevel-helical gear units sizes 68, 108, 128, 148 and 168.

64

6.8 Cast iron end cover for hollow shaft

The cast iron end cover is delivered ready-fitted on the gear unit flange. The end cover must be demounted to fit the output shaft.

Assembly of end cover

- 1) Undo screws part 1 and remove end cover part 2.
- 2) Using a suitable cleaning agent, clean the support surface of the end cover, part 2, on the gear unit.
- 3) Coat the supporting surface of the end cover, part 2, with a suitable sealing agent.
- 4) Fasten end cover part 2 by screws.




Figure 6.8: End cover made from cast iron

1 Bolt

2 End cover

3 Gear unit housing

**6.9 Shaft-mounting gear unit with hollow shaft and parallel key,
hollow shaft and splines,
hollow shaft and shrink disk**

6.9.1 Mounting the hollow shaft



Caution.
Damage to shaft sealing ring through solvent or benzine.
Protect against contact at all time.

- 1) Using petrol or a solvent, remove the corrosion-preventive paint coat from the shaft ends and flanges.
- 2) Check the seats or edges of the hollow and machine shaft for damage. In case of damage contact the **FLENDER TÜBINGEN GMBH** customer service.



Note.
Coat with the mounting paste which comes with the delivery or any suitable lubricant, e.g. Calypsol type H 443 HD88 grease, to prevent frictional corrosion of the contact surfaces.



Caution in the case of shrink disks.
Lubricants in the area of the shrink disk seat impair torque transmission.
Keep bore in hollow shaft and machine shaft completely grease-free.
Do not use impure solvents and cleaning cloths.

- 3) Fit the drive with the aid of nut and threaded spindle. The counterforce is provided by the hollow shaft.



Caution.
The hollow shaft must be precisely aligned with the machine shaft to avoid misalignment.
Failure of the bearings from overload in the case of flange-mounted drive.
Do not overstress hollow shaft axially and radially.

- 4) Secure the hollow shaft axially on the machine shaft with e.g. a locking ring, washer or set screw at a tightening torque T_A acc. to table 6.9.1 "Tightening torque T_A set screw".

| Size | 38 | 48 | 68 | 88 | 108 | 128 | 148 | 168 | 188 |
|------------|----|----|----|----|-----|-----|-----|-----|-----|
| T_A [Nm] | 16 | 28 | 69 | 69 | 138 | 138 | 138 | 237 | 237 |

Table 6.9.1: Tightening torque T_A set screw



Note for shrink disks.
The hollow shaft is axially secured on the machine shaft by means of a shrink disk connection.




Figure 6.9.1-1: Mounting hollow shaft and parallel key

Part 3 - Part 4 are not included in scope of delivery.




Figure 6.9.1-2: Mounting hollow shaft and splines

Part 3 - Part 4 are not included in scope of delivery.




Figure 6.9.1-3: Mounting hollow shaft and shrink disk

a greased

b absolutely free of grease

Part 3 - Part 5 are not included in scope of delivery.

- 1 Machine shaft
- 2 Hollow shaft
- 3 Hexagon nut

- 4 Threaded spindle
- 5 Washer
- 6 Locking ring

- 7 Parallel key
- 8 Bronze bush



Note.

Coat with a suitable lubricant, e.g. Calypsol type H 443 HD88 grease, to prevent frictional corrosion of the contact surfaces of the customer's machine shaft in the vicinity of the bronze bush.

Instead of the nut and threaded spindle shown in the diagram, other types of equipment such as hydraulic lifting equipment may be used.

6.9.2 Remove hollow shaft and parallel key



Caution.

Before driving out the machine shaft fasten a suitably dimensioned means of absorbing load to the drive.
Slightly pretension the drive element so that the drive does not drop into the drive element when the insert-shaft is released.

If frictional corrosion has occurred on the seat surfaces, use rust solvent to enable the gear unit to be pulled off. Allow the rust solvent to work in sufficiently.

- 1) Remove the axial fastening of the hollow shaft.



Caution.

It is essential to prevent misalignment when removing the gear unit.




Figure 6.9.2: Remove hollow shaft and parallel key

- | | | |
|--------------------|-----------------|-------------------|
| 8 Threaded spindle | 10 Hexagon nut | 12 Threaded block |
| 9 Hexagon nut | 11 Parallel key | 13 Washer |

Part 8 - Part 13 are not included in scope of delivery.

Suggested design for threaded piece and disc see figure 6.9.3 and table 6.9.3.

- 2) Drive out the machine shaft with the aid of the disk, part 13, threaded block, part 12, parallel key, part 11, and threaded spindle, parts 8 - 10.
- 3) When the rust solvent has sufficiently worked in, pull off the gear unit, using the device, see figure 6.9.2 "Remove hollow shaft and parallel key".

6.9.3 Suggested design for threaded piece and disc




Figure 6.9.3: Suggested design for threaded piece and disc

| Size | b10 [mm] | b11 [mm] | b12 [mm] | d10 [mm] | d11 [mm] | s11 | t _{max} [mm] | u [mm] |
|------|-------------|-------------|-------------|-------------|-------------|---------|--------------------------|-----------|
| 38 | 6 | 15 | 10 | 29.9 | 20 | M10x1.5 | 33 | 8 |
| 48 | 6 | 15 | 5 | 34.9 | 24 | M12x1.5 | 43 | 10 |
| | | | | 39.9 | 28 | | | 12 |
| 68 | 7 | 20 | 7 | 39.9 | 28 | M16x1.5 | 48.5 | 12 |
| | | | | 44.9 | 33 | | | 14 |
| 88 | 7 | 20 | 10 | 49.9 | 36 | M16x1.5 | 64 | 14 |
| | | | | 59.9 | 45 | | | 18 |
| 108 | 10 | 24 | 10 | 59.9 | 45 | M20x1.5 | 74.5 | 18 |
| | | | | 69.9 | 54 | | | 20 |
| 128 | 10 | 24 | 5 | 69.9 | 54 | M20x1.5 | 85 | 20 |
| | | | | 79.9 | 62 | | | 22 |
| 148 | 10 | 24 | 7 | 79.9 | 62 | M20x1.5 | 95 | 22 |
| | | | | 89.9 | 72 | | | 25 |
| 168 | 10 | 30 | 8 | 99.9 | 80 | M24x1.5 | 106 | 28 |
| | | | | 109.9 | 90 | | 116 | |
| 188 | 10 | 30 | 11 | 119.9 | 95 | M24x1.5 | 127 | 32 |

Table 6.9.3: Suggested design for threaded piece and disc

6.10 Shrink disc

6.10.1 Mounting the shrink disc

The shrink disc is delivered ready for installation.



Caution.
Do not dismantle shrink disc before initial fitting.



Caution.
Lubricants in the area of the shrink disc seat impair torque transmission.
Keep bore in hollow shaft and machine shaft completely grease-free.
Do not use impure solvents and cleaning cloths.



Caution.
Plastic deformation of the hollow shaft when tightening the tensioning bolts before fitting the machine shaft.
First fit machine shaft. Then tighten tensioning bolts.




Figure 6.10.1-1: Shrink disc

- | | | | | | |
|---|---------------|---|---------------------------|---|-----------------|
| a | greased | b | absolutely free of grease | | |
| 1 | Machine shaft | 3 | Inner ring | 5 | Tensioning bolt |
| 2 | Hollow shaft | 4 | Outer ring | | |



Caution.
The end face of the hollow shaft, part 2, must be flush with the inner ring, part 3, of the shrink disc.



Caution.
Avoid overloading the individual bolts.
Do not exceed the maximum torque acc. to table 6.10.1 "Tightening torque T_A clamping screw" at $\mu = 0,1$.
Of prior importance is the alignment of the end faces. If this alignment is not achieved when tensioning, the tolerance of the stub shaft must be checked.

| Clamping screw thread | d1 | Tightening torque T_A strength class 10.9 | Tightening torque T_A strength class 12.9 |
|-----------------------|-----------|--|--|
| | [mm] | [Nm] | [Nm] |
| M 6 | 12 - 30 | 12 | - |
| M 8 | 36 - 68 | 29 | 35 |
| M 10 | 75 - 100 | 58 | 70 |
| M 12 | 105 - 125 | 100 | 121 |
| M 14 | 135 - 155 | 160 | 193 |
| M 16 | 160 - 200 | 240 | 295 |
| M 20 | 220 - 280 | 470 | 570 |

Table 6.10.1: Tightening torque T_A clamping screw

- 1) The clamping screws, part 5, must be tightened one after the other, working round several times, until the front faces of the outer and inner ring are flush..




Figure 6.10.1–2: Sequence for tightening the clamping screws

- 2) In this way you can check for the optimum tightening condition.
- 3) If necessary, grease the outside surfaces of the hollow shaft in the area of the shrink disk seat.
- 4) Fit the safety cover delivered with the unit, see section 6.7 "Steel safety cover for hollow shaft and shrink disc".

6.10.2 Pulling off the shrink disc

If the outer ring does not release from the inner ring, several clamping screws can be removed and then screwed into adjacent forcing threads.

The rings can then be released without difficulty.

- 1) Loosen the clamping screw one after the other, working round several times.
- 2) Pull the shrink disc from the hollow shaft.

6.10.3 Cleaning and greasing the shrink disc

Loosened shrink discs need not be dismantled and re-greased before being re-tensioned.

Dismantle and clean the shrink disc.

Before reassembly grease only the inner sliding surfaces of the shrink disc.

Use for this a solid lubricant with a friction coefficient of $\mu = 0.04$ in accordance with table 6.10.3 "Lubricants for shrink disc cleaning".

| Lubricant | Commercial form | Manufacturer |
|------------------------------------|-----------------|--------------------|
| Molykote 321 R (lubricating paint) | Spray | DOW Corning |
| Molykote Spray (Powder spray) | | |
| Molykote G Rapid | Spray or Paste | Klüber Lubrication |
| Molykombin UMFT 1 | Spray | |
| Unimily P 5 | Powder | |
| Aemasol MO 19 P | Spray or Paste | A. C. Matthes |

Table 6.10.3: Lubricants for shrink disc cleaning

6.11 Attachment of standard motors

6.11.1 Fit standard motor on coupling housing with torsionally flexible coupling




Figure 6.11.1: Coupling housing with torsionally flexible coupling

502 Plug
505 Hexagon head screw
555 Coupling half
556 Coupling half
557 flexible element
564 Set screw

- 1) Fit the coupling half, part 556, onto the end of the motor shaft in accordance with section 6.6 "Installation of input drive and output drive elements on gear unit shafts".
- 2) Adhere to the spacing dimension z12 acc. to table 6.11.1–3 "Distance dimension z12" ein.

| IEC B5 | 80 | 90 | 100 | 112 | 132 | 160 | 180 | 200 | 225 | 250 | 315 |
|----------|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| z12 [mm] | 15 | 26 | 30 | 30 | 45 | 66 | 59 | 60 | 90 | 75 | 33 |

| NEMA TC | 56C | 143TC / 145TC | 182TC / 184TC | 213TC / 215TC | 254TC / 256TC | 284TC / 286TC | 324TC / 326TC | 364TC / 365TC |
|----------|------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|
| z12 [mm] | 27.5 | 28 | 36.5 | 45.5 | 50 | 61 | 71 | 78 |

Table 6.11.1–3: Distance dimension z12



Note.

Dimension z12 applies to standard assignment of the coupling. In the case of a special assignment, refer for the dimension to the relevant special dimension diagram.

- 3) Using the set screw, part 564, secure the coupling half, part 556, against axial displacement.
- 4) In the case of motors which are balanced with a half parallel key (symbol "H") machine off projecting and visible parts of the parallel key.

72

- 5) Insert the flexible element part 557 into the coupling half part 555.
- 6) Flange-mount the motor on the coupling housing and fasten it with the bolts, part 505, to the prescribed torque acc. to table 6.11.1-4 "Tightening torque T_A fitted motor".

| Thread size | Tightening torque T_A strength class min. 8.8 [Nm] | Thread size | Tightening torque T_A strength class min. 8.8 [Nm] |
|-------------|--|-------------|--|
| M 4 | 3 | M 16 | 210 |
| M 5 | 6 | M 20 | 450 |
| M 6 | 10 | M 24 | 750 |
| M 8 | 25 | M 30 | 1500 |
| M 10 | 50 | M 36 | 2500 |
| M 12 | 90 | | |

Table 6.11.1-4: Tightening torque T_A fitted motor



Caution.

If drives are inadequately sealed, moisture may find a way in. If installing the drive outside or in the case of a higher type of protection (\geq IP 55): Seal flange, bolts, part 505, and any sealing plugs, part 502, provided or elements fitted, e.g. proximity switches, with a suitable sealing compound. Flange-mounted motors must generate a sealing surface running all the way round.

6.11.2 Using a clamp ring, attach standard motor to coupling housing




Figure 6.11.2-3: Coupling lantern with clamping ring

| | | |
|------------------------|-------------------------------|------------------|
| 502 Mounting plug | 515 Drive shaft | 563 Parallel key |
| 503 Mounting plug | 560 Clamp ring | 564 Set screw |
| 505 Hexagon head screw | 561 Hexagon socket head screw | |

- 1) Remove the mounting plugs part 502 and part 503.
- 2) Align drive shaft, part 515, and clamp ring, part 560, of the gear unit by turning to the mounting holes for mounting plugs, part 502 and part 503.
- 3) Coat the set screw, part 564, with adhesive (medium-strength, e.g. Loctite 243), see figure 6.11.2-3 "Coupling lantern with clamping ring".
- 4) Fix clamp ring, part 560.



Caution.

Do not overstress the motor shaft axially when flange-mounting the motor. Keep the motor shaft completely grease-free in the area of the clamp ring. In the case of brake motors release the brake while flange-mounting.

- 5) Flange-mount the motor to the coupling housing and fasten it with the bolts, part 505, to the prescribed torque acc. to table 6.11.2-1 "Tightening torque T_A fitted motor".

| Thread size | Tightening torque T_A strength class min. 8.8 [Nm] | Thread size | Tightening torque T_A strength class min. 8.8 [Nm] |
|-------------|--|-------------|--|
| M 4 | 3 | M 16 | 210 |
| M 5 | 6 | M 20 | 450 |
| M 6 | 10 | M 24 | 750 |
| M 8 | 25 | M 30 | 1500 |
| M 10 | 50 | M 36 | 2500 |
| M 12 | 90 | | |

Table 6.11.2-1: Tightening torque T_A fitted motor



Caution.

When pushing the motor onto the coupling, the motor bearing on the ventilation side may become overstressed. When fitting the motor in a vertical position from size 100 upwards the weight of the rotor shaft prevents the bearing from being overstressed. When fitting the motor in a horizontal position and for motors up to size 90, see work steps 6) - 8).

- 6) Remove the fan cover.
7) Ease the overstress on the bearing by lightly pressing the shaft end by hand, see figure 6.11.2-4 "Pressure on motor shaft".




Figure 6.11.2-4: Pressure on motor shaft

- 8) Mount the fan cowl.
9) Screw the set screw, part 564, onto parallel key, part 563, until slight resistance is felt, then unscrew the set screw half a turn.
10) Insert the Allen key into set screw, part 564, through the hole for part 503. This prevents the shaft turning.



Caution.

Set screw, part 564, must not be in contact, of hexagon socket screw, part 561, has been tightened.

- 11) Tighten the hexagon socket screw, part 561, to tightening torque $T_{A SW2}$ acc. to table 6.11.2-2 "T_A and SW".
- 12) Tighten the set screw to tightening torque $T_{A SW1}$ acc. to table 6.11.2-2 "T_A and SW" an.

| IEC B5 | 63 | 71 | 80 | 90 | 100 | 112 | 132 | 160 | 180 | 200 | 225 | 250 | 280 |
|-------------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| T _{A SW1} [Nm] | 1.3 | 1.3 | 1.3 | 2.9 | 2.9 | 2.9 | 5.8 | 9.9 | 9.9 | 9.9 | 9.9 | 9.9 | 48 |
| SW1 [mm] | 2 | 2 | 2 | 3 | 3 | 3 | 4 | 5 | 5 | 5 | 5 | 5 | 8 |
| T _{A SW2} [Nm] | 15 | 15 | 15 | 35 | 35 | 35 | 70 | 120 | 120 | 295 | 295 | 295 | 580 |
| SW2 [mm] | 5 | 5 | 5 | 6 | 6 | 6 | 8 | 10 | 10 | 14 | 14 | 14 | 17 |

| NEMA TC | 56C | 143TC / 145TC | 182TC / 184TC | 213TC / 215TC |
|-------------------------|-----|---------------|---------------|---------------|
| T _{A SW1} [Nm] | 1.3 | 2.9 | 2.9 | 5.8 |
| SW1 [mm] | 2 | 3 | 3 | 4 |
| T _{A SW2} [Nm] | 15 | 15 | 35 | 70 |
| SW2 [mm] | 5 | 5 | 6 | 8 |

Table 6.11.2-2: T_A and SW



Caution.

If drives are inadequately sealed, moisture may find a way in
 If installing the drive outside or in the case of a higher type of protection (≥ IP 55):
 Seal flange, bolts, part 505, and mounting plugs, part 502 and part 503, with a suitable
 sealing compound.
 Flange-mounted motors must generate a sealing surface running all the way round.

- 13) Seal the mounting holes with the plugs, part 502 and part 503.

6.12 Motor base plate



Drives in ATEX version.

The motor bedplate version is delivered without belt, belt pulley and safety cover.
 Sparks may be caused by friction or impact.
 A safety system must be used to ensure that
 - the belt does not slip and so become a source of combustion,
 - no foreign bodies can get into the belt drive zone.



Danger.

Rotating drive parts.
 Always fit suitable safety equipment to cover the belt, chain or other open drives.



Caution.

Belt breakage and bearing damage through incorrect belt tension.
 Observe operating instructions for V-belt drives.
 Fit belt pulleys onto the drive shaft, part 515, in accordance with section 6.6
 "Installation of input drive and output drive elements on gear unit shafts".

The motor bedplate serves to mount an IEC-B3 foot-mounted motor used mainly to drive a V-belt drive.
 Fit the motor in accordance with the manufacturer's operating instructions.

For other types of drive, e.g. chain drive, please observed the relevant operating instructions or
 manufacturer's information.

6.12.1 Mounting IEC motors up to size 112




Figure 6.12.1: Mounting motor bedplates - IEC motors up to size 112

515 Drive shaft 588 Bolt 590 Motor plate
585 Bolt

- 1) Loosen the screw, part 585 (4x).
- 2) Adjust the height of the motor plate, part 590, by evenly turning the screw, part 588, and adjust e.g. the belt tension.
- 3) After adjusting to the correct height, tighten the bolts, part 585, (4x) to the prescribed torque acc. to table 6.12.1 "Tightening torque T_A fitted motor".

| Thread size | Tightening torque T_A strength class min. 8.8 [Nm] | Thread size | Tightening torque T_A strength class min. 8.8 [Nm] |
|-------------|--|-------------|--|
| M 4 | 3 | M 16 | 210 |
| M 5 | 6 | M 20 | 450 |
| M 6 | 10 | M 24 | 750 |
| M 8 | 25 | M 30 | 1500 |
| M 10 | 50 | M 36 | 2500 |
| M 12 | 90 | | |

Table 6.12.1: Tightening torque T_A fitted motor



Caution.

On completing installation and adjusting work protect bright parts against corrosion. Use a suitable, durable corrosion-preventive medium.

6.12.2 Mounting IEC motors sizes 132 to 200



Danger.
Motor bedplate may slip out of the fastening.
Do not adjust when in a suspended mounting position.




Figure 6.12.2: Mounting motor bedplate IEC motors sizes 132 to 200

| | | |
|-----------------|------------|-----------------|
| 515 Drive shaft | 586 Pillar | 589 Hexagon nut |
| 585 Set screw | 588 Bolt | 590 Motor plate |

- 1) Loosen the set screws Pos. 585 (4x).
- 2) Adjust the height of the motor plate, part 590, by evenly turning the screw, part 588, and adjust e.g. the belt tension.
- 3) After setting the correct height tighten the set screws, part 585, (4x).



Caution.
On completing installation and adjusting work protect bright parts against corrosion.
Use a suitable, durable corrosion-preventive medium.

6.12.3 Mounting IEC motors from size 225




Figure 6.12.3: Mounting motor bedplate IEC motors from size 225

| | | |
|-----------------|-----------------|-----------------|
| 515 Drive shaft | 588 Bolt | 590 Motor plate |
| 585 Set screw | 589 Hexagon nut | 592 Hexagon nut |
| 586 Pillar | | |

- 1) Loosen the set screws Pos. 585 (4x).
- 2) Undo the hexagon nuts, part 592, of the support.
- 3) Adjust the height of the motor plate, part 590, by evenly turning the screw, part 588, and adjust e.g. the belt tension.
- 4) After setting the correct height tighten the set screws, part 585, (4x).



Caution.

When tightening the hexagon nuts, part 592, do not force or twist the motor plate, part 590, into a different position.

- 5) Tighten the hexagon nuts, part 592, of the support.

6.13 Torque arm with shaft-mounted gear units

The torque arm serves to absorb the reaction torque and, if necessary, the weight of the drive.



Drives in ATEX version.

Worn or irreparably damaged rubber elements will not function properly. Sparks may be caused by impact.

The rubber elements must be replaced immediately.



Caution.

Dangerously high impact moments due to too high backlash.

Ensure that the torque support does not give rise to excessive constraining forces (e.g. through the driven shaft running out of true).



Caution.

Keep solvents, oils, greases and fuels away from the rubber elements.

6.13.1 Fit torque arm to bevel helical gear unit



Danger.

The torque arm bush must be mounted in bearings on both sides.

Suggestion for fitting the gear unit with torque arm:




Figure 6.13.1: Torque arm on bevel helical gear unit

T_R Reaction torque on gear unit housing = output torque T_2

F_S Bracing force of the torque arm against the suspension

Properties of the rubber elements:

| | |
|-------------------------------|-------------------|
| Basic material natural rubber | 60 Shore A |
| thermal resistance | -45 °C ... +70 °C |

- 1) Clean the contact surfaces between housing and torque arm.
- 2) Secure the bolts for fastening the torque arm on the gear unit with Schnorr lock washers.
- 3) Tighten the bolts to the prescribed torque acc. to table 6.13.1 "Tightening torque T_A Fitting torque arm".

| Thread size | Tightening torque T_A strength class min. 8.8 [Nm] | Thread size | Tightening torque T_A strength class min. 8.8 [Nm] |
|-------------|--|-------------|--|
| M 8 | 25 | M 20 | 450 |
| M 10 | 50 | M 24 | 750 |
| M 12 | 90 | M 30 | 1500 |
| M 16 | 210 | | |

Table 6.13.1: Tightening torque T_A Fitting torque arm

6.13.2 Mounting torque arm on parallel shaft helical gear unit



Note.

We recommend using pretensioned, damping rubber elements.

Suggestion for fastening the rubber elements ordered from and supplied by us:




Figure 6.13.2: Torque arm on parallel shaft helical gear unit

Fixings such as angle, screw, nut etc. are not included in the delivery.

| Type | F.38B | F.48B | F.68B | F.88B | F.108B | F.128B | F.148B | F.168B | F.188B |
|--------|-------|-------|-------|-------|--------|--------|--------|--------|--------|
| x [mm] | 13.1 | 18.2 | 17 | 27.2 | 26 | 35.8 | 34.8 | 46.2 | 45.1 |

Table 6.13.2: Setting dimension x

Properties of the rubber elements:

Basic material natural rubber 70 Shore A
hermal resistance -40 °C ... +80 °C

6.13.3 Mounting torque arm on helical worm gear unit



Danger.
The torque arm bush must be mounted in bearings on both sides.

Suggestion for fitting the gear unit with torque arm:




Figure 6.13.3: Torque arm on helical worm gear unit

The torque arm may be fitted in various positions, depending on the hole circle pitch.

Properties of the rubber elements:

Basic material natural rubber 60 Shore A
thermal resistance -45 °C ... +70 °C

- 1) Clean the contact surfaces between housing and torque arm.
- 2) Tighten the bolts to the prescribed torque acc. to table 6.13.3 "Tightening torque T_A Fitting torque arm".

| Thread size | Tightening torque T_A strength class min. 8.8 [Nm] | Thread size | Tightening torque T_A strength class min. 8.8 [Nm] |
|-------------|--|-------------|--|
| M 8 | 25 | M 20 | 450 |
| M 10 | 50 | M 24 | 750 |
| M 12 | 90 | M 30 | 1500 |
| M 16 | 210 | | |

Table 6.13.3: Tightening torque T_A Fitting torque arm

7. Start-up



Danger.

Secure the drive unit to prevent it from being started up unintentionally. Attach a warning notice to the start switch.



Danger.

Remove any oil spillage immediately with an oil-binding agent in compliance with environmental requirements.

7.1 Oil level check before start-up

Check the oil level before starting up, rectify the oil level, if necessary.



Note.

Description of the work see section 10.2.1 "Oil level".

7.2 Fill in oil

If the gear unit has been delivered without oil, put in lubricant before starting up.



Note.

Description of the work see section 10.2.3 "Oil change".

7.3 Ventilation of the gear unit

7.3.1 Filter for ventilation or pressure relief valve without securing clip

In the case of gear units with required housing ventilation the necessary ventilation filter or pressure relief valve without a securing clip is delivered separately. They must be replaced with the appropriate screw plug before starting up the gear unit.




1) Unscrew the sealing element at the point marked with this symbol, see section 3.5 "Mounting positions".

2) Seal the gear unit with the ventilation filter or the pressure relief valve without securing clip..

7.3.2 Pressure relief valve with securing clip (special version)

In the case of gear units with the required housing ventilation the pressure relief valve is fitted.

Remove the transport fixture by pulling the securing clip in the direction of the arrow.



7.4 Start-up after long-term preservation

7.4.1 Long-term preservation up to 18 months

The gear unit is preserved internally, but delivered without oil.



Caution.

Before starting up fill the gear unit with lubricant, see section 10.2.3 "Oil change".

7.4.2 Long-term preservation up to 36 months

The gear unit is delivered with a complete oil filling.



Caution.

Before starting up adjust oil level in accordance with the assembly option, see section 3.5 "Mounting positions".



- 1) Unscrew the sealing element at the point marked with this symbol, see section 3.5 "Mounting positions" and drain the oil.

- 2) Check the oil level.

- 3) Rectify the oil level, if necessary, see section 10.2.3 "Oil change", and check it again.

7.5 Drive with backstop (special version)



Caution.

Before starting up check direction of rotation.

Turn drive side or motor over manually.

Check direction of motor rotation with the aid of the phase sequence. If necessary, exchange two outer conductors.

8. Operation



Drives in ATEX version.

The difference between the temperature of the housing and the ambient temperature (max. 40 °C) must not exceed 70 K.

Using a suitable temperature sensor, measure the temperature at the lowest point of the housing (oil sump) or at the mounting surface in the case of output assemblies. Changes are an indication of possible incipient damage.



Caution.

In case of changes during operation the drive must be switched off immediately.

Determine the cause of the fault with the aid of the fault table in section 9. "Faults, causes and remedy".

Remedy faults or have faults remedied.

Check the gear unit during operation for:

- excessive operating temperature
- changes in gear noise
- possible oil leakage at the housing and shaft seals.

84

9. Faults, causes and remedy



Note.

Faults and malfunctions occurring during the guarantee period and requiring repair work on the drive must be carried out only by **FLENDER TÜBINGEN GMBH** Customer Service. In the case of faults and malfunctions occurring after the guarantee period and whose cause cannot be precisely identified, we advise our customers to contact our customer service.

If you need the help of our customer service, please state the following:

- data on the rating plate
- kind and extent of the fault
- suspected cause.

| Malfunctions | Causes | Remedy |
|----------------------------------|--|---|
| Unusual noises on the gear unit | oil level too low | check oil level, see section 10.2.1 "Oil level". |
| | foreign bodies in oil (irregular noise) | stop drive. Check oil quality. Clean drive. Change oil, see section 10.2.2 "Oil quality". |
| | excessive bearing play and/or bearing defective | check and, if necessary, replace bearings. |
| | teeth defective | check teeth and, if necessary, replace. |
| | fastening bolts loose | tighten bolts / nuts, see section 10.2.10 "Checking tightness of fastening bolts". |
| | excessive load on drive and output | check load on rating data. E.g. adjust belt tension. |
| | transport damages | check drive for transport damage. |
| | damage through blocking during start-up | contact customer service. |
| Unusual noises on the drive unit | bearing of drive unit not lubricated (from motor size 160 upwards) | relubricate bearing, see section 10.2.5 "Relubrication of the rolling bearings in drive units". |
| | excessive bearing play and/or bearing defective | check and, if necessary, replace bearings. |
| | fastening bolts loose | tighten bolts / nuts, see section 10.2.10 "Checking tightness of fastening bolts". |
| Unusual noises on the motor | excessive bearing play and/or bearing defective | check and, if necessary, replace bearings. |
| | motor brake rubbing | check, and if necessary adjust lifting gap. |
| | inverter parametrisation | correct parametrisation. |

| Malfunctions | Causes | Remedy |
|---|--|---|
| Oil leak | incorrect oil level for assembly option used | check assembly option, see section 3.5 "Mounting positions". Check oil level, see section 10.2.1 "Oil level". |
| | overpressure due to lack of ventilation | mount ventilation acc. to mounting position, see section 3.5 "Mounting positions". |
| | overpressure due to soiled ventilation | clean ventilation system, see section 10.2.8 "Clean ventilation filter". |
| | shaft sealing rings defective | replace shaft sealing rings. |
| | cover / flange bolts loose | tighten bolts / nuts, see section 10.2.10 "Checking tightness of fastening bolts". Continue observation of drive unit. |
| | surface sealing defective (e.g. on cover, flange) | reseal. |
| | transport damage (e.g. microcracks) | check drive for transport damage. |
| Oil leakage on gear-unit ventilation | incorrect oil level for the assembly option used and/or incorrect ventilation position | check position of ventilation and assembly option, see section 3.5 "Mounting positions". Check oil level, see section 10.2.1 "Oil level". |
| | frequent cold starts, during which the oil foams up | contact customer service. |
| Gear unit overheating | motor fan cover and/or drive badly soiled | clean fan cover and surface of drive, see section 10.2.9 "Clean drive". |
| | incorrect oil level for assembly option used | check assembly option, see section 3.5 "Mounting positions". Check oil level, see section 10.2.1 "Oil level". |
| | incorrect oil being used (e.g. incorrect viscosity) | check oil used, see section 10.2.2 "Oil quality". |
| | oil too old | check date of last oil change. Change oil, see section 10.2.3 "Oil change". |
| | excessive bearing play and/or bearing defective | check and, if necessary, replace bearings. |
| | backstop not running freely | replace backstop. |
| Output shaft does not turn when motor is running. | force flow interrupted by breakage in the gear unit | contact customer service. |

| Malfunctions | Causes | Remedy |
|--|---|---|
| Drive does not run or starts with difficulty | incorrect oil level for assembly option used | check assembly option, see section 3.5 "Mounting positions". Check oil level, see section 10.2.1 "Oil level". |
| | incorrect oil being used (e.g. incorrect viscosity) | check oil used, see section 10.2.2 "Oil quality". |
| | excessive load on drive and output | check load on rating data. E.g. adjust belt tension. |
| | motor brake is not lifted | check switching/connection of brake. Check brake for wear. If necessary, readjust brake. |
| | drive runs against backstop | change direction of motor or backstop rotation. |
| Excessive play on drive and output | flexible elements worn (e.g. with couplings) | replace flexible elements. |
| | positive connection disrupted by overload | contact customer service. |
| Drop of speed or torque | belt tension too low (in case of belt drive). | check belt tension, replace belt, if necessary. |

Table 9.: Faults, causes and remedy



10. Maintenance and repair

10.1 General information for maintenance

All inspection, maintenance and repair work must be done with care by trained and qualified personnel only. Observe the instructions given in section 2. "Safety instructions".



Drives in ATEX version.

All measures and checks and their results must be documented by the operator and kept in a safe place.

Maintenance and servicing must be carried out only by properly trained, authorised personnel. Only parts supplied by **FLENDER TÜBINGEN GMBH** must be used for servicing.

| Measure | Interval | Description of work |
|--|--|---|
| Observe and check drive unit for unusual noises, vibrations or changes | daily; if possible, more frequently during operation | see section 8. "Operation". |
| Check housing temperature | after 3 h, 1 day, then monthly | |
| Checking oil level | after the 1st day, then monthly | see section 10.2.1.1 "Check the oil level in the gear housing". |
| Checking the function of the oil sensor | regularly and after oil change | see section 10.2.1.4 "Checking the oil level sensor". |
| Checking the oil quality | every 6 months | see section 10.2.2 "Oil quality". |
| First oil change after start-up | after approx. 10 000 operating hours, at the latest after 2 years. | see section 10.2.3 "Oil change". |
| Subsequent oil changes | every 2 months or 10 000 operating hours | |
| Checking gear unit for leaks | after the 1st day, then monthly | see section 10.2.7 "Seal check". |
| Clean ventilation and, if necessary, replace | depending on degree of soiling, at least every 6 months. | see section 10.2.8 "Clean ventilation filter". |
| Clean drive | | see section 10.2.9 "Clean drive". |
| Check, and if necessary adjust slip coupling | every 12 months at least | see section 10.2.12 "Carry out maintenance on slip coupling". |
| Check coupling | for first time after 3 months | Observe the separate operating instructions. |
| Carrying out complete inspection of drive unit | every 12 months | see section 10.2.11 "Inspection of the drive". |
| Check that fastening bolts of gear unit and mounted elements are securely tightened. Check that covers and sealing plugs are securely fastened | after 3 h, then at regular intervals. | see section 10.2.10 "Checking tightness of fastening bolts". |

| Measure | Interval | Description of work |
|---|---|--|
| Relubricating the rolling bearings in drive units | at least every 12 months or every 4 000 operating hours | see section 10.2.5 "Relubrication of the rolling bearings in drive units". |
| Change rolling bearing grease | along with oil change | see section 10.2.6 "Change rolling bearing grease". |
| Replace bearing | - | see section 10.2.4 "Replacing bearings". |
| Checking rubber buffers of torque arm | every 6 months | see section 6.13 "Torque arm with shaft-mounted gear units". |

Table 10.1: Maintenance measures

10.2 Description of maintenance and repair work

10.2.1 Oil level



Drives in ATEX version.

After the screw plug has been removed, the oil level may not be more than 3 mm (in the case of 3/8" hole) or 5 mm (in the case of 3/4" hole) below the minimum filling level.



Danger.

Secure the drive unit to prevent it from being started up unintentionally. Attach a warning notice to the start switch.



Danger.

Danger of scalding from the hot oil emerging. Before starting any work wait until the oil has cooled down to 30 °C.



Danger.

Remove any oil spillage immediately with an oil-binding agent in compliance with environmental requirements.



Caution.

The oil quantity and the position of the sealing elements depend upon the assembly option, see section 3.5 "Mounting positions".



Note.

As a rule, mineral oil is used as lubricant. Synthetic oils with special properties are available optionally.

For data such as oil grade, oil viscosity and oil quantity required, refer to the rating plate, see section 3.2 "General technical data".

For oil compatibility refer to, see section 10.3 "Lubricants".



Note.

In case of double gear units every single unit is to be considered separately.

10.2.1.1 Check the oil level in the gear housing





Figure 10.2.1.1-1: Oil level

a Oil level

1) Switch off the power supply to the drive.



2) Unscrew the sealing element at the point marked with this symbol, see section 3.5 "Mounting positions".

3) Check the oil level.

4) Rectify the oil level, if necessary, see section 10.2.3 "Oil change", and check it again.

5) Check the condition of the sealing ring on the sealing element; if necessary, replace the sealing ring.

6) Seal the gear unit with the sealing element.

Check the oil level in the gear housing size 38

Size 38 gear units have no screw plug for checking the oil level.




Figure 10.2.1.1-2: Oil level check on size 38 gear unit

1) Switch off the power supply to the drive.

2) Demount the drive and set it up in accordance with figure 10.2.1.1-2 "Oil level check on size 38 gear unit". The screw plug, part 1, must be on the upward side.

3) Unscrew the plug, part 1.

- 4) Put a mark (a) on a suitable dipstick, part 2.
- 5) Insert the dipstick, part 2, vertically through the hole until the mark (a) is level with the surface of the gear unit.
- 6) Pull the dipstick, part 2, out vertically.
- 7) Measure the distance "x" on the dipstick, see figure 10.2.1.1–3 "Distance "x"".




Figure 10.2.1.1–3: Distance "x"

- 8) Compare value "x" with the value acc. to table 10.2.1.1 "Values for distance "x"".

| Type | max. distance "x" between oil level and marking on oil dipstick [mm] | | | | | |
|--------|---|---------------|---------------|---------------|---------------|---------------|
| | B3 | B6 | B7 | B8 | V5 | V6 |
| E.38 | 43 | 37 | 37 | 31 | 23 | 19 |
| Z.38 | 93 | 83 | 83 | 83 | 75 | 32 |
| D.38 | 89 | 82 | 82 | 82 | 52 | 35 |
| | B5 B14 | V1 V18 | V3 V19 | | | |
| EF.38 | 44 | 24 | 18 | | | |
| ZF.38 | 87 | 56 | 33 | | | |
| DF.38 | 81 | 31 | 26 | | | |
| | B3-00 H-01 | B8-00 H-02 | B7-00 H-03 | B6-00 H-04 | V5-00 H-05 | V6-00 H-06 |
| K.38 | 64 | 35 | 21 | 52 | 40 | 46 |
| | B5-01 H-01 | B5-03 H-02 | B5-02 H-03 | B5-00 H-04 | V1-00 H-05 | V3-00 H-06 |
| KF.38 | 66 | 40 | 20 | 54 | 45 | 50 |
| | B5-01 H-01 | B5-03 H-02 | B5-02 H-03 | B5-00 H-04 | V1-00 H-05 | V3-00 H-06 |
| FZ.38B | 137 | 152 | 137 | 137 | 87 | 73 |
| FD.38B | 110 | 147 | 132 | 132 | 110 | 65 |

Table 10.2.1.1: Values for distance "x"

- 9) Rectify the oil level, if necessary, see section 10.2.3 "Oil change", and check it again.
- 10) Check the condition of the sealing ring on the sealing element; if necessary, replace the sealing ring.
- 11) Seal the gear unit with the sealing element, part 1.
- 12) Mount the drive.

10.2.1.2 Checking the oil level by the oil sight glass (special version)

In the case of the oil sight glass the oil level must be in the middle of the sight glass.




Figure 10.2.1.2: Oil level in the oil sight glass

Rectify the oil level, if necessary, see section 10.2.3 "Oil change", and check it again.

10.2.1.3 Checking the oil level by the oil dipstick (special version)

Measure the oil level with the dipstick resting on the hole but not screwed in.

The oil level must be between the lower and upper (min. - max.) marks on the oil dipstick.

If the electric oil level monitoring system is used, the oil must be level with the upper (max.) mark on the oil dipstick.

Rectify the oil level, if necessary, see section 10.2.3 "Oil change", and check it again.

10.2.1.4 Checking the oil level sensor (special version)




Drives in ATEX version.

The oil level sensor indicates the oil level only when the gear unit is shut off.

Lower the oil level and fill it up again until the oil level sensor gives a switching signal. Observe the separate operating instructions for the oil level sensor.

10.2.2 Oil quality

- 1) Switch off the power supply to the drive.



- 2) Unscrew the sealing element at the point marked with this symbol, see section 3.5 "Mounting positions" and take a small sample of oil.
- 3) Check the condition of the sealing ring on the sealing element; if necessary, replace the sealing ring.
- 4) Seal the gear unit with the sealing element.
- 5) Signs of changes in the oil can be seen with the naked eye. Fresh oil is clear to the eye and has a typical smell and a specific product colour. Clouding or a flocculent appearance indicate water and/or contamination. A dark or black colour indicates residue, severe thermal decomposition or contamination. If you detect such abnormalities, the oil must be changed immediately.
- 6) Check the oil level.
- 7) Rectify the oil level, if necessary, see section 10.2.3 "Oil change", and check it again.

10.2.3 Oil change



Danger.

Secure the drive unit to prevent it from being started up unintentionally. Attach a warning notice to the start switch.



Danger.

Danger of scalding from the hot oil emerging.
Before starting any work wait until the oil has cooled down to 30 °C.



Danger.

Remove any oil spillage immediately with an oil-binding agent in compliance with environmental requirements.



Caution.

The oil quantity and the position of the sealing elements depend upon the assembly option, see section 3.5 "Mounting positions".



Note.

As a rule, mineral oil is used as lubricant. Synthetic oils with special properties are available optionally.

For data such as oil grade, oil viscosity and oil quantity required, refer to the rating plate, see section 3.2 "General technical data".

For oil compatibility refer to, see section 10.3 "Lubricants".



Note.

In case of double gear units every single unit is to be considered separately.



Note.

In case of ambient conditions deviating from the normal (high ambient temperatures, high relative humidity, aggressive ambient media), the intervals between changes should be shorter. In such cases contact the **FLENDER TÜBINGEN GMBH** customer service to determine the individual lubricant change intervals.

Draining the oil



Note.

The oil must be warm, as too cold oil will flow too sluggishly to drain properly. If necessary, allow gear unit to run for 15 - 30 minutes to warm up.

- 1) Switch off the power supply to the drive.



- 2) Unscrew the sealing element at the point marked with this symbol, see section 3.5 "Mounting positions".



- 3) Unscrew the sealing element at the point marked with this symbol, see section 3.5 "Mounting positions".

- 4) Place a sufficiently large, suitable receptacle under the oil drainage plug.



- 5) Unscrew the sealing element at the point marked with this symbol, see section 3.5 "Mounting positions" and completely drain off the oil into the receptacle.

- 6) Check the condition of the sealing ring on the sealing element; if necessary, replace the sealing ring.

- 7) Seal the gear unit with the sealing element.

Fill in oil



- 1) Unscrew the sealing element at the point marked with this symbol, see section 3.5 "Mounting positions".

- 2) Fill the gear unit with fresh oil, using a filter (max. mesh 25 μm). When refilling, use the same type of oil with the same viscosity.

- 3) Check the oil level.

- 4) Rectify the oil level, if necessary, see section 10.2.3 "Oil change", and check it again.

- 5) Check the condition of the sealing ring on the sealing element; if necessary, replace the sealing ring.

- 6) Seal the gear unit with the sealing element.

10.2.4 Replacing bearings



Drives in ATEX version.

The bearing life depends very much on the operating conditions. It is therefore very difficult to calculate it reliably. If the operating conditions are specified by the operator, the bearing life can be calculated and indicated on the rating plate. If no information is given, changes in the vibration and noise pattern can serve as an indication that an immediate bearing replacement is necessary.

10.2.5 Relubrication of the rolling bearings in drive units




Caution.

When relubricating, do not mix greases with different soap bases.

Relubricating the drive units is required from motor size 160 upwards.

The bearings have already been initially greased.

The standard lubricating grease used is a mineral-oil-based lithium-saponified grease of NLGI class 3, see table 10.3–2 "Rolling bearing greases".



Using a grease gun, inject the grease into the bearing point via the lubricating nipples provided. Inject 50 g grease per lubricating point, unless otherwise specified in the vicinity of the lubricating point.

Figure 10.2.5: Grease nipple

10.2.6 Change rolling bearing grease

The rolling bearings have been filled with a lithium-saponified rolling bearing grease at the factory.

Clean the bearing before filling it with fresh lubricant.

In the case of the bearings of the output shaft or intermediate shafts the grease quantity must fill 2/3 and in the case of bearings on the input side 1/3 of the space between the bearing bodies.

10.2.7 Seal check

Oil or grease escaping in small quantities (a few drops) from the shaft sealing ring must be regarded as normal during the running-in phase (24 hours running time).

If the quantities escaping are great or leakage continues after the running-in phase, the shaft sealing ring must be replaced to prevent consequential damage.

Because of its structure and function a shaft sealing ring is subject to natural wear. The service life depends on the operating conditions. It is recommended that the shaft sealing rings be included in the periodic maintenance and servicing work on the system.

10.2.8 Clean ventilation filter

Clean the ventilation filter, depending on the degree of soiling - at least every 6 months.

- 1) Unscrew the ventilation filter.
- 2) Flush out the ventilation filter with petroleum ether or a similar cleaning agent.
- 3) Blow the ventilation filter out with compressed air.
- 4) Seal the gear unit with the ventilation filter.

10.2.9 Clean drive



Drives in ATEX version.
Dust deposits prevent heat radiation and cause high housing temperatures.
Keep the drive free from dirt and dust.



Caution.
Do not use a high-pressure cleaning appliance to clean the drive.
Do not use tools with sharp edges.

Switch off the power supply to the drive before cleaning it.

10.2.10 Checking tightness of fastening bolts



Drives in ATEX version.
Loose parts can cause sparks through impact.
Entry of foreign bodies may cause sparks.



Note.
Damaged headless screws must be replaced with new screws of the same type and strength class.

- 1) Switch off the power supply to the drive.
- 2) Using a torque wrench, check that all fastening bolts are correctly tightened for torque, acc. to table 10.2.10 "Tightening torques T_A - fastening bolts".

| Thread size | Tightening torque T_A | |
|-------------|-------------------------|----------------|
| | Strength class | Strength class |
| | 8.8 [Nm] | 10.9 [Nm] |
| M 4 | 3 | 4 |
| M 5 | 6 | 9 |
| M 6 | 10 | 14 |
| M 8 | 25 | 35 |
| M 10 | 50 | 70 |
| M 12 | 90 | 120 |
| M 16 | 210 | 295 |
| M 20 | 450 | 580 |
| M 24 | 750 | 1000 |
| M 30 | 1500 | 2000 |
| M 36 | 2500 | 3600 |

Table 10.2.10: Tightening torques T_A - fastening bolts

10.2.11 Inspection of the drive

Routinely inspect the drive once a year in accordance with the possible criteria listed in section 9. "Faults, causes and remedy".

Check the drive in accordance with the criteria set out in section 2. "Safety instructions".

Touch up damaged paintwork carefully.

10.2.12 Carry out maintenance on slip coupling



Note.
Check the condition of the slip clutch initially after 500 operating hours and then at least once yearly and after every blockage of the machine.

If necessary, readjust the slip torque or replace the wearing parts (friction lining and bushes). Friction linings must always be replaced in pairs. We recommend replacing worn bushes in sets.

For this, please observe the relevant operating instructions for the clutch.

10.3 Lubricants



Danger.

The listed lubricants are not approved under USDA -H1 / -H2 (United States Department of Agriculture). They are not or only conditionally approved for use in the foodstuffs or pharmaceutical industry. If lubricants with USDA -H1 / -H2 approval are required, please contact the **FLENDER TÜBINGEN GMBH** customer service.



Caution.

When changing oil of the same type, the quantity of oil remaining in the gear unit should be kept as low as possible. Generally speaking, a small remaining quantity will cause no particular problems.

Gear oils of different types and manufacturers must not be mixed. If necessary, the manufacturer should confirm that the new oil is compatible with residues of the used oil.

If changing very different types of oil or oils with very different additives, always flush out the gear unit with the new oil. This applies particularly when changing from polyglycols (PG) to another gear oil or vice versa. Residues of used oil must be completely removed from the gear unit.



Caution.

Gear oils must never be mixed with other substances. Flushing with paraffin or other solvents is not permitted, as traces of these substances always remain inside the unit.



Caution.

If applications are outside the temperature ranges specified in the table 10.3–1 "Oils" likewise contact the **FLENDER TÜBINGEN GMBH** customer service with regard to the choice of oil.

If due to its mounting position or load the temperature of the gear unit rises above +80 °C, contact the **FLENDER TÜBINGEN GMBH** customer service with regard to the choice of a suitable synthetic lubricant.



Note.

The lubricants are not or are only conditionally biodegradable. If lubricants are required in accordance with these classifications, please contact the **FLENDER TÜBINGEN GMBH** customer service.



Note.

These recommendations are not a guarantee of the quality of the lubricant supplied by your supplier. Each lubricant manufacturer is responsible for the quality of his own product.

The oil selected for use in the gear unit must be of the viscosity (ISO VG class) stated on the rating plate. The viscosity class indicated applies for the contractually agreed operating conditions.

In the case of different operating conditions contact with **FLENDER TÜBINGEN GMBH** is required.

The lubricants suitable for use in the gear unit are listed in table 10.3–1 "Oils" and table 10.3–2 "Rolling bearing greases".

We are familiar with the composition of these lubricants and, as far as we are currently aware, they possess the properties acc. to state of the art with regard to load-bearing capacity, corrosion resistance (FZG-Test DIN 51354 = force level > 12), resistance to grey staining and compatibility with seals and interior paint coats which are necessary for the type of gear unit concerned.

We therefore advise our customers to select one of the lubricants listed in this table, taking into account the VG class specified on the nameplate.

If by agreement gear units are filled at the factory with special lubricants for the above mentioned special applications, this is shown on the rating plate, e.g.: CLP-H1 VG220 or CLP E VG220.

The guarantee specifications are valid only for the lubricants shown in these operating instructions.

Service life of the lubricants



Note.

If oil sump temperatures exceed +80 °C, the service life may also be lower than shown in figure 10.3 "Approximate values for oil-change intervals". The general rule is that an increase in temperature by 10 K will halve the service life.



Note.

In the case of rolling bearings with grease filling we recommend changing the grease filling as well when changing the oil.

With an oil sump temperature of +80 °C the following service life with adherence to the characteristics required by **FLENDER TÜBINGEN GMBH** is expected:

- 1) Mineral oil
Biologically degradable oil
Physiologically safe oil (USDA -H1 / -H2) 10 000 operating hours or 2 years
- 2) Synthetic oil (PG) 20 000 operating hours or 4 years




Figure 10.3: Approximate values for oil-change intervals

T Oil-bath steady-state temperature [°C]
I Oil-change interval in operating hours [h]

FLENDER TUBINGEN











| | Mineral oil | Synthetic oil (PG) / Polyglycol (PG) | |
|---|--|--------------------------------------|----------------------------------|
| Designation to DIN 51 502 | CLP ISO VG 220 | CLP PG ISO VG 220 | CLP PG ISO VG 460 |
| Gear-unit types | E., D./Z., K., F. | E., D./Z., K., F., C. | |
| Ambient temperatures | -10 °C ... +40 °C | -20 °C ... +50 °C | 0 °C ... +60 °C |
|  | CLP 220 S | | |
|  | Degol BG 220 | Degol GS 220 | Degol GS 460 |
|  | Energol GR-XP 220 | Energyn SG-XP 220 | Energyn SG-XP 460 |
|  | Alpha SP 220 Optigear BM 220 Tribol 1100/220 | Optiflex A 220 Tribol 800/220 | Optiflex A 460 Tribol 800/460 |
|  | Falcon CLP 220 | Polydea PGLP 220 | Polydea PGLP 460 |
|  | Spartan EP 220 | Glycolube 220 | Glycolube 460 |
|  | Renolin CLP 220 | Renolin PG 220 | Renolin PG 460 |
|  | Klüberoil GEM 1-220 | Syntheso D 220 EP | Syntheso D 460 EP |
|  | Mobilgear XMP 220 | | |
|  | Omala 220 | Tivela WB | Tivela SD |

Table 10.3-1: Oils



Note.

The service life of the grease is approx. 4.000 operating hours. It is based on a max. ambient temperature of +40 °C. The service life of the grease decreases by a factor of 0.7 for every 10 K rise in temperature.











| Lithium-saponified greases NLGI 3/2 | |
|---|-----------------------------------|
|  | Aralub HL3, HL2 |
|  | Energrease LS3, LS2 |
|  | Longtime PD2 TRIBOL 4020/220-2 |
|  | Glissando 30, 20 |
|  | Beacon 3 |
|  | Renolit FWA160, FWA220 |
|  | Centroplex GLP402 |
|  | Mobilux 3, 2 |
|  | Alvania RL3, RL2 |
|  | Wiolub LFK2 |

Table 10.3-2: Rolling bearing greases

100

11. Disposal

Dispose of the housing parts, gears, shafts and rolling bearings as steel scrap.

This also applies to grey cast iron parts, if no separate collection is made.

The worm wheels are made partly from non-ferrous metal. Dispose of them accordingly.



Danger.

Incorrect disposal of used oil is a threat to the environment and health.

After use the oil must be taken to a used oil collection point. Any addition of foreign material such as solvents and brake and cooling fluid is prohibited.

Avoid prolonged contact with the skin.

Collect and dispose of used oil in accordance with regulations.

Remove any oil spillage immediately with an oil-binding agent in compliance with environmental requirements.

12. Stocking spare parts and customer service addresses

12.1 Stocking spare parts

By stocking the most important spare and wearing parts on site you can ensure that the drive is ready for use at any time.



Caution.

Please note that spare parts and accessories not supplied by us have not been tested or approved by us.

The installation and/or use of such products may therefore impair essential characteristics of the drive, thereby posing an active or passive risk to safety.

FLENDER TÜBINGEN GMBH will assume no liability or guarantee for damage caused by spare parts and accessories not supplied by **FLENDER TÜBINGEN GMBH**.

We guarantee only the original spare parts supplied by us.


Please note that certain components often have special production and supply specifications and that we always supply you with spare parts which comply fully with the current state of technical development as well as current legislation.

When ordering spare parts, always state the following:

- Order no. (see rating plate **4**)
- Type designation (see rating plate **5**)
- Part no. (3-digit part no. from spare parts list, 6-digit code no. or 7-digit article no.)
- Quantity


12.2 Spare parts lists

12.2.1 One-stage helical gear units



- | | | |
|-----------------------|-------------------|---------------------|
| 001 Gear unit housing | 145 Locking ring | 225 Seal |
| 101 Output shaft | 160 Shaft seal | 301 Plug-in pinion |
| 103 Spacer/bush | 201 Adapter plate | 305 Gear wheel |
| 105 Parallel key | 205 Bolt | 335 Parallel key |
| 130 Bearings | 210 Bolt | 401 Screw plug |
| 135 Locking ring | 211 Screw lock | 420 Breather filter |
| 136 Locking ring | 220 Seal | 430 Eye bolt |
| 140 Bearings | | |

12.2.2 Two and three-stage helical gear units




- 001 Gear unit housing
- 020 Bearings
- 025 Locking ring
- 030 Bearings
- 050 Housing cover
- 051 Bolt
- 055 Seal
- 101 Output shaft
- 103 Spacer/bush
- 105 Parallel key
- 130 Bearings
- 135 Locking ring
- 140 Bearings

- 141 Supporting disk/shim
- 144 Supporting disk/shim
- 145 Locking ring
- 160 Shaft seal
- 201 Adapter plate
- 205 Bolt
- 210 Bolt
- 211 Screw lock
- 215 Parallel pin
- 220 Seal
- 225 Seal
- 301 Plug-in pinion
- 305 Gear wheel

- 306 Parallel key
- 315 Bearings
- 320 Bearings
- 325 Pinion shaft
- 330 Gear wheel
- 331 Parallel key
- 340 Pinion shaft
- 345 Gear wheel
- 346 Parallel key
- 401 Screw plug
- 420 Breather filter
- 430 Eye bolt


12.2.3 Bevel-helical gear units



- | | | |
|--------------------------|--------------------------|------------------------|
| 001 Gear unit housing | 095 Bolt | 301 Plug-in pinion |
| 020 Bearings | 096 Screw lock | 305 Gear wheel |
| 022 Supporting disk/shim | 101 Output shaft | 320 Bevel-gear pair |
| 027 Locking ring | 130 Bearings | 325 Bevel pinion shaft |
| 030 Bearings | 131 Supporting disk/shim | 327 Parallel key |
| 031 Supporting disk/shim | 133 Nilos ring | 328 Locking ring |
| 040 Output flange | 135 Locking ring | 331 Parallel key |
| 045 Bolt | 140 Bearings | 335 Locking ring |
| 050 Housing cover | 143 Nilos ring | 340 Pinion shaft |
| 051 Bolt | 144 Supporting disk/shim | 345 Gear wheel |
| 055 Seal | 146 Locking ring | 346 Parallel key |
| 060 Bearings | 160 Shaft seal | 351 Parallel key |
| 061 Supporting disk/shim | 201 Adapter plate | 401 Screw plug |
| 063 Nilos ring | 205 Bolt | 411 Bolt |
| 065 Locking ring | 210 Bolt | 413 Washer |
| 070 Sealing cap | 211 Screw lock | 415 Locking ring |
| 090 Torque arm | 220 Seal | 418 Plug/sealing cap |
| 091 Rubber bush | 225 Seal | 420 Breather filter |


105

12.2.4 Parallel shaft helical gear units



- | | | |
|--------------------------|--------------------------|--------------------------|
| 001 Gear unit housing | 109 Locking ring | 210 Bolt |
| 020 Bearings | 110 Locking ring | 211 Screw lock |
| 021 Supporting disk/shim | 120 Shrink disc | 220 Seal |
| 022 Supporting disk/shim | 128 Supporting disk/shim | 225 Seal |
| 025 Locking ring | 129 Supporting disk/shim | 301 Pinion |
| 030 Bearings | 130 Bearings | 305 Gear wheel |
| 034 Nilos ring | 131 Supporting disk/shim | 306 Parallel key |
| 040 Output flange | 132 Spacer/bush | 307 Spacer/bush |
| 045 Bolt | 133 Nilos ring | 310 Locking ring |
| 050 Housing cover | 135 Locking ring | 311 Supporting disk/shim |
| 051 Bolt | 140 Bearings | 325 Pinion shaft |
| 055 Seal | 141 Spacer/bush | 330 Gear wheel |
| 065 Sealing cap | 143 Nilos ring | 331 Parallel key |
| 070 Sealing cap | 144 Supporting disk/shim | 340 Pinion shaft |
| 091 Rubber bush | 146 Locking ring | 345 Gear wheel |
| 101 Drive shaft | 160 Shaft seal | 346 Parallel key |
| 107 Bearings | 201 Adapter plate | 401 Screw plug |
| 108 Bearings | 205 Bolt | 420 Breather filter |

12.2.5 Helical worm gear units



| | | |
|--------------------------|----------------------|----------------------|
| 001 Gear unit housing | 333 Nilos ring | 305 Gear wheel |
| 020 Bearings | 335 Locking ring | 311 Parallel key |
| 030 Bearings | 340 Worm shaft | 345 Worm wheel |
| 032 Supporting disk/shim | 345 Worm wheel | 346 Parallel key |
| 035 Locking ring | 401 Screw plug | 411 Bolt |
| 037 Locking ring | 411 Bolt | 412 Screw lock |
| 040 Output flange | 412 Screw lock | 413 Washer |
| 045 Bolt | 413 Washer | 415 Locking ring |
| 070 Sealing cap | 415 Locking ring | 418 Plug/sealing cap |
| 090 Torque arm | 418 Plug/sealing cap | 420 Breather filter |
| 091 Rubber bush | 420 Breather filter | 430 Eye bolt |
| 095 Bolt | 430 Eye bolt | |
| 101 Output shaft | | |
| 130 Bearings | | |
| 131 Supporting disk/shim | | |

12.3 Customer-service addresses

FLENDER TÜBINGEN GMBH Germany

FLENDER TÜBINGEN GMBH Postfach 1709 · D-72007 Tübingen
Bahnhofstr. 40-44 · D-72072 Tübingen
Telefon +49 (0) 70 71 - 707 0
Fax +49 (0) 70 71 - 707 400
E-mail: sales-motox@flender-motox.com
<http://www.flender.com>
24 h Service Hotline +49 (0) 172 - 7 32 29 55

Vertriebszentrum Bocholt D-46393 Bocholt
Alfred-Flender-Str. 77, D-46395 Bocholt
Tel. +49 (0) 2871 - 92 0
Fax +49 (0) 2871 - 92 14 35
E-mail: vz.bocholt@flender.com

Vertriebszentrum Stuttgart D-70472 Stuttgart
Friedlzheimer Str. 3 · D-70499 Stuttgart
Tel. +49 (0) 7 11 - 7 80 54 51
Fax +49 (0) 7 11 - 7 80 54 50
E-mail: vz.stuttgart@flender.com

Vertriebszentrum München D-85750 Karlsfeld
Liebigstr. 14 · D-85757 Karlsfeld
Tel. +49 (0) 81 31 - 90 03 0
Fax +49 (0) 81 31 - 90 03 33
E-mail: vz.muenchen@flender.com

Vertriebszentrum Berlin Schlossallee 8 · D-13156 Berlin
Tel. +49 (0) 30 - 91 42 50 58
Fax +49 (0) 30 - 47 48 79 30
E-mail: vz.berlin@flender.com

FLENDER TÜBINGEN GMBH Europe**ALBANIA / MACEDONIA /
SERBIA-MONTENEGRO**

A. Friedr. Flender AG
Branch Office
c/o G.P. Inzenjering d.o.o.
III Bulevar 54 / 19
YU - 11070 Novi Beograd
Tel. +381 (0) 11 - 60 44 73
Fax +381 (0) 11 - 3 11 67 91
E-mail: flender@eunet.yu

AUSTRIA

Flender Ges.m.b.H.
Industriezentrum N6-Süd
Str. 4, Objekt 14, Postfach 132
AT - 2355 Wiener Neudorf
Tel. +43 (0) 22 36 - 6 45 70
Fax +43 (0) 22 36 - 6 45 70 10
E-mail: office@flender.at
http://www.flender.at

BELGIUM & LUXEMBOURG

N.V. Flender Belge S.A.
Cyriel Buyssestraat 130
BE - 1800 Vilvoorde
Tel. +32 (0) 2 - 2 53 10 30
Fax +32 (0) 2 - 2 53 09 66
E-mail: sales@flender.be

**BOSNIA-HERZEGOVINA / CROATIA /
SLOVENIA**

A. Friedr. Flender AG
Branch Office,
c/o HUM - Naklada d.o.o.
Mandroviceva 3
HR - 10000 Zagreb
Tel. +385 (0) 1 - 2 30 60 25
Fax +385 (0) 1 - 2 30 60 24
E-mail: flender@hi.hinet.hr

BULGARIA

A. Friedr. Flender AG
Branch Office
c/o Auto - Profi GmbH
Alabin Str. 52, 1000 Sofia
Tel. +359 (0) 2 - 9 80 66 06
Fax +359 (0) 2 - 9 80 33 01
E-mail: flender@auto-profi.com

CZECH REPUBLIC

A. Friedr. Flender AG
Branch Office
Hotel DUO, Teplická 17
CZ - 19000 Praha 9
Tel. +420 2 - 83 88 23 00
Fax +420 2 - 83 88 22 05
E-mail: flender_pumpria@hotelduo.cz

DENMARK

Flender Scandinavia A/S
Rugmarken 35 B
DK - 3520 Farum
Tel. +45 (0) 70 22 60 03
Fax +45 (0) 44 99 16 62
E-mail: kontakt@flenderscandinavia.com
http://www.flenderscandinavia.com

ESTHONIA / LATVIA / LITHUANIA

Flender Branch Office
Addinol Minerali Marketing OÜ
Suur-Sõjamäe 32
EE - 11415 Tallinn / Esthonia
Tel. +372 (0) 6 - 27 99 99
Fax +372 (0) 6 - 27 99 90
E-mail: flender@addinol.ee
http://www.addinol.ee

FINLAND

Flender Oy
Ruosilantie 2 B
FI - 00390 Helsinki
Tel. +358 (0) 9 - 4 77 84 10
Fax +358 (0) 9 - 4 36 14 10
E-mail: webmaster@flender.fi
http://www.flender.fi

FRANCE

Flender S.a.r.l.
3, rue Jean Monnet - B.P. 5
FR - 78996 Elancourt Cedex
Tel. +33 (0) 1 - 30 66 39 00
Fax +33 (0) 1 - 30 66 35 13
E-mail: sales@flender.fr

SALES OFFICES:

Flender S.a.r.l.
Agence de Lyon
Parc Inopolis
Route de Vourles
FR - 69230 Saint Genis Laval
Tel. +33 (0) 4 - 72 83 95 20
Fax +33 (0) 4 - 72 83 95 39
E-mail: sales@flender.fr

Flender Graffenstaden SA
1, rue du Vieux Moulin
FR - 67400 Illkirch-Graffenstaden
B.P. 84
FR - 67402 Illkirch-Graffenstaden
Tel. +33 (0) 3 - 88 67 60 00
Fax +33 (0) 3 - 88 67 06 17
E-mail: flencomm@flender-graff.com

GREECE

Flender Hellas Ltd.
2, Delfon str.
GR - 11146 Athens
Tel. +30 210 - 2 91 72 80
Fax +30 210 - 2 91 71 02
E-mail: flender@otenet.gr

HUNGARY

A. Friedr. Flender AG
Branch Office
Bécsi Út 3-5
HU - 1023 Budapest
Tel. +36 (0) 1 - 3 45 07 90
Fax +36 (0) 1 - 3 45 07 92
E-mail: jambor.leszlo@axelero.hu

ITALY

Flender Cigala S.p.A.
Parco Tecnologico Manzoni, Palazzina G
Viale delle industrie, 17
IT - 20040 Caponago (MI)
Tel. +39 (0) 02 - 95 96 31
Fax +39 (0) 02 - 95 74 39 30
E-mail: info@flendercigala.it

THE NETHERLANDS

Flender Nederland B.V.
Lage Brink 5-7
NL - 7317 BD Apeldoorn
Postbus 1073
NL - 7301 BH Apeldoorn
Tel. +31 (0) 55 - 5 27 50 00
Fax +31 (0) 55 - 5 21 80 11
E-mail: sales@flender.nl

Bruinhof B.V.

Boterdiep 37
NL - 3077 AW Rotterdam
Postbus 9607
NL - 3007 AP Rotterdam
Tel. +31 (0) 10 - 4 97 08 08
Fax +31 (0) 10 - 4 82 43 50
E-mail: info@bruinhof.nl
http://www.bruinhof.nl

NORWAY

Please refer to
Flender Scandinavia A/S
Rugmarken 35 B
3520 Farum
Tel. +45 (0) 70 22 60 03
Fax +45 (0) 44 99 16 62
E-mail: kontakt@flenderscandinavia.com
http://www.flenderscandinavia.com

POLAND

A. Friedr. Flender AG
Branch Office
Przedstawicielstwo w Polsce ul. Wyzwolenia 27
PL - 43 - 190 Mikołów
Tel. +48 (0) 32 - 2 26 45 61
Fax +48 (0) 32 - 2 26 45 62
E-mail: flender@pro.onet.pl
http://www.flender.pl

PORTUGAL

Rodamientos FEYC, S. A.
R. Jaime Lopes Dias, 1668 CV
PT - 1750 - 124 Lissabon
Tel. +351 (0) 21 - 7 54 24 10
Fax +351 (0) 21 - 7 54 24 19
E-mail: info@rportugal.com

ROMANIA

A. Friedr. Flender AG
Branch Office
B-dul Garii Obor Nr. 8D
Sector 2 - Bucuresti
Tel. +40 (0) 21 - 2 53 21 28
Fax +40 (0) 21 - 2 52 98 60
E-mail: office@flender.ro

RUSSIA

F & F GmbH
Tjuschina 4-6
RU - 191119 St. Petersburg
Tel. +7 (0) 8 12 - 3 20 90 34
Fax +7 (0) 8 12 - 3 40 27 60
E-mail: flendergus@mail.spbnit.ru

SLOVAKIA

A. Friedr. Flender AG
Branch Office
Vajanského 49, P.O. Box 286
SK - 08001 Presov
Tel. +421 (0) 51 - 7 70 32 67
Fax +421 (0) 51 - 7 70 32 67
E-mail: micenko.flender@nexta.sk

SPAIN

Flender Ibérica S.A.
Poligono Industrial San Marcos
Calle Morse, 31 (Parcela D-15)
ES - 28906 Getate, Madrid
Tel. +34 (0) 91 - 6 83 61 86
Fax +34 (0) 91 - 6 83 46 50
E-mail: f-iberica@flender.es
http://www.flender.es

SWEDEN

Flender Scandinavia
Åsenvägen 2
44339 Lerum
Tel. +46 (0) 302 - 1 25 90
Fax +46 (0) 302 - 1 25 56
E-mail: kontakt@flenderscandinavia.com
http://www.flenderscandinavia.com

SWITZERLAND

Flender AG
Zeughausstr. 48
CH - 5600 Lenzburg
Tel. +41 (0) 62 - 8 85 76 00
Fax +41 (0) 62 - 8 85 76 76
E-mail: info@flender.ch
http://www.flender.ch

TURKEY

Flender Güc Aktarma Sistemleri
Sanayi ve Ticaret Ltd. Sti.
IMES Sanayi Sitesi, E Blok 502, Sokak No. 22
TR - 81260 Dudullu - Istanbul
Tel. +90 (0) 2 16 - 4 66 61 41
Fax +90 (0) 2 16 - 3 64 59 13
E-mail: cuzkan@flendertr.com
http://www.flendertr.com

UKRAINE

A. Friedr. Flender AG
Branch Office
c/o DIV - Deutsche Industrievertretung
Prospect Pobedy 44
UA - 252057 Kiev
Tel. +380 (0) 44 - 4 46 80 49
Fax +380 (0) 44 - 2 30 29 30
E-mail: flender@div.kiev.ua

UNITED KINGDOM & IRE

Flender Power Transmission Ltd.
Thornbury Works, Leeds Road
GB - Bradford, West Yorkshire BD3 7 EB
Tel. +44 (0) 12 74 - 65 77 00
Fax +44 (0) 12 74 - 66 98 36
E-mail: flenders@flender-power.co.uk
http://www.flender-power.co.uk

FLENDER TÜBINGEN GMBH International

AFRICA

EGYPT

Sons of Farid Hassanen
81 Matbaa Ahlia Street
EG - Boulak 11221, Cairo
Tel. +20 (0) 2 - 5 75 15 44
Fax +20 (0) 2 - 5 75 17 02
E-mail: hussein@sonfarid.com

NORTH AFRICAN COUNTRIES

Please refer to Flender s.a.r.l.
3, rue Jean Monnet - B.P. 5
FR - 78996 Elancourt Cedex
Tel. +33 (0) 1 - 30 66 39 00
Fax +33 (0) 1 - 30 66 35 13
E-mail: sales@flender.fr

SOUTH AFRICA

Flender Power Transmission (Pty.) Ltd.
Cnr. Furnace St & Quality Road
P.O. Box 131
ZA - Isando 1600 Johannesburg
Tel. +27 (0) 11 - 5 71 20 00
Fax +27 (0) 11 - 5 92 24 34
E-mail: sales@flender.co.za
http://www.flender.co.za

SALES OFFICES:

Flender Power Transmission (Pty.) Ltd.
Unit 3 Marconi Park
9 Marconi Crescent, Montague Gardens
P.O. Box 3729
Chempet 7442, Cape Town
Tel. +27 (0) 21 - 5 51 50 03
Fax +27 (0) 21 - 5 52 38 24
E-mail: sales@flender.co.za

Flender Power Transmission (Pty.) Ltd.
Unit 3 Goshawk Park
Falcon Industrial Estate
P.O. Box 1608
ZA - New Germany 3620, Durban
Tel. +27 (0) 31 - 7 05 38 92
Fax +27 (0) 31 - 7 05 38 72
E-mail: sales@flender.co.za

Flender Power Transmission (Pty.) Ltd.
9 Industrial Crescent, Ext. 25
P.O. Box 17609
ZA - Witbank 1035
Tel. +27 (0) 13 - 6 92 34 38
Fax +27 (0) 13 - 6 92 34 52
E-mail: sales@flender.co.za

Flender Power Transmission (Pty.) Ltd.
Unit 14 King Fisher Park, Alton
Cnr. Ceramic Curve & Alumina Allee
P.O. Box 101995
ZA - Meerensee 3901, Richards Bay
Tel. +27 (0) 35 - 7 51 15 63
Fax +27 (0) 35 - 7 51 15 64
E-mail: sales@flender.co.za

AMERICA

ARGENTINA

Chilicote S.A.
Avda. Julio A. Roca 546
C 1067 ABN Buenos Aires
Tel. +54 (0) 11 - 43 31 66 10
Fax +54 (0) 11 - 43 31 42 78
E-mail: chilicote@chilicote.com.ar

ARGENTINA / BOLIVIA / CHILE / ECUADOR /

PARAGUAY / URUGUAY

Flender Cono Sur Limitada
Avda. Galvarino Gallardo 1534
Providencia, CL - Santiago
Tel. +56 (0) 2 - 2 35 32 49
Fax +56 (0) 2 - 2 64 20 25
E-mail: flender@flender.cl
http://www.flender.cl

BRASIL

Flender Brasil Ltda.
Rua Quatorze, 60 - Cidade Industrial
32211-970, Contagem - MG
Tel. +55 (0) 31 - 33 69 21 00
Fax +55 (0) 31 - 33 69 21 66
E-mail: vendas@flenderbrasil.com

SALES OFFICES:

Flender Brasil Ltda.
Rua James Watt, 142 - conj. 142 - Brooklin Novo
04576-050, - São Paulo - SP
Tel. +55 (0) 11 - 55 05 99 33
Fax +55 (0) 11 - 55 05 30 10
E-mail: fliessao@uol.com.br

Flender Brasil Ltda.
Rua Campos Salles, 1095 - sala 04 - Centro
14015-110 - Ribeirão Preto - SP
Tel. +55 (0) 16 - 6 35 15 90
Fax +55 (0) 16 - 6 35 11 05
E-mail: flender.ripreto@uol.com.br

CANADA

Flender Power Transmission Inc.
215 Shields Court, Units 4-6
CA - Markham, Ontario L3R 8V2
Tel. +1 (0) 9 05 - 3 05 10 21
Fax +1 (0) 9 05 - 3 05 10 23
E-mail: info@flenderpti.com
http://www.flender.ca

CHILE

Sergent S.A.
Av. Pde. Bulnes 205, Casilla 166 D
CL - Santiago
Tel. +56 (0) 2 - 6 99 15 25
Fax +56 (0) 2 - 6 98 39 89
E-mail: sevcentas@sargentagricola.cl

COLOMBIA

A.G.P. Representaciones Ltda.
Flender Liaison Office Colombia
Av Boyaca No 23A, 50 Bodega UA 7-1
CO - Bogotá
Tel. +57 (0) 1 - 5 70 63 53
Fax +57 (0) 1 - 5 70 73 35
E-mail: aguerrero@agp.com.co
http://www.agp.com.co

MEXICO

Flender de Mexico S.A. de C.V.
17, Pte, 713 Centro
MX - 72000 Puebla
Tel. +52 (0) 2 22 - 2 37 19 00
Fax +52 (0) 2 22 - 2 37 11 33
E-mail: szugasti@flendermexico.com
http://www.flendermexico.com

SALES OFFICES:

Flender de Mexico S.A. de C.V.
Lago Nargis No. 38, Col. Granada
MX - 11520, Mexico, D.F.
Tel. +52 (0) 55 - 52 54 30 37
Fax +52 (0) 55 - 55 31 69 39
E-mail: info@flendermexico.com

Flender de Mexico S.A. de C.V.
Ave. San Pedro No. 231-5, Col. Miravalle
MX - 64660, Monterrey, N.L.
Tel. +52 (0) 81 - 83 63 82 82
Fax +52 (0) 81 - 83 63 82 83
E-mail: info@flendermexico.com

PERU

Potencia Industrial E.I.R.L.
Calle Gonzales Olaechea
110-URB, La Aurora
Miraflores - Lima
Tel. +51 (0) 1 - 2 42 84 68
Fax +51 (0) 1 - 2 42 08 62
E-mail: cesarzam@potenciaindustrial.com.pe
http://www.potenciaindustrial.com.pe

USA

Flender Corporation
950 Tollgate Road
P.O. Box 1449
US - Elgin, IL. 60123
Tel. +1 (0) 8 47 - 9 31 19 90
Fax +1 (0) 8 47 - 9 31 07 11
E-mail: flender@flenderusa.com
http://www.flenderusa.com

Flender Corporation
Service Centers West
4234 Foster Ave.
US - Bakersfield, CA. 93308
Tel. +1 (0) 6 61 - 3 25 44 78
Fax +1 (0) 6 61 - 3 25 44 70
E-mail: flender1@lightspeed.net

VENEZUELA

F. H. Transmisiones S.A.
Urbanización Buena Vista
Calle Johan Schafer o Segunda Calle
Municipio Sucre, Petare
VE - Caracas
Tel. +58 (0) 2 12 - 21 52 61
Fax +58 (0) 2 12 - 21 18 38
E-mail: fhtransm@telcel.net.ve
http://www.fhtransmisiones.com

ASIA

BAHRAIN / IRAQ / JORDAN / LYBIA / OMAN /

QATAR / U.A.E. / YEMEN

Please refer to A. Friedr. Flender AG
Middle East Sales Office
IMES Sanayi, Sitesi, E Blok 502, Sokak No. 22
TR - 81260 Dudullu - Istanbul
Tel. +90 (0) 2 16 - 4 99 66 23
Fax +90 (0) 2 16 - 3 64 59 13
E-mail: meso@flendertr.com

BANGLADESH / SRI LANKA

Please refer to Flender Limited
No. 2 St. George's Gate Road, 5 th Floor, Hastings
Kolkata - 700022
Tel. +91 (0) 33 - 22 23 05 45
Fax +91 (0) 33 - 22 23 08 30
E-mail: flender@flenderindia.com

INDIA

Flender Limited, Head Office
No. 2 St. George's Gate Road, 5 th Floor, Hastings
Kolkata - 700022
Tel. +91 (0) 33 - 22 23 05 45
Fax +91 (0) 33 - 22 23 08 30
E-mail: flender@flenderindia.com

Flender Limited

Industrial Growth Centre
Rakhajungle, Nimpura
Kharagpur - 721302
Tel. +91 (0) 32 22 - 23 33 07
Fax +91 (0) 32 22 - 23 33 64
E-mail: works@flenderindia.com

SALES OFFICES:

No. 2 St. George's Gate Road, 5 th Floor, Hastings
Kolkata - 700022
Tel. +91 (0) 33 - 22 23 05 45
Fax +91 (0) 33 - 22 23 08 30
E-mail: ero@flenderindia.com

Flender Limited

Western Regional Sales Office
Plot No. 23, Sector 19 - C, Vashi
Navi Mumbai - 400705
Tel. +91 (0) 22 - 27 65 72 27
Fax +91 (0) 22 - 27 65 72 28
E-mail: wro@flenderindia.com

Flender Limited

Southern Regional Sales Office
41 Nelson Manickam Road, Aminjikarai
Chennai - 600029
Tel. +91 (0) 44 - 23 74 39 21
Fax +91 (0) 44 - 23 74 39 19
E-mail: sro@flenderindia.com

Flender Limited

Northern Regional Sales Office
302 Bhikaji Cama Bhawan
11 Bhika Ji Cama Place
New Delhi - 110066
Tel. +91 (0) 11 - 51 85 96 56 / 57 / 58
Fax +91 (0) 11 - 51 85 96 59
E-mail: nro@flenderindia.com

INDONESIA

Flender Singapore Pte. Ltd. Representative Office
06 - 01 Wisma Presisi
Taman Aries Blok A1 No.1
Jakarta Barat 11620
Tel. +62 (0) 21 - 58 90 20 15
Fax +62 (0) 21 - 58 90 20 19
E-mail: bobwall@cbn.net.id

IRAN

Cimaghand Co. Ltd.
No. 13, 16th East Street, P.O. Box 15745-493
Beyhaghi Ave., Argentina Sq., IR - Tehran 15156
Tel. +98 (0) 21 - 8 73 02 14
Fax +98 (0) 21 - 8 73 39 70
E-mail: info@cimaghand.com

ISRAEL

Greenshpon Engineering Works Ltd.
Bar-Lev Industrial Park
Misgav 20179 - Israel
Tel. +972 (0) 4 - 9 91 31 81
Fax +972 (0) 4 - 9 91 34 77
E-mail: sales@greenshpon.com
http://www.greenshpon.com

JAPAN

Flender Japan Co. Ltd.
WBG Marive East 21 F
Nakase 2 - 6, Mihama-ku, Chiba-shi
Chiba 261 - 7121
Tel. +81 (0) 43 - 2 13 39 30
Fax +81 (0) 43 - 2 13 39 55
E-mail: contact@flender-japan.com

KAZAKHSTAN

A. Friedr. Flender AG
Branch Office
Abay ave 143
480009 Almaty
Tel. +7 (0) 32 72 43 39 54
Fax +7 (0) 32 72 77 90 82
E-mail: grabarse@kazgate.de

KOREA

Flender Ltd.
7th Fl. Dorim Bldg., 1823 Bangbae-Dong
Seocho-Ku, KR - Seoul 137-060
Tel. +82 (0) 2 - 34 78 63 37
Fax +82 (0) 2 - 34 78 63 45
E-mail: sales@flender-korea.com
http://www.flender-korea.com

KUWAIT

South Gulf Company
Al-Shoaiikh Ind. Area
P.O. Box 26229, KW - Safat 13123
Tel. +965 (0) - 4 82 97 15
Fax +965 (0) - 4 82 97 20
E-mail: adelameen@awalnet.net.sa

LEBANON

Gabriel Acar & Fils s.a.r.l.
Dahr-el-Jamal
Zone Industrielle, Sin-el-Fil
B.P. 80484, Beyrouth
Tel. +961 (0) 1 - 49 82 72
Fax +961 (0) 1 - 49 49 71
E-mail: gacar@beirut.com

MALAYSIA

Flender Singapor Pte. Ltd., Representative Office
37 A - 2, Jalan PJU 1/39, Dataran Prima
MY - 47301 Petaling Jaya, Selangor Darul Ehsan
Tel. +60 (0) 3 - 78 80 42 63
Fax +60 (0) 3 - 78 80 42 73
E-mail: flender@tm.net.my

PAKISTAN

Please refer to A. Friedr. Flender AG
D - 46393 Bocholt
Tel. +49 (0) 28 71 - 92 22 59
Fax +49 (0) 28 71 - 92 15 16
E-mail: ludger.wittag@flender.com

PEOPLE'S REPUBLIC OF CHINA

Flender Power Transmission (Tianjin) Co., Ltd.
Shuang Hu Rd.-Shuangchen, Rd. West, Beichen
Economic
Development Area (BEDA)
CN - Tianjin - 300400
Tel. +86 (0) 22 - 26 97 20 63
Fax +86 (0) 22 - 26 97 20 61
E-mail: flender@flendertj.com
http://www.flendertj.com

Flender Power Transmission (Tianjin) Co., Ltd.
Beijing Office
C-415, Lufthansa Center
50 Liangmaqiao Road, Chaoyang District
CN - Beijing - 100 016
Tel. +86 (0) 10 - 64 62 21 51
Fax +86 (0) 10 - 64 62 21 43
E-mail: beijing@flenderprc.com.cn

Flender Power Transmission (Tianjin) Co., Ltd.
Shanghai Office
Unit 1101 - 1102, Harbour Ring Plaza
No. 18 Xizang Zhong Road
CN - Shanghai - 200001
Tel. +86 (0) 21 - 53 85 31 48
Fax +86 (0) 21 - 53 85 31 46
E-mail: shanghai@flenderprc.com.cn

Flender Power Transmission (Tianjin) Co., Ltd.
Wuhan Office
Room 1503, Jianyin Building
709 Jianshedadao
CN - Wuhan - 430015
Tel. +86 (0) 27 - 85 48 67 15
Fax +86 (0) 27 - 85 48 68 36
E-mail: wuhan@flenderprc.com.cn

Flender Power Transmission (Tianjin) Co., Ltd.
Guangzhou Office
Rm 2802, Guangzhou International, Electronics
Tower
403 Huanshi Road East
CN - Guangzhou - 510095
Tel. +86 (0) 20 - 87 32 60 42
Fax +86 (0) 20 - 87 32 60 45
E-mail: guangzhou@flenderprc.com.cn

Flender Power Transmission (Tianjin) Co., Ltd.
Chengdu Office
G-6 / F, Guoxin Mansion, 77 Xiyu Street
CN - Chengdu - 610015
Tel. +86 (0) 28 - 86 19 83 72
Fax +86 (0) 28 - 86 19 88 10
E-mail: chengdu@flenderprc.com.cn

Flender Power Transmission (Tianjin) Co., Ltd.
Shenyang Office
Rm. 2-163, Tower I, City Plaza, Shenyang
206 Nanjing Street (N), Heping District
Shenyang 110001
Tel. +86 (0) 24 - 23 34 20 48
Fax +86 (0) 24 - 23 34 20 46
E-mail: shenyang@flenderprc.com.cn

Flender Power Transmission (Tianjin) Co., Ltd.
Xi'an Office
Rm. 302, Shanzi Zhong Da,
International Mansion, 30 Southern Road
Xi'an 710002
Tel. +86 (0) 29 - 7 20 32 68
Fax +86 (0) 29 - 7 20 32 04
E-mail: xian@flenderprc.com.cn

PHILIPPINE

Flender Singapore Pte. Ltd. Representative Office
28/F, Unit 2814, The Enterprise Centre
6766 Ayala Avenue corner
Paeso de Roxas, Makati City
Tel. +63 (0) 2 - 8 49 39 93
Fax +63 (0) 2 - 8 49 39 17
E-mail: roman@flender.com.ph

SAUDI ARABIA

South Gulf Sands Est.
Bandaria Area, Dohan Bldg.,
Flat 3/1
P.O. Box 32150
Al-Khobar 31952
Tel. +966 (0) 3 - 8 87 53 32
Fax +966 (0) 3 - 8 87 53 31
E-mail: adelameen@awalnet.net.sa

SINGAPORE

Flender Singapore Pte. Ltd. Representative Office
06-01 Wisma Presisi
Taman Aries Blok A1 No. 1
Jakarta Barat 11620
Tel. +62 (0) 21 - 58 90 20 15/16/17
Fax +62 (0) 21 - 58 90 20 19
E-mail: bobwall@cbn.net.id

SYRIA

Misrabi Co & Trading, Mezzeh Autostrade
Transportation
Building 4/A, 5th Floor
P.O. Box 12450, SY - Damascus
Tel. +963 (0) 11 - 6 11 67 94
Fax +963 (0) 11 - 6 11 09 08
E-mail: ismael.misrabi@gmx.net

TAIWAN

A. Friedr. Flender AG, Taiwan Branch Company
1 F, No. 5, Lane 240, Nan Yang Street, Hsichih
TW - Taipei Hsien 221
Tel. +886 (0) 2 - 26 93 24 41
Fax +886 (0) 2 - 26 94 36 11
E-mail: flender_tw@flender.com.tw

THAILAND

Flender Singapore Pte. Ltd. Representative Office
23/F M Thai Tower, All Seasons Place
87 Wireless Road, Phatumwan
TH - Bangkok 10330
Tel. +66 (0) 2 - 6 27 91 09
Fax +66 (0) 2 - 6 27 90 01
E-mail: christian.beckers@flender.th.com

VIETNAM

Flender Singapore Pte. Ltd. Representative Office
Suite 6/A, 16F Saigon Tower, 29 Le Duan Street,
District 1
Ho Chi Minh City, VN - Vietnam
Tel. +84 (0) 8 - 8 23 62 97
Fax +84 (0) 8 - 8 23 62 88
E-mail: flender_vn@flender.com.vn

AUSTRALIA

AUSTRALIA
Flender (Australia) Pty. Ltd.
9 Nello Place, P.O. Box 6047, Whetherill Park
N.S.W. 2164, AU - Sydney
Tel. +61 (0) 2 - 97 56 23 22
Fax +61 (0) 2 - 97 56 48 92
E-mail: sales@flender.com.au
http://www.flender.com.au

SALES OFFICES:

Flender (Australia) Pty. Ltd.
Suite 3, 261 Centre Rd.
AU - Bentleigh, VIC, 3204
Melbourne
Tel. +61 (0) 3 - 95 57 08 11
Fax +61 (0) 3 - 95 57 08 22
E-mail: sales@flender.com.au

Flender (Australia) Pty. Ltd.
Suite 5 - 1407 Logan Rd.
Mt. Gravatt
AU - QLD 4122, Brisbane
Tel. +61 (0) 7 - 34 22 23 89
Fax +61 (0) 7 - 34 22 24 03
E-mail: sales@flender.com.au

Flender (Australia) Pty. Ltd.
Suite 2, 403 Great Eastern Highway
AU - W.A. 6104, Redcliffe - Perth
Tel. +61 (0) 8 - 94 77 41 66
Fax +61 (0) 8 - 94 77 65 11
E-mail: sales@flender.com.au

NEW ZEALAND

Please refer to Flender (Australia) Pty. Ltd.
9 Nello Place, P.O. Box 6047, Whetherill Park
N.S.W. 2164, AU - Sydney
Tel. +61 (0) 2 - 97 56 23 22
Fax +61 (0) 2 - 97 56 48 92
E-mail: sales@flender.com.au

13. Declaration by the manufacturer, Declaration of Conformity

13.1 Declaration by the manufacturer

in accordance with EC Engineering Guideline 98/37/EC, Appendix II B

We hereby declare that the

Single-stage helical gear units and gear motors of the types

| | | |
|-------------|--------------|--------------|
| E.38 | E.88 | E.148 |
| E.48 | E.108 | |
| E.68 | E.128 | |

Two- and three-stage helical gear units and gear motor of the types

| | | |
|----------------|-----------------|-----------------|
| D./Z.38 | D./Z.88 | D./Z.148 |
| D./Z.48 | D./Z.108 | D./Z.168 |
| D./Z.68 | D./Z.128 | D./Z.188 |

Bevel-helical gear units and gear motors of the types

| | | |
|-------------|--------------|--------------|
| K.38 | K.88 | K.148 |
| K.48 | K.108 | K.168 |
| K.68 | K.128 | K.188 |

Parallel-shaft helical gear units and gear motors of the types

| | | |
|--------------|---------------|---------------|
| F.38B | F.88B | F.148B |
| F.48B | F.108B | F.168B |
| F.68B | F.128B | F.188B |

Helical worm gear units and gear motors of the types

| | |
|-------------|-------------|
| C.38 | C.68 |
| C.48 | C.88 |

described in these operating instructions are intended for incorporation in a machine, and that it is prohibited to put them into service before verifying that the machine into which they are incorporated complies with the EC Guidelines 98/37/EC.

This Manufacturer's Declaration takes into account all the unified standards applying to our products in part or in whole published by the European Commission in the Official Journal of the European Community.

These include in particular:

- EN 292-1
- EN 292-2
- EEN 294
- EEN 349
- EN 60204-1

Tübingen, 03.05.2004


(p.p. Head of Gear Unit Development)

13.2 EC Declaration of Conformity

Document No. KE GKFSN298 DE / 07.03

Equipment designation: MOTOX[®]-N Gear-unit series
Type: E, Z, D, K, F, C
Sizes: 38 - 188
Add-on subassemblies: A, P, K

The designated equipment conforms to the requirements of the explosion protection guideline 94/9/EC. It has been developed and manufactured in conformity to the following European standards:

- EN 1050/1996
- pr EN 13463-5/2002
- pr EN 13463-6/2002
- EN 1127-1/1997
- pr EN 13463-8/2001
- EN 13463-1/2001
- EN 50281-1/-2/1999

Kind of explosion protection for equipment group II of category 2 and 3:



-  II2 G/D ck T4/120 °C
-  II2 G/D bck T4/120 °C
-  II3 G/D ck T4/120 °C

EC Declarations of Conformity and/or EC Type Test Certificates for further equipment added to the gear unit and/or for safety systems are enclosed.

These may be specifically:


- Rotating electrical machines
- Safety systems for oil level and/or temperature monitoring equipment.

The technical documentation for gear units of category 2 has been subjected to a voluntary inspection and filed with the specified office no. 0123 TÜV PRODUCT SERVICE GmbH, Ridlerstraße 31, D-80339 München.

Tübingen, 03.05.2004  (p.p. Head of Gear Unit Development)  (p. p. Head of Quality Management)

Supplement to operating instructions

ATEX



MOTOX[®]-N

Gear units

and

gear motors

in ATEX design

Contents

| | | |
|------------|---|----------|
| 1.2 | Proper usage | 2 |
| 3.1 | General technical data on the rating plate | 2 |
| 5.11 | Coats of paint | 2 |
| 6.1 | General information on installation - Potential equalisation | 2 |
| 7.1.1 | Oil level check - Checking the oil level sensor | 2 |
| 10. | Maintenance and servicing of gear units in explosion-hazardous locations | 3 |
| 12. | Declaration of the manufacturer - Declaration of Conformity | 4 |

FLENDER **TÜBINGEN**

FLENDER TÜBINGEN GMBH · Bahnhofstr. 40-44 · D-72072 Tübingen
Tel. +49 (0) 7071/707-0 · Fax +49 (0) 7071/707-400 · <http://www.flender.com>
E-mail: sales-motox@flender-motox.com
A company of A. Friedr. Flender GmbH

114



Note.

These operating instructions contain only the supplements to **MOTOX®-N**-gear units in ATEX design.

Please note the complete sets of operating instructions BA F298 EN 12.01, BA K298 EN 12.01, BA G298 EN 12.01, BA S298 EN 12.01.

1.2 Proper usage

The gear motor satisfies the requirements of the explosion protection guideline 94/9/EC if the permitted conditions indicated on the rating plate are adhered to.

3.1 General technical data on the rating plate

| | |
|-----------------|---|
| FLENDER | 1 |
| TÜBINGEN | 2 |
| 3 | |
| 4 | |
| 5 | |
| 6 | |

- 1 Type designation
- 2 Assembly option, order number
- 3 Output speed, T_2 = output torque, transmission ratio, service factor, input speed, T_1 = input torque
- 4 Explosion-Hazard symbol and explosion-hazard marking, CE marking
- 5 Oil quantity, oil grade, weight
- 6 Bearing life

5.11 Coats of paint

Plastic surfaces exposed to friction in normal operation can become electrostatically charged. With use in zone 21 and 22 (dusts) the thickness of the paint coat must not exceed 200 μm .

6.1 General information on installation

Potential equalisation

When mounting or connecting the gear unit to the machine care must be taken that potential is equalised. (Affect on bearings of stray electric currents from electrical equipment).

7.1.1 Oil level check

Checking the oil level sensor

To check the oil level sensor, the oil level must be lowered and raised until the sensor emits a control signal. Observe the separate operating instructions for the oil level sensor.

115

10. Maintenance and servicing of gear units in explosion-hazardous locations

| Measures | Periods | Remarks |
|--|---|--|
| Observe and check gear units for noise, vibration or changes | from time to time, more often during operation if possible | Changes are an indication of possible incipient damage. |
| Check oil temperature | after 1h, 5h, 1 day, then weekly | The housing temperature must not exceed 90 °C. The temperature must be measured at the lowest point (oil sump), using a suitable temperature sensor. |
| Checking oil level | after the 1st day, then weekly | |
| Check gear units for leaks | after the 1st day, then weekly | |
| First oil change after start-up | after approx. 10 000 operating hours, at the latest after 3 years | |
| subsequent oil changes | every 3 years or 10 000 operating hours | |
| Relubricating the rolling bearings | yearly or every 5 000 operating hours | |
| Checking the function of the oil sensor | regularly and after oil change | To check the oil level sensor, the oil level must be lowered and then raised again until the sensor emits a control signal. Observe separate operating instructions. |
| Checking the coupling | for first time after 3 months | Observe separate operating instructions. |
| Cleaning the drive | according to level of contamination | Dust deposits prevent heat radiation and cause high operating temperatures. |
| Bearing renewal | The bearing life depends very much on the operating conditions. It is therefore very difficult to calculate it reliably. If the operating conditions are specified by the operator, the bearing life can be calculated and indicated on the rating plate. If no information is given, changes in the vibration and noise pattern can serve as an indication that an immediate bearing replacement is necessary. | |
| Check that covers and plugs are securely fastened | regularly | Entry of foreign bodies may cause sparks. |
| Check that fastening screws of mounted elements are securely tightened | after 1h, then regularly | Loose parts can cause sparks through impact. |

All measures and checks and their results must be documented by the operator and kept in a safe place.

Maintenance and servicing must be carried out only by properly trained, authorised personnel. Only parts supplied by Flender must be used for servicing.

12. Declaration of the manufacturer - Declaration of Conformity

EG Declaration of Conformity

Document no. KE GKFSN298 DE / 12.02



Equipment designation: **MOTOX®-N gear unit series**
Type: **E, Z, D, F, K, C**
Sizes: **38 to 188**
Add-on subassemblies: **A and K**

The designated equipment conforms to the requirements of the explosion protection guideline 94/9/EEC.

The designated equipment has been developed and manufactured in conformity to the following European standards:

- EN 1050/1996
- pr EN 13463-5/2002
- pr EN 13463-6/2002
- EN 1127-1/1997
- pr EN 13463-8/2001
- EN 13463-1/2001
- EN 50281-1/-2/1999

Kind of explosion protection for equipment group II of category 2 and 3:

-  II2 G/D ck T4/120°C
-  II2 G/D bck T4/120°C
-  II3 G/D ck T4/120°C


EC Declarations of Conformity and/or EC Type Test Certificates for further equipment added to the gear unit and/or for safety systems are enclosed.


These may be specifically:

- Rotating electrical machines
- Safety systems for oil level and/or temperature monitoring equipment

The technical documentation for gear units of category 2 has been subjected to a voluntary inspection and deposited with the specified office no. 0123 TÜV PRODUCT SERVICE GmbH, Ridlerstraße 31, D - 80339 München.

Tübingen, 17.12.2002


(Head of Gear Unit Development)


(Head of Quality Management)



Bredgar Road, Gillingham, Kent, ME8 6PN
Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
Fax: 01634 386684 Internet: www.mixertech.co.uk

Operating and Maintenance Manual

Proximity Switch Instructions



Operating Distance

The operating distance is the most important characteristic of a proximity switch. On a physical basis, the following approximate formula applies to inductive and capacitive sensors

$$S \leq D/2,$$

Where D is the diameter of the sensing face of the sensor.


Magnetic sensors with the magnets supplied by Pepperl+Fuchs have an operating distance of up to 60mm.

Definition of Operating Distance

Nominal Operating Distance s_n

(defined in IEC 947-2-5 as "Rated Operating Distance") is obtained empirically from axial proximity to a standard square measuring plate made from St 37 (EN 50010).

The plate must be 1mm thick and have sides of length = 1.inner circle diameter or: $3 \cdot s_n$, which ever is the greater value.



Actual Operating Distance s_r

The operating distance of a single proximity switch, measured at an ambient temperature of $(23 \pm 5) ^\circ\text{C}$, at a voltage within the operating voltage range and with the specified conditions of installation: $0,9 \cdot s_n \leq s_r \leq 1,1 \cdot s_n$

Usable Operating Distance s_u

Operating distance of a single proximity switch, measured in an ambient temperature range between -25°C and $+70^\circ\text{C}$ and at a supply voltage between 85% and 110% of the rated operating voltage: $0,9 \cdot s_r \leq s_u \leq 1,1 \cdot s_r$

Assured Operating Distance s_a

Distance from the sensing surface at which the actuation of the proximity switch is assured under specified conditions:

$$0 \leq s_a \leq 0,81 \cdot s_n$$


Repeat Accuracy R

Variation of the actual operating distance (s_r), measured over a period of eight hours, with a housing temperature $(23 \pm 5) ^\circ\text{C}$, at an arbitrary relative humidity and with a supply voltage $U_e \pm 5\%$ or with an arbitrary voltage $\pm 5\%$ within the rated operating voltage range:

$$R \leq 0,1 \cdot s_r$$

Differential Travel H


Distance between the switching points obtained when the measuring plate approaches the proximity switch and when the measuring plate moves away from the proximity switch. The distance is given relative to the actual operating distance s_r , measured at an ambient temperature of $(23 \pm 5) ^\circ\text{C}$ and at the rated operating voltage: $H \leq 0,2 \cdot s_r$






Operating Distance

Axial proximity to the standard measuring plate has been accepted as the criterion for measuring the operating distance. However if the plate is moved laterally within the active sensing zone, then a different operating distances is obtained, dependent on the distance from the axis. This relationship is described by the **Response Curve**.



Response curve for the NJ8-18... Inductive sensor.




Response curve for the CJ8-18... Capacitive sensor.


For slotted sensors, the response is dependent only on the depth to which the object is inserted in the slot.

Factors which affect the Operating Distance

The nature of the material of the damping element plays a significant role. This is described by the **Reduction Factor**. The reduction factor is the factor by which the operating distance is reduced for a given material relative to that for St 37 steel. The smaller the reduction factor, the smaller is the operating distance for that specific material.



For inductive sensors the characteristic parameter is the ratio **Conductance / Permeability**.




For capacitive sensors the characteristics parameter is the **Relative Permittivity ϵ_r** .



Operating Distance

The greatest possible operating distance (in relation to the diameter) is achieved with non-flush mounted sensors. The minimum values given in the table are suggested for their installation (dimensions in mm).



| | A | | B | | C |
|--------------------|---------------|-------|---------|-------|---------------------------------------|
| Inductive Sensors | $2 \cdot s_n$ | | 3 · D | | flush: C = D not-flush: C = 3·D |
| Capacitive Sensors | Plastic | Metal | Plastic | Metal | |
| CJ 1 ... | 5 | 15 | 15 | 30 | 60 |
| CJ 4 ... | 20 | 35 | 80 | 120 | 60 |
| CJ 2 ... | 15 | 50 | 30 | 60 | 100 |
| CJ 6 ... | 40 | 50 | 80 | 160 | 100 |

- D – Sensor face diameter
- A – Height of sensor face above mounting surface.
- B – Slot width.
- C – Distance separating the sensor face Edges
- E – Distance between upper face of installation and the metallic object ($\geq s_n$)



Please enquire if in doubt.

Flush mountable inductive and capacitive sensors (A=0) have advantages: They are better mechanically protected and less sensitive than non-flush mountable sensors to fault inducing influences. This is achieved by a special internal screening.

Flush mountable sensors achieve approximately 60% of the operating distance of sensors intended for non-flush mounting.

Magnetic sensors can also be flush mounted.

Sensors are often mounted next to each other. The minimum separations C, given in the table, should be maintained in order to avoid mutual interference.





Electrical Data and Connections

Pepperl+Fuchs supply sensors with AC or DC outputs. The table opposite provides an overview of the type available.

Direct Voltage Sensors, Two-Wire, Type Z are operated in series with the load. Several are provided with a Graetz bridge at the input and tolerant to polarity reversal, others are short circuit protected and protected against polarity reversal and are this extremely easy to handle.

A small off-state current follows in the switched off conditions. When switched in circuit a relatively small voltage drop occurs across the switching element. The sensors are available as

- Normally open (ZO),
- Normally closed (Z1),
- Wiring programmable (Z2).

Direct Voltage Sensors, Three-Wire, Type E

These sensors have separate connections for the power and for the load. They are protected from overload, short circuit and polarity reversal. The off-state current is negligible. They are supplied as

- Normally open, switched low (E bzw. EO),
- Normally closed, switched low (E1),
- Normally open, switched high (E2)
- Normally closed, switched high (E3).

Direct Voltage Sensors, Four-Wire, Type A

These sensors correspond to the E type, but are provided with a normally closed and a normally open output:

- Normally closed and normally open, Switched high (A)
- Normally closed and normally open, Switched low (A2).

Alternating Voltage Sensors, Two-Wire, Type W

Are operated in series with load. Depending on the function, a small off-state current

flows in the switched-off condition and a voltage drop occurs at the switch. They are supplied as

- Normally closed (Wö),
- Normally open (WS),
- Normally closed or normally open (W) (Wiring programmable).


Universal Mains Sensors, Two-Wire, Type U

are operated in series with the load. There is an off-state current in the switched-off condition and a voltage drop to consider when the sensors are switched in circuit. They are supplied as

- Normally closed (Uö),
- Normally open (US),
- Normally closed or normally open (U) (Wiring programmable).

NAMUR Sensors, Two-Wire, N

Namur* sensors, in accordance with DIN



19234, are two-wire sensors which have either a uniform or non-uniform path-current characteristic.

The characteristic values of voltage and current are maintained sufficiently low, that the NAMUR sensors can be used in hazardous areas (ignition protection class "intrinsically safe").


The following types are supplied:

- Normally closed (N) and
- Normally open (1N).




Electrical Data and Connections

Due to the extended electronics in the NAMUR sensor, it is possible to obtain a binary switching behaviour in the sensor (defined hysteresis/differential travel) by maintaining the standardised voltage and current values.



NAMUR sensors can be connected to external switching amplifiers to convert the current variations in a binary output signal. Pepperl+Fuchs offers a range of switching amplifiers for Ex and non-Ex applications.



*e.g. Pepperl+Fuchs KCD2-EL
KFD2-SR-Ex1
EG2-R

*e.g. Pepperl+Fuchs KCD2-EL
KFD2-SR-Ex1
EG2-R

Safety Sensors, Two-Wire, SN

These sensors correspond to the N-types, but with an additional function, however: if a fault develops in the sensor, or the interface unit, or the connecting wiring, the output is automatically switched to the safe "OFF" state. The circuit combination of the proximity switch and the interface unit is approved by the TÜV on the basis of DIN VDE 0660 Part 209 to provide a contact – free actuating position switch for safety functions. Both components are constructed in accordance with the Fail-Safe switching principle. The following types are available:

- Normally closed (SN) and
- Normally open (S1N).

Parallel and Series Connection

Proximity switches can be connected in parallel or in series, in order to achieve simple logic functions (AND, OR, NAND, NOR).

Combinations with mechanical switches are also possible. In accordance with the Ex-Regulation, NAMUR sensors may not be connected either in parallel or in series.

| | Parallel | Serial |
|------------|---|--|
| Two-Wire | Note off-state current, Note time delay not NAMUR sensors | Note voltage drop not NAMUR sensors |
| Three-Wire | De-coupling diodes recommended | Note voltage drop Note time delay |



General Specification

Permissible Shock and Vibration Loading

Shock proof testing is carried out at 30 x acceleration (30 g) over a duration of 11 ms; the vibration testing at 55 Hz and 1 mm amplitude (IEC 68-2-6 und -7).

Permissible Tightening Torque Settings [Nm]

| | Special Steel | Brass | PBT |
|------------|---------------|-------|------|
| M 5 x 0,5 | 3,0 | - | - |
| M 8 x 1 | 10,0 | 3,0 | - |
| M 12 x 1 | 15,0 | 10,0 | 0,75 |
| M 18 x 1 | 30,0 | 30,0 | 1,5 |
| M 30 x 1,5 | 30,0 | 30,0 | 3,0 |

Wiring Colour Codes and Connector Layout (IEC 947-5-2)

| Type | Function | Polarity | Wiring Colours/Terminals |
|--------|----------|----------|---|
| 2-Wire | N.O. | free | 3,4 any colour except green, yellow |
| AC | N.C. | free | 1,2 any colour except green, yellow |
| or | N.O. | note | L+ brown (1), L- blue (4) |
| DC | N.C. | note | L+ brown (1), L- blue (2) |
| 3-Wire | N.O. | note | L+ brown (1), L- blue (3), Output black (4) |
| DC | N.C. | note | L+ brown (1), L- blue (3), Output black (2) |
| 4-Wire | N.O. | note | L+ brown (1), L- blue (3), N.C. white (2), N.O. black (4) |
| DC | N.C. | note | L+ brown (1), L- blue (3), N.C. white (2), N.O. black (4) |

Switches which are not protected by insulation require a connection for a protective conductor for voltages over 50 VAC and 120 VDC.



General Specification

The **No-Load Supply Current** I_0 is the self current requirement of the sensor. It is measured with load.

The **Operating Current** I_L is the maximum load current for continuous operation.

The **Short Time Current** I_k is the current which can occur for a short period on switch on, without damaging the sensor.


The **Off-State Current** I_R is the current that flows across the load when the sensor is switched off.

The **Operating Voltage** U_B is given as a maximum value of the supply voltage. Safe operation of the sensor is assured within this range. In the case of NAMUR sensors the nominal voltage is stated.

The **Voltage Drop** U_d is measured across the driven sensor or output.

The **Ripple Voltage** is the alternating voltage which is superimposed on the operating voltage (peak-peak) and is stated as a percentage of the arithmetic mean value. Pepperl+Fuchs sensors correspond with the standard DIN EN 50 008 in having a maximum of 10% ripple.

The **Switching Frequency** (frequency of operating cycles) is the maximum number of



Reversals from damped to non-damped state, measured in Hertz (Hz)-sec IEC 947-5-2, Appendix 1.

Permissible Interference Voltage

Short term voltage peaks on the supply leads can destroy unprotected sensors. All Pepperl+Fuchs sensors have a transients protection which suppresses interface pulses up to 1 kV over 10ms duration.

The **Time Delay** t_v is the period of time that passes between connecting the supply voltage to a proximity switch and the switch being ready for operation.

Suppression of Switch On Pulses

All Pepperl+Fuchs sensors are equipped with a device which suppresses a fault signal at the output over a period of time t_f when the operating voltage is first applied.

Short Circuit Protection

With a pulsing short circuit protection, with which all Pepperl+Fuchs sensors are equipped, the output is periodically blocked and released again if the limiting current is exceeded, until the short circuit has been eliminated.


The **Permissible Ambient Temperature** is the temperature range within which the sensor normally functions. The temperature range applicable to the Pepperl+Fuchs Standard Series is: -25°C +70°C or 248K 343 K.

The following ranges apply to special types:

| | | | |
|-------|---------|----------|-------|
| -25°C | + 100°C | or 248 K | 373 K |
| -40°C | + 150°C | or 233 K | 423 K |
| 0°C | + 200°C | or 273 K | 473 K |

Protection Class

Pepperl+Fuchs sensors are protected, as appropriate, in accordance with IP 65, IP 67 or IP 68 (DIN 40050 and IEC 529) (see chapter Additional information).



Bredgar Road, Gillingham, Kent, ME8 6PN
Tel: 01634 386683 e.mail: sales @ mixertech.co.uk
Fax: 01634 386684 Internet: www.mixertech.co.uk

Confidential

**TITLE: REMOVABLE FLANGE COUPLING
 FITTING PROCEEDURE**

Modification



Please refer to Drawing No. 1000/01

- 1. Ensure shaft end, and inside of coupling are clean and free from burrs.*
- 2. Ensure shoulder on shaft is also clean and free from burrs.*
- 3. Fit key (5) into shaft.*
- 4. Smear shaft with copper slip or other anti-galling substance.*
- 5. Slide coupling (4) onto shaft (1).*
- 6. Ensure shaft sits down on shaft shoulder and the slide fit is a neat fit i.e. coupling does not rock on shaft.*
- 7. Fit locating/spigot plate (3) to coupling ensure shaft end does not protrude past spigot plate face.*
- 8. Fit 8.8 H.T bolts c/w spring washer and torque to recommend bolting torques given in service manual for the correct bolt size. Ensure bolt heads do not protrude outside spigot plate.*
- 9. Remove coupling in reverse order.*



Bredgar Road, Gillingham, Kent, ME8 6PN
 Tel: 01634 386683 e.mail: sales@mixertech.co.uk
 Fax: 01634 386684 Internet: www.mixertech.co.uk

| Electrical Supply | Code | Standard Symbol | Circuit Principle / Technical Data. |
|--|--|--|--|
| Direct Voltage 10 V ... 60 V | 2-Wire Z Z0, Z1, Z2 polarity reversal protected short circuit protected | switched high pnp Normally open, NO or Normally closed, NC | <p>Base Series 5 V / 4 mA... 100 mA Stand. Series 4 V / 2 mA... 200 mA Off-state curr. 0,7 mA</p> npn ohmic load output L+ L- |
| | Base Series 10 V ... 30 V 100 mA Standard Series 10 V ... 60 V 200 mA | 3-Wire E, E0, E1, E2, E3 short circuit protected polarity reversal protected | |
| Alternating voltage 20 V ... 250 V | Vierdraht A A2 short circuit protected polarity reversal protected | switched high pnp Normally closed, NC and Normally open, NO | <p>Voltage drop 2,5 V / Off-state current 0,3 mA Operating volt. 0 mA ... 200 mA No load current 20 mA</p> <p>Data as for Type A</p> <p>Voltage drop "on": 6 V Off-state current 1 mA Operating volt. 5 mA ... 500 mA</p> |
| | WS W0 W W3 | Normally closed, NC and Normally open, NO | |
| Universal voltage 20 V ... 250 VAC 45 Hz ... 65 Hz 30 V...300 VDC | US U0 | Normally closed, NC or Normally open, NO | <p>Voltage drop "on": 5 V Off-state current 1,5 mA Operating volt. 5 mA ... 500 mA</p> |
| Direct Voltage 8 V | NAMUR N 1N SN S1N DIN 19234 | Normally closed, NC or Normally open, NO | <p>Universal voltage 8 V Output current < 1 mA actuated > 3 mA unactuated</p> |





PLEASE REMEMBER TO QUOTE YOUR
ORDER No OR OUR CONTRACT No
WHEN MAKING SPARES EQUITIES.

| ITEM No | No OFF | DESCRIPTION |
|---------|--------|-------------------------|
| A | 1 | ELECTRIC MOTOR |
| B | 1 | REDUCTION GEARHEAD |
| C | 1 | ANGLE BASE PLATE |
| D | 1 | SLEEVE COUPLING |
| E | 1 | OUTPUT SHAFT |
| F | 1 | HIGH EFFICIENCY TURBINE |
| G | 1 | GEARED MOTOR |

TITLE:
1000 SERIES MIXER
PARTS LIST

DRG No:
1000S/AP/1T





PLEASE REMEMBER TO QUOTE YOUR
ORDER No OR OUR CONTRACT No
WHEN MAKING SPARES EQUIRIES.

| ITEM No | No OFF | DESCRIPTION |
|---------|--------|-------------------------|
| A | 1 | ELECTRIC MOTOR |
| B | 1 | REDUCTION GEARHEAD |
| C | 1 | MOUNTING BASE PLATE |
| D | 1 | INPUT SHAFT |
| E | 1 | FLANGE COUPLING |
| F | 1 | OUTPUT SHAFT |
| G | 1 | HIGH EFFICIENCY TURBINE |
| J | 1 | REDUCTION GEARBOX |

TITLE: 1000 SERIES MIXER PARTS LIST

DRG No: 1000S/FC/1T





PLEASE REMEMBER TO QUOTE YOUR
ORDER No OR OUR CONTRACT No
WHEN MAKING SPARES EQUITIES.

| ITEM No | No OFF | DESCRIPTION |
|---------|--------|-------------------------|
| A | 1 | ELECTRIC MOTOR |
| B | 1 | REDUCTION GEARHEAD |
| C | 1 | MOUNTING BASE PLATE |
| D | 1 | INPUT SHAFT |
| E | 1 | SPLIT MUFF COUPLING |
| F | 1 | OUTPUT SHAFT |
| G | 1 | HIGH EFFICIENCY TURBINE |
| H | 1 | TURBINE BOSS |
| J | 1 | REDUCTION GEARBOX |

TITLE:
1000 SERIES MIXER
PARTS LIST

DRG No:
1000S/FC/2T




PLEASE REMEMBER TO QUOTE YOUR
ORDER No OR OUR CONTRACT No
WHEN MAKING SPARES EQUIRIES.

| ITEM No | No OFF | DESCRIPTION |
|---------|--------|-------------------------|
| A | 1 | ELECTRIC MOTOR |
| B | 1 | REDUCTION GEARHEAD |
| C | 1 | MOUNTING BASE PLATE |
| D | 1 | INPUT SHAFT |
| E | 1 | SPLIT MUFF COUPLING |
| F | 1 | OUTPUT SHAFT |
| G | 1 | HIGH EFFICIENCY TURBINE |
| H | 1 | TURBINE BOSS |
| J | 1 | REDUCTION GEARBOX |

TITLE:
1000 SERIES MIXER
PARTS LIST

DRG No:
1000S/FC/3T

PLEASE QUOTE OUR CONTRACT
 No OR YOUR ORDER No ON ALL
 PARTS ENQUIRIES.



| ITEM No | DESCRIPTION | No | OFF |
|---------|-------------------|----|-----|
| A | ELECTRIC MOTOR | 1 | |
| B | GEARHEAD | 1 | |
| C | LOWER HOUSING | 1 | |
| D | FLANGE COUPLING | 1 | |
| E | MECH SEAL PLATE | 1 | |
| F | OUTPUT SHAFT | 1 | |
| G | TURBINE | 1 | |
| H | REDUCTION GEARBOX | 1 | |


TITLE

2000 SERIES MIXER
 PARTS LIST

DRG No

2000/FC/1T

PLEASE QUOTE OUR CONTRACT
 No OR YOUR ORDER No ON ALL
 PARTS ENQUIRIES.



| ITEM No | DESCRIPTION | No | OFF |
|---------|-------------------|----|-----|
| A | ELECTRIC MOTOR | 1 | |
| B | GEARHEAD | 1 | |
| C | LOWER HOUSING | 1 | |
| D | FLANGE COUPLING | 1 | |
| E | GLAND PLATE | 1 | |
| F | OUTPUT SHAFT | 1 | |
| G | TURBINES | 2 | |
| H | REDUCTION GEARBOX | 1 | |


TITLE

2000 SERIES MIXER
 PARTS LIST

DRG No 2000/FC/2T

12

PLEASE QUOTE OUR CONTRACT
 No OR YOUR ORDER No ON ALL
 PARTS ENQUIRIES.




| ITEM No | DESCRIPTION | No | OFF |
|---------|-------------------|----|-----|
| A | ELECTRIC MOTOR | 1 | |
| B | GEARHEAD | 1 | |
| C | LOWER HOUSING | 1 | |
| D | FLANGE COUPLING | 1 | |
| E | LIPSEAL PLATE | 1 | |
| F | OUTPUT SHAFT | 1 | |
| G | TURBINES | 2 | |
| H | REDUCTION GEARBOX | 1 | |

TITLE

2000 SERIES MIXER
 PARTS LIST

DRG No 2000/HS/2T

PLEASE REMEMBER TO QUOTE YOUR
ORDER No OR OUR CONTRACT No
WHEN MAKING SPARES EQUIRIES.




| ITEM No | No OFF | DESCRIPTION |
|---------|--------|-----------------------|
| A | 1 | ELECTRIC MOTOR |
| B | 1 | REDUCTION GEARHEAD |
| C | 1 | MOUNTING BASE PLATE |
| D | 1 | OUTPUT SHAFT |
| E | 1 | RIGID FLANGE COUPLING |
| F | 3 | TURBINE BLADE |
| G | 1 | TURBINE |
| H | 1 | TURBINE BOSS |
| J | 1 | REDUCTION GEARBOX |

TITLE: 3000 SERIES MIXER PARTS LIST

DRG No: 3000/FC/1T

PLEASE REMEMBER TO QUOTE YOUR
ORDER No OR OUR CONTRACT No
WHEN MAKING SPARES EQUIRIES.




| ITEM No | No OFF | DESCRIPTION |
|---------|--------|---------------------|
| A | 1 | ELECTRIC MOTOR |
| B | 1 | REDUCTION GEARHEAD |
| C | 1 | MOUNTING BASE PLATE |
| D | 1 | OUTPUT SHAFT |
| F | 3 | TURBINE BLADE |
| G | 1 | TURBINE |
| H | 1 | TURBINE BOSS |
| J | 1 | REDUCTION GEARBOX |

TITLE: 3000 SERIES MIXER PARTS LIST


DRG No: 3000/SM/1T

| BOLT DIA. | REQUIRED BOLT TORQUE (Nm) | |
|-----------|---------------------------|-------------------|
| | GR. 4,6 & St/St BOLTS | GR. 8,8 HTS BOLTS |
| 10 | 28 | 42 |
| 12 | 50 | 72 |
| 16 | 115 | 178 |
| 20 | 217 | 348 |
| 24 | 320 | 600 |
| 30 | 586 | 1190 |



| | | |
|------------------|----------------------|--|
| SCALE: N.T.S. | MANUFACTURING NOTES: | |
| | DRAWN: A.E.ISAACS | TITLE: SINGLE HA700 IMPELLER / FLANGE COUPLING |
| | DATE: 97/07/02 | DRG. No.: TORQUE CHART 1 |
| | REV. | |

| BOLT DIA. | REQUIRED BOLT TORQUE (Nm) | |
|-----------|---------------------------|-------------------|
| | GR. 4,6 & St/St BOLTS | GR. 8,8 HTS BOLTS |
| 10 | 28 | 42 |
| 12 | 50 | 72 |
| 16 | 115 | 178 |
| 20 | 217 | 348 |
| 24 | 320 | 600 |
| 30 | 586 | 1190 |



SCALE:
N.T.S.

DRAWN:
A.E.ISAACS

DATE:
97/07/02


MANUFACTURING NOTES:

TITLE: SINGLE HA700 IMPELLER, STABILISED / FLANGE COUPLING

DRG. No.: TORQUE CHART 2

REV.

| BOLT DIA. | REQUIRED BOLT TORQUE (Nm) | |
|-----------|---------------------------|-------------------|
| | GR. 4,6 & St/St BOLTS | GR. 8,8 HTS BOLTS |
| 10 | 28 | 42 |
| 12 | 50 | 72 |
| 16 | 115 | 178 |
| 20 | 217 | 348 |
| 24 | 320 | 600 |
| 30 | 586 | 1190 |



SCALE:
N.T.S.

DRAWN:
A.E.ISAACS

DATE:
97/07/02

MANUFACTURING NOTES:

TITLE: DOUBLE HA700 IMPELLERS / FLANGE COUPLING.

DRG. No.: TORQUE CHART 3


REV.

139

| BOLT DIA. | REQUIRED BOLT TORQUE (Nm) | |
|-----------|---------------------------|-------------------|
| | GR. 4,6 & St/St BOLTS | GR. 8,8 HTS BOLTS |
| 10 | 28 | 42 |
| 12 | 50 | 72 |
| 16 | 115 | 178 |
| 20 | 217 | 348 |
| 24 | 320 | 600 |
| 30 | 586 | 1190 |

BOLT HEAD THIS SIDE.
2, 3 OR 5 BOLTS
MAY BE FITTED

DOWN PUMPING HYDRO BLADE
IMPELLER, CAN BE 2 OR 3 BLADES.




BLADES MUST BE POSITIONED
ON FRONT OF EARS AS SHOWN.

DIRECTION OF ROTATION

BOLT HEAD THIS SIDE.
2, 3 OR 5 BOLTS
MAY BE FITTED

STIFFENER RIB MAY OR
MAY NOT BE FITTED.



DOWN PUMPING HYDRO BLADE
IMPELLER, CAN BE 2 OR 3 BLADES,
STABILISER FINS FITTED.

SCALE:
N.T.S.

MANUFACTURING NOTES:

DRAWN:
A.E.ISAACS

TITLE: DOUBLE HA700 IMPELLER, LOWER IMPELLER
STABILISED / FLANGE COUPLING.

DATE:
97/07/02

DRG. No.: TORQUE CHART 4

REV.

140

| BOLT DIA. | REQUIRED BOLT TORQUE (Nm) | |
|-----------|---------------------------|-------------------|
| | GR. 4,6 & St/St BOLTS | GR. 8,8 HTS BOLTS |
| 10 | 28 | 42 |
| 12 | 50 | 72 |
| 16 | 115 | 178 |
| 20 | 217 | 348 |
| 24 | 320 | 600 |
| 30 | 586 | 1190 |

BLADES MUST BE POSITIONED ON FRONT OF EAR AS SHOWN.

STIFFENER RIB MAY OR MAY NOT BE FITTED

UP PUMPING HYDRO BLADE IMPELLER, CAN BE 2 OR 3 BLADES.

BOLT HEAD THIS SIDE. 2, 3 OR 5 BOLTS MAY BE FITTED.

DIRECTION OF ROTATION

BOLT HEAD THIS SIDE. 2, 3 OR 5 BOLTS MAY BE FITTED.

STIFFENER RIB MAY OR MAY NOT BE FITTED

BLADES MUST BE POSITIONED ON FRONT OF EAR AS SHOWN.

DOWN PUMPING HYDRO BLADE IMPELLER, CAN BE 2 OR 3 BLADES.

SCALE:
N.T.S.

DRAWN:
A.E.ISAACS

DATE:
97/07/02

MANUFACTURING NOTES:


TITLE: HA700 & HA800 IMPELLERS / FLANGE COUPLING

DRG. No.: TORQUE CHART 5

REV.

141


| BOLT DIA. | REQUIRED BOLT TORQUE (Nm) | |
|-----------|---------------------------|-------------------|
| | GR. 4,6 & St/St BOLTS | GR. 8,8 HTS BOLTS |
| 10 | 28 | 42 |
| 12 | 50 | 72 |
| 16 | 115 | 178 |
| 20 | 217 | 348 |
| 24 | 320 | 600 |
| 30 | 586 | 1190 |



| | | |
|----------------------|---|---------------------------|
| SCALE: N.T.S. | MANUFACTURING NOTES: | |
| DRAWN: A.E.ISAACS | TITLE: HA700 & HA800 IMPELLERS, LOWER IMPELLER STABILISED / FLANGE COUPLING | |
| DATE: 97/07/02 | DRG. No.: TORQUE CHART 6 | REV. <input type="text"/> |

Handwritten initials/signature


| BOLT DIA. | REQUIRED BOLT TORQUE (Nm) | |
|-----------|---------------------------|-------------------|
| | GR. 4,6 & St/St BOLTS | GR. 8,8 HTS BOLTS |
| 10 | 28 | 42 |
| 12 | 50 | 72 |
| 16 | 115 | 178 |
| 20 | 217 | 348 |
| 24 | 320 | 600 |
| 30 | 586 | 1190 |



| | | | |
|--|----------------------|--|------|
| | SCALE: N.T.S. | MANUFACTURING NOTES: | |
| | DRAWN: A.E.ISAACS | TITLE: SINGLE HA745 IMPELLER / FLANGE COUPLING | |
| | DATE: 97/07/02 | DRG. No.: TORQUE CHART 7 | REV. |

143

| BOLT DIA. | REQUIRED BOLT TORQUE (Nm) | |
|-----------|---------------------------|-------------------|
| | GR. 4,6 & St/St BOLTS | GR. 8,8 HTS BOLTS |
| 10 | 28 | 42 |
| 12 | 50 | 72 |
| 16 | 115 | 178 |
| 20 | 217 | 348 |
| 24 | 320 | 600 |
| 30 | 586 | 1190 |



BOLT HEADS THIS SIDE.
2, 4 OR 6 BOLTS
MAY BE FITTED.

DIRECTION OF ROTATION

BOLT HEADS THIS SIDE.
2, 4 OR 6 BOLTS
MAY BE FITTED.

STIFFENER RIB MAY OR
MAY NOT BE FITTED.

BLADES MUST BE POSITIONED
ON FRONT OF EARS AS SHOWN.

DOWN PUMPING PITCHED BLADE
IMPELLER, CAN BE 2 OR 4 BLADES.

SCALE:
N.T.S.

MANUFACTURING NOTES:

DRAWN:
A.E.ISAACS

TITLE: DOUBLE HA745 IMPELLER / FLANGE
COUPLING


DATE:
97/07/02

DRG. No.: TORQUE CHART 8

REV.

144


| BOLT DIA. | REQUIRED BOLT TORQUE (Nm) | |
|-----------|---------------------------|-------------------|
| | GR. 4,6 & St/St BOLTS | GR. 8,8 HTS BOLTS |
| 10 | 28 | 42 |
| 12 | 50 | 72 |
| 16 | 115 | 178 |
| 20 | 217 | 348 |
| 24 | 320 | 600 |
| 30 | 586 | 1190 |



| | | |
|------------------|----------------------|---|
| SCALE: N.T.S. | MANUFACTURING NOTES: | |
| | DRAWN: A.E.ISAACS | TITLE: HA745 & HA700 IMPELLERS / FLANGE COUPLING. |
| | DATE: 97/07/02 | DRG. No.: TORQUE CHART 9 |
| | REV. | |

45


| BOLT DIA. | REQUIRED BOLT TORQUE (Nm) | |
|-----------|---------------------------|-------------------|
| | GR. 4,6 & St/St BOLTS | GR. 8,8 HTS BOLTS |
| 10 | 28 | 42 |
| 12 | 50 | 72 |
| 16 | 115 | 178 |
| 20 | 217 | 348 |
| 24 | 320 | 600 |
| 30 | 586 | 1190 |



| | | |
|----------------------|--|------|
| SCALE: N.T.S. | MANUFACTURING NOTES: | |
| | TITLE: HA745 & HA800 IMPELLERS / FLANGE COUPLING | |
| | DRG. No.: TORQUE CHART 10 | REV. |
| DRAWN: A.E.ISAACS | | |
| DATE: 97/07/02 | | |

146


| BOLT DIA. | REQUIRED BOLT TORQUE (Nm) | |
|-----------|---------------------------|-------------------|
| | GR. 4,6 & St/St BOLTS | GR. 8,8 HTS BOLTS |
| 10 | 28 | 42 |
| 12 | 50 | 72 |
| 16 | 115 | 178 |
| 20 | 217 | 348 |
| 24 | 320 | 600 |
| 30 | 586 | 1190 |



| | | |
|------------------|----------------------|--|
| SCALE: N.T.S. | MANUFACTURING NOTES: | |
| | DRAWN: A.E.ISAACS | TITLE: SINGLE HA745 IMPELLER / FLANGE COUPLING |
| | DATE: 97/07/02 | DRG. No.: TORQUE CHART 11 |
| | REV. | |

14


| BOLT DIA. | REQUIRED BOLT TORQUE (Nm) | |
|-----------|---------------------------|-------------------|
| | GR. 4,6 & St/St BOLTS | GR. 8,8 HTS BOLTS |
| 10 | 28 | 42 |
| 12 | 50 | 72 |
| 16 | 115 | 178 |
| 20 | 217 | 348 |
| 24 | 320 | 600 |
| 30 | 586 | 1190 |



| | | |
|-----------------------|---|------|
| SCALE: N.T.S. | MANUFACTURING NOTES: | |
| DRAWN: A.E. ISAACS | TITLE: DOUBLE HA745 IMPELLER, LOWER IMPELLER STABILISED / FLANGE COUPLING | |
| DATE: 97/07/02 | DRG. No.: TORQUE CHART 12 | REV. |

146

| BOLT DIA. | REQUIRED BOLT TORQUE (Nm) | |
|-----------|---------------------------|-------------------|
| | GR. 4,6 & St/St BOLTS | GR. 8,8 HTS BOLTS |
| 10 | 28 | 42 |
| 12 | 50 | 72 |
| 16 | 115 | 178 |
| 20 | 217 | 348 |
| 24 | 320 | 600 |
| 30 | 586 | 1190 |



BOLT HEADS THIS SIDE.
2, 3 OR 5 BOLTS
MAY BE FITTED.

STIFFENER RIB MAY OR
MAY NOT BE FITTED.

BLADES MUST BE POSITIONED
ON FRONT OF EARS AS SHOWN.

DOWN PUMPING HYDRO BLADE
IMPELLER, CAN BE 2 OR 3 BLADES.

DIRECTION OF ROTATION

BOLT HEADS THIS SIDE.
2, 4 OR 6 BOLTS
MAY BE FITTED.

STIFFENER RIB MAY OR
MAY NOT BE FITTED.

RADIAL PUMPING VERTICAL PITCHED BLADE
IMPELLER, CAN BE 2, 4 OR 6 BLADES.

BLADES MUST BE POSITIONED
ON FRONT OF EARS AS SHOWN.

SCALE:
N.T.S.

MANUFACTURING NOTES:

DRAWN:
S PHILLIPS

TITLE: SINGLE HA700 IMPELLER / VPBT &
FLANGE COUPLING

DATE:
24.06.00

DRG. No.: TORQUE CHART 13

REV.


149

| | REQUIRED BOLT TORQUE (Nm) | |
|-----------|---------------------------|-------------------|
| BOLT DIA. | GR. 4,6 & St/St BOLTS | GR. 8,8 HTS BOLTS |
| 10 | 28 | 42 |
| 12 | 50 | 72 |
| 16 | 115 | 178 |
| 20 | 217 | 348 |
| 24 | 320 | 600 |
| 30 | 586 | 1190 |

| | | | |
|--|----------------------|---------------------------------------|---------------------------|
| | SCALE: N.T.S. | MANUFACTURING NOTES: | |
| | DRAWN: A.E.ISAACS | TITLE: BOLT TORQUE SETTINGS - GENERAL | |
| | DATE: 97/07/02 | DRG. No.: TORQUE CHART 17 | REV. <input type="text"/> |

150

IMPORTANT!



LOCATED BY EACH TURBINE (BOLTED ASST'S ONLY)

| BOLT DIA. | REQUIRED BOLT TORQUE (Nm) | |
|--------------|------------------------------|----------------------|
| | GR. 4,6 & St/St BOLTS | GR. 8,8 HTS BOLTS |
| 10 | 28 | 42 |
| 12 | 50 | 72 |
| 16 | 115 | 178 |
| 20 | 217 | 348 |
| 24 | 320 | 600 |
| 30 | 586 | 1190 |

LOCATED BY FLANGE COUPLING ASST

WARNING!

CHECK GEAR BOX
OIL LEVEL AT THIS
PLUG BEFORE
STARTING UNIT.

LOCATED BY REMOVABLE PLUG OF SILT LEVEL GROSS
OF GEARBOX



REMOVE PLUG AND FIT
BREATHER BEFORE
STARTING UNIT.

LOCATED ON GEARBOX


MIXERTECH LIMITED

Bredgar Road, Gillingham, Kent ME8 6PN

Telephone: 01634-386683 Fax: 01634-386684

E-mail: sales@mixertech.co.uk

www.mixertech.co.uk



SERIAL N°

TAG N°

MODEL N°

 D.O.M.

IMPORTANT



ROTATION

2000 Series Mixer NAME PLATE / Combo Detail

MIXERTECH
LIMITED

BREDGAR ROAD, GILLINGHAM, KENT ME8 6PN
 TELEPHONE: 01634 - 386683 FAX: 01634 - 386684
 E-MAIL: sales@mixertech.co.uk www.mixertech.co.uk

SERIAL NO. TAG NO.
 MODEL NO. D.O.M.

CE

1000 Series Hixel NAME LABEL

IMPORTANT  **ROTATION**

1000 Series Hixel Rotation LABEL



ENGINEERS IN FLUID
 MIXING TECHNOLOGY